



Emergency Brake Lining Sizes

Year	D.D.	Size W x Th. x Length	No. Pcs	Cat. No	Type
FLXIBLE-TWIN COACH					
64-66	F2D6V-401 & -7, 2636-DD-1, 1959 FT 33 & 35 & 40.....12	5x1/4x11-3/8.....1ea.	2021		Internal
65-68	FT35 & 40; 1955-56 FT30, 1951 S25 & S2.....12-1/4	5x1/2x10-51/64.....2			S w/R L
68-69	236DD1.....	5x1/2x14.....2			S w/R L
60-68	2183-DD1; 182's, 218's, 228's.....14-15	2-1/2x1/4x90°.....2	S-559		Tru-Stop
61	44TT2, 48TT2.....16	3x1/4x90°.....4	S-557		Tru-Stop
FORD TRUCK					
60-68	800, 850, 950, 1000, 1959-60, 350P, 400P, 1958-60, 500B.P.F., 1956-60 350, 400 & 500P; 500 B & F 1957.....12	4x1/4x14.....2	2085		Internal
60-65	F4-5 & 6, 1957, 600 & 650 B & F.....8	2-1/2x1/4x11-1/8.....2	6021		External
66-60	250 & 350 F; 1957-60 400 P; Also Some 1956 600 thru 900 Series.....8	2x5/32x12-5/16.....2	677		External
69-69	500(late), 600, 700 B & F, 550, 600, 700 C....9	3x3/16x10-1/2.....2	2095		Internal
69-69	750 B, C & F, 800 C & F.....9	3x3/16x10-9/16.....2	2086		Internal
69-69	850, 950, 1000, 1100 C & F & 800, 850, 950T..12	4x5/16x13-15/16.....2		S w/R L	Internal
66	600,700,750 800F.....9-1/2	3x5/16x9-3/4 & 10.....3	6035		External
66	800, 900.....10-1/2	3x5/16x9 & 11-7/8.....3			S w/R L
63-60	750T, 800F.....11-1/2	4x5/16x9-3/4 & 12-7/8.....3	6053		External
66-67	100F.....11	2x3/16x47-41/64.....1			S w/R L
70	P-350, 400 & 500.....9	2x7/32x10-1/4.....2 or 2-1/2x1/4x7-1/4...1 7-7/8...2			S w/R L
FOUR WHEEL DRIVE					
60-63	HG, R, RC, RT, RU.....10	3x1/4x14-3/4.....2	6038		External
61-63	HA, G, R & RC.....9-1/2	3x5/16x14-1/2.....2	667 or 103013		External
G.M.O. COACH					
60-67	4010, 4106, 4501-2-6-7-9-10-12-14-15-16 17, 18 & 19, 5105, 6, 8, 5301, 2, 3.....12	4-1/2x1/2x11-1/2.....2	4356		Internal
69-61	860 Series; 54-59 800 Series.....12	3x1/4x11-1/2.....2	2079		Internal
60-66	3701-2, 3751, 4101-3 & 4.....11	6x5/8x10-1/4 & 13.....1 ea.	4244		External
63	3102.....11	2x1/4x90°.....2	S-576		Tru-Stop
60-63	3101-2, 3205-9, 3608-9-10-12, 3714.....12	3x1/2x11-1/2.....2	4355		Internal