

## Module 4

| OVERHEADS                                                                                                                                                                                                                                                                                                                                                                                    | SCRIPT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | SG |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----|
| <p><b>REMOVAL PROCESS FOR RESISTORS</b></p> <ul style="list-style-type: none"> <li>- Two Persons</li> <li>- Cut wire leads on back of panel</li> <li>- Use power tool to remove two hexnuts</li> <li>- Remove resistor washer &amp; insulator</li> <li>- Use encapsulant as needed to seal resistors, washers and insulators</li> <li>- Wait 20 minutes before continuing removal</li> </ul> | <p>5. Prior to removal, a qualified person must perform an exposure assessment.</p> <p>Removal process for resistors:</p> <ul style="list-style-type: none"> <li>-Two person operation</li> <li>-One person cuts wire leads on back of panel</li> <li>-Second person uses power tool to remove two hex nuts</li> <li>-Remove resistor, washer and insulator</li> <li>-Use encapsulate, as appropriate, to seal resistors, washers and insulators. <b>WAIT 20 MINUTES BEFORE CONTINUING REMOVAL AND DISPOSAL OPERATION!</b></li> </ul> <p>If there is any possibility the resistor has been damaged during the removal process, it must be sealed with an encapsulate before disposal. If asbestos containing washers are identified inside the equipment, the washer and insulator should be encapsulated.</p> <p>As always, all asbestos containing waste should be disposed properly.</p> | 6  |
| <p><b>PICTORIAL OF ROLLING LADDER BRAKE ASSEMBLY</b></p>                                                                                                                                                                                                                                                                                                                                     | <p>6. The brake lining in rolling ladders equipped with top brakes is typically asbestos. Once the work area is protected, wet the brake lining pad and carefully remove. Properly bag and dispose of the brake lining.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 8  |