


REMOVAL AND INSTALLATION (Continued)



Item	Part Number	Description
1	2200	Brake shoes and linings (2 required)
2	—	Washer (part of 2A637 RH/ 2A638 LH)
3	—	Parking brake lever pin retainer (part of 2A637 RH/ 2A638 LH)
4	—	Brake shoe guide plate (part of 2C077)
5	—	Primary brake shoe retracting spring (part of 2296)
6	—	Parking brake strut (part of 2C077)
7	—	Parking brake strut spring (part of 2C077)
8	—	Brake shoe adjusting screw spring (part of 2296)
9	2041	Brake shoe adjusting screw
10	—	Cable guide (part of 2A176 RH/ 2A177 LH)

(Continued)

Item	Part Number	Description
11	—	Brake shoe adjusting lever cable (part of 2A176 RH/ 2A177 LH)
12	—	Secondary brake shoe retracting spring (part of 2296)
13	—	Brake shoe hold-down spring (part of 2296)
14	—	Brake shoe adjusting lever cable spring (part of 2A176 RH/ 2A177 LH)
15	—	Adjusting lever return spring (part of 2A176 RH/ 2A177 LH)
16	—	Brake shoe adjusting lever (part of 2A176 RH/ 2A177 LH)
17	—	Brake shoe hold-down spring pin (part of 2296)