
NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed


NLI 113535



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed


00057

NLI 113536



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113537



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

VOLUME MIXING DIRECTIONS FOR SOFT PASTE WHITE LEAD

REPAINT WORK

NEW WORK

OUTSIDE WOOD	INT. WOOD	BRICK	STUCCO, CONCRETE AND STONE	INTERIOR PLASTER AND WALLBOARD


P 436-98

NLI 113538

NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed


00057

NLI 113539



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed


NLI 113540



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057


NLI 113541



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed


00057

NLI 113542



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed


NBI 113543



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

NLI 113544



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

NLI 113545

CHAPTER II

Exterior Wood Painting

WOOD is on most buildings the most widely used outdoor material. As such its painting for protection and decoration is an important consideration. This chapter contains the basic information needed to properly prepare and to efficiently paint exterior surfaces of wood with white lead paint.


Approximate Formulas

The formulas in this chapter have been carefully worked out to represent our best judgment as to sound painting practice for average conditions. In most localities and for most types of surfaces, they will give excellent results. However, it is recognized that even the best average formulas do not meet all conditions and one of the chief advantages of mixing paint from white lead is that adjustments can readily be made to meet special conditions. I experience is the surest guide to the adjustment but a few general facts may be helpful.

FORMULAS FOR PAINT FOR EXTERIOR WOOD SURFACES APPEAR ON PAGES 14 AND 15

NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed


NLI 113546



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed


00057

NLI 113547




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113548




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed


00057

NLI 113550




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113551




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113552



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113553



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

STAINING WOOD SHINGLES AND BOX OR BOARDS

A small amount of testing material, with care to stain the shingles or siding to the desired color, should be tried on a concealed part. Dutch Boy flatting oil (or turpentine) and two parts Dutch Boy boiled linseed oil. A mixture of three parts Dutch Boy Lead Mixing Oil and one part Dutch Boy linseed oil boiled or raw, may also be used.

Remember to obtain the desired color is a necessary rule to add the proper colors to oil. The color formulas which follow give the amounts of Dutch Boy colors to oil required for each gallon of the above liquid mixture to produce the same color.

Gray

12½ pounds Dutch Boy white lead
mixed of Dutch Boy Lampblack

Deep Red Brown

6 pounds Dutch Boy indian red

Bright Red

6 pounds Dutch Boy venetian red

Permanent Green

16 pounds Dutch Boy Ammonia oxide

Early Permanent Green

12½ pounds Dutch Boy medium chrome green

Golden Brown

½ pound Dutch Boy raw sienna
16 pounds Dutch Boy brown feather umber

Red Brown

6 pounds Dutch Boy raw feather umber

Deep Brown

6 pounds Dutch Boy brown feather umber

Note—While creosote oil sometimes is used for staining shingles and rough siding, it is not recommended to produce a good, permanent stain and will probably cause trouble at the moment is painted on the exterior. Creosote stains brownish a coat of paint usually "bleed" through and cause discoloration.

PREPARING EXTERIOR WOOD SURFACES

The same precautions must be taken in preparing to paint a house as in the preparations of any other surface. If the old paint is rough and scaly or thick and gummy, the door should be cleaned down to the wood by planing, by burning and scraping or by the use of a paint remover. If a remover is used, the surface must be brushed copiously and with a coat of strong vinegar to neutralize all remaining traces of alkali and then thoroughly washed with water. Make sure that every part of the door is clean and solid. After sandpapering and cleaning, the door is ready for painting.


PREPARING WOOD FLOORS

If the floor — as a new pine, poplar, hardwood, or other soft wood, see Formula No. 101 on page 15 for the best coat. If the floor is of hard wood — oak, maple, ash, walnut, pine or a stained wood, the same formula has proven the best coat by Dutch Boy.

In applying, use a brush well filled with paint and brush out well. Use care at each floor to flow on the paint so as that it does not dry properly, and then hurrying too much with the other strokes.


NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113555



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed


NLI 113556



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

00057


NLI 113557



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057


NLI 113558



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed


00057

NLI 113559




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 11350




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113562



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113563



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

NLI 113564

58

PROCESSES IN WOOD FINISHING

brow and shew, appearing dark in some spots and light in others. The stain should be applied while the surface is still wet. After the stain has been on the surface for five or ten minutes wipe off the surplus with a dry cloth. When the stain has thoroughly dried, apply shellac and then finish by rubbing or varnishing.

The staining material to produce the desired color of stain should be added to as much Dutch Boy thinning oil. An alternate mixture may be used as one part Dutch Boy raw linseed oil and one part gum turpentine plus ½ part Dutch Boy liquid drier.

The following approximate color formulas are based on one gallon of staining liquid.

Cherry

6½ pts. Dutch Boy burnt sienna

Mahogany

4 pts. Dutch Boy vandyke brown
½ pt. Dutch Boy raw lake

Note: Vary the proportions of the above colors to get the depth of mahogany desired.

Light Oak

1 pt. Dutch Boy raw sienna
½ pts. Dutch Boy raw umber

Fumed Oak

1 pt. Dutch Boy raw sienna
½ pt. Dutch Boy burnt umber
Standard brown sienna

PROCESSES IN WOOD FINISHING

Old Maple

½ pt. Dutch Boy raw sienna
½ pt. Dutch Boy burnt sienna
½ pt. Dutch Boy raw umber

Walnut

6½ pts. Dutch Boy vandyke brown
(or)
4 pt. Dutch Boy burnt sienna
½ pt. Dutch Boy ivory black
Note: In the color of black walnut and is desired, add more ivory black.

Cherry, Fumed Wood

A ground should first be prepared by staining the wood in the usual way. The paste should be mixed as follows, according to the wood to be stained. The quantities are based on the use of one lbs. of white lead.

Cherry

½ pint Dutch Boy venetian red
½ pint Dutch Boy umber color

Mahogany

1 pint Dutch Boy venetian red
½ pint Dutch Boy umber color

Light Oak

1 qt. Dutch Boy raw sienna
½ pt. Dutch Boy medium chrome yellow

Dark Oak

½ pint Dutch Boy umber color

Old Maple

¼ qt. Dutch Boy C. P. orange chrome yellow

58

NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

NLI 113565

CHAPTER 5


Interior Wall Painting

THERE is now no necessity on the treatment of interior walls with new beauty, cleanliness and economy. Its use involves color and type of finish. Cleanliness depends upon washability. Economy has to do with cost and years of wear. These three results are best secured by the use of paint or low lead paint.

PAINT AS AN INTERIOR WALL SURFACE APPEARS ON PAGES 56 AND 58

NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113560



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

NLI 113567

Figure 4

A—Correct method of cutting, the "V" being extended to show no paper on the surface. B—If cut as shown instead of cutting "V".

The edges of the opened crack should be washed with water to wet the paper, being pleasure not burning a hand with the old wall. Fill the crack to within a quarter inch of the surface and allow the paper plaster to set partially before brushing up to the wall surface.

All loose dust and dirt should be removed before painting. If the surface is excessively dusty or covered with grease, it should be washed. This is especially true of kitchen, bathrooms and laundry walls and ceilings.

It is always advisable to allow new plaster at least six months to dry and season thoroughly before attempting to paint it. Fresh plaster contains lime alkali, which has a tendency to keep paint from drying properly and to cause colors to bleach out.

Many people do not care to let their walls go unpainted but six months. In such cases, it is possible to neutralize the "age" of new plaster with a solution made by dissolving two pounds of zinc sulphate in one gallon of water. After this solution is applied, walls are never to allowed but the plaster to dry before painting.

Painting Over Unpainted Walls

Walls that have been previously unpainted should be washed thoroughly with a sponge and warm water before applying the primary coat. Any salt stains left on the old surface will prevent the new paint from adhering properly.

Painting Over Wallpaper

Painting over wallpaper is not a good practice because, once the paint has been applied, it is difficult, if not impossible, to remove the paper at any later date without serious damage to the plaster.


However, if circumstances require that the paper be painted, it can be done successfully provided there is but one layer on the wall and that layer is in good condition. *Before* painting, all sections of loose paper should be torn away and if there are any plaster cracks or defects underneath, they should be filled with patching plaster. Any conspicuous grease the plaster is also should be washed down with lye or sandpaper. Painting a clean dusty wall on loose plaster.

Never a silk paper contains colors which bleed (or, when any light paint is applied over them the oil in the paint dissolves the color in the paper and the color comes through and discolors the paint. If this difficulty is anticipated it would be well to use a little paint on a section of the paper. If discoloration results it would probably be unwise to continue the paper than to attempt to stop the bleeding.

If the paper is textured, it should be remembered that paint will not hide the texture.

NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed


NLI 113568



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed


00057

NLI 113569




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113570




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113571




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113572




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113573




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113574



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113575



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057


NLI 113576

CHAPTER VII

Decorative Wall Finishes


NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113577




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113/8




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113579




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113580




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113581




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113582



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed


NLI 113583



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed


00057

NLI 113584



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed


NLI 113585




CHAPTER VIII
Metal Painting

NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113586




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113588



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113589



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

NLI 113590

CHAPTER IX


Painting Small Boats

UNDER the classification, as far as painting practice is concerned, we may include everything from a canoe to a sizable yacht. The point with which the average boat owner keeps his craft bright and shipshape matters what its size or dimensions undoubtedly. Paint, of course, is the natural medium for this decorative urge just as it is for protective purposes. This chapter is devoted therefore to directions and proven formulas for meeting the various types of craft coming under the head of small boats.

It should not be assumed from the chapter heading and list as well as what I have to say that the rules are one, no nothing larger than yachts. On the contrary, the same products used for painting small boats have long been used for protecting and decorating the biggest boats and steamships. The painting of ships of this sort, however, is more or less a specialized field and it is felt that a detailed discussion would be out of place in this handbook. In general, it may be said that the same procedure and the same materials recommended in this chapter for smaller boats also apply to larger ones. Of course, the dimensions of the vessels of any kind or


NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113591




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113592



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

00057




CHAPTER X

Common Painting Defects
Their Causes and Cures


NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113594




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113595




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113596



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113597



NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

00057

NLI 113598

If cracking and curling have occurred over the entire surface it is usually advisable to remove all of the old paint by means of scrub and scraper before repainting. Otherwise, the old film will probably continue to scale, carrying the new paint with it. One regular interval should be followed for the repainting.

Blistering and Peeling
(Figure 20)

The most common cause of blistering is moisture present on the material behind the paint film. Peeling quite naturally follows blistering. In severe cases where the paint which has blistered no longer grips the surface properly and a comparatively small amount of pressure is sufficient to force it completely from the surface.

In some cases, the heat of the sun is enough to increase the vapor pressure of the moisture on the material so that it will cause blistering. In severe, or in usually the heat of a radiator or a stove which causes the trouble. The most excessive might a point to the inner spot or is an blister. Therefore a point that presents some on spot at the moisture behind it, and then gives the surface properly, is less likely to show this trouble.

The best way to avoid blistering is to make sure that the surface to be painted is thoroughly dry. In the case of paint volumes which are painted on all sides, it is necessary to be particularly careful because of the moisture in on the volumes when it is painted. Blistering is apt to occur even when pure white lead paint, which possesses unusual tenacity,

is used for the painting. Sometimes one hole such holes are drilled at the top and bottom of panel volumes to allow ventilation within the volumes and thus dry out the moisture which may be present.

In repainting a blistered surface, it is necessary to scrape off all the defective paint, allow the wood to dry out thoroughly and repaint as one new work. The primary coat on such work should be permitted to dry for a considerable time and it will be found that this is properly designed, will permit the wood to dry out further, and yet will tend to prevent the entrance of moisture from the outside. If both or inside or exterior ones are responsible for the presence of moisture, these should of course be properly repaired before anything else is done.

Spattering
(Figure 21)


Spattering is always caused by loss of gloss, flaking and rarely chalking or spots or small areas due to the eruption of oil from the finishing coat by the porous surface underneath. It is very likely to occur on new work that is only given two coats or old work painted with one coat. Spattering usually shows up more prominently with dark tints and colors. This defect will not occur when sufficient material properly formulated paint are applied.

Wrinkling
(Figure 22)

This condition occurs when a paint film contains ingredients that are soluble in a part or when soluble compounds are formed by chemical reactions after


NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113599




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113600




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113601




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113602




NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113603




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113604




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113605




NOTICE: if the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113606



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113607



NOTICE: If the film image is less clear than this notice, it is due to the quality of the document being filmed

NLI 113608

