Factors Influencing the Performance of Rotary Dryers, by C. F. Prutton and C. O. Miller (*Transactions, American Institute of Chemical Engineers*, Part 1, February, 1942; Part 2, August, 1942).

Drying of Solids by Through Circulation, by W. R. Marshall and O. A. Hougen (*Transactions, American Institute of Chemical Engineers*, 1942).

Factors that Influence Drier Performance, by A. Weisselberg (*Chemical and Metallurgical Engineering*, August, 1932).

Typical Dryer Calculations, by O. A. Hougen (*Chemical and Metallurgical Engineering*, January and March, 1940).

Symposium on Drying, Articles by W. K. Lewis, W. H. Carrier, A. E. Stacey, Jr. and R. S. Fleming, R. G. Metz, G. B. Ridley, C. O. Lavett, D. J. Van Marle (*Journal Industrial Engineering Chemistry*, May, 1921).

Principles of Drying Lumber and Humidity Diagram, by H. D. Tiemann (*Forest Service Bulletin* 104, 1912).

The Drying of Solids, by T. K. Sherwood (*Bulletin Massachusetts Institute of Technology*, Nos. 237, 247 and 258).

Air Conditioning and Engineering, American Blower Co., 1935.

Drying in Industrial Plants, by J. O. Ross.

Elements of Chemical Engineering, by Badger and McCabe (McGraw Hill Co., 1931).

Fan Engineering, Buffalo Forge Co.

Die Trockentechnik, by M. Hirsch (Julius Springer, Berlin, 1932).

Drying (*Kent's Mechanical Engineers Handbook*).

Drying, by W. H. Carrier (*Marks' Mechanical Engineers Handbook*).

Drying (*Perry's Chemical Engineers Handbook*, 1941).

Kiln Drying of Lumber, by A. Koehler and R. Thelen, New York, 1926.

Kiln Drying of Lumber, by H. D. Tiemann (Lippencott, 1920).

Modern Drying Machinery, by H. B. Grenshaw, London, 1926.

Principles of Chemical Engineering, by Walker, Lewis, McAdams (Chapters on Evaporation, Humidity and Drying, McGraw Hill Co.).

Chapter 42

NATURAL VENTILATION

Wind Forces, Stack Effect, Openings, Windows, Doors, Skylights, Roof Ventilators, Stacks, Principles of Control, General Rules, Measurements, Dairy Barn Ventilation, Garage Ventilation

VENTILATION by natural forces, finds application in industrial plants, public buildings, schools, dwellings, garages, and in farm buildings.

The natural forces available for moving air into, through and out of buildings are: (*a*) wind forces, and (*b*) the difference in temperature between the air inside and outside a building. The air movement may be caused by either of these forces acting alone or by a combination of the two, depending upon atmospheric conditions, building design and location. The ventilating results obtained will vary, from time to time, due to variation in the velocity and direction of the wind and the heat generated in the building. The arrangement, location, and control of the ventilating openings should be such that the two forces act cooperatively rather than in opposition.

WIND FORCES

In considering the use of natural wind forces for producing ventilation, account must be taken of: (1) average wind velocity, (2) prevailing wind direction, (3) seasonal and daily variations in velocity and direction, and (4) local wind interference by nearby buildings, hills or other obstructions of similar nature.

Values are given in Table 1, Chapter 7 for the average summer wind velocities and the prevailing wind directions in various localities throughout the United States, while Table 2, Chapter 6, lists similar values for the winter. In almost all localities the summer wind velocities are lower than those in the winter, and in about two-thirds of the localities the prevailing direction is different during the summer and winter. While the tables give no average velocities below 5 mph, there will be times when the velocity is lower, even in localities where the seasonal average is considerably above 5 mph. There are relatively few places where the velocity falls below one half of the average for many hours per month. Consequently, if the natural ventilating system is designed for wind velocities of one-half of the average seasonal velocity, it should prove satisfactory in almost every case.