| MANUFACTURING SPECIFICATION | Colorbestos Sidewall Shingles | SPEC NO. | 423-2.23 |
|---|---|---|---|
| | | PAGE NO. | 1 of 1 |

Dover White - Cedargrain Texture, All Styles

CANCELLED

**Formulas:** "D" Type

| | Formula No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| | 6D20 Fibre * | 300 | 300 | 300 | 300 | 300 | 300 | 300 |
| X PS 1061 | Type I Std. Portland Cement | 470 | 470 | 470 | 470 | 470 | 470 | 470 |
| PS 1281 | J-M Spec. Silica Flour | 300 | 300 | 300 | 300 | 300 | 300 | 300 |
| | Shingle Scrap (Note 1) | 500 | 475 | 450 | 425 | 400 | 375 | 350 |
| | Minimum Batch Weight | 1570 | 1545 | 1520 | 1495 | 1470 | 1445 | 1420 |
| | Other Scraps (Note 2) | 100 | 125 | 150 | 175 | 200 | 225 | 250 |

Note 1: (a) Shingle Scrap should be blended 1 part normal cured to two parts of steam cured.

From 0 to 100# of the Shingle Scrap may be replaced by any of the following approved Mineral Fillers: Mastic Filler, Limestone Dust, Limestone Aggregate, Ground Trap Rock, Greystone and Trancite Pipe Scrap and Rock Wool Shot.

(b) Rock Wool Shot must be introduced at the Shingle Scrap grinders and must be evenly distributed throughout the scrap.

Note 2: (a) Wet Machine Scrap, Corrugated Transite Scrap or Transite Pipe Scrap may be added to the formulas above up to the amounts shown.

(b) Up to 75# of material from the Dust Collectors and/or 75# of Machine Drop from the same or other machines producing similar stock may be added to the above formulas.

Caution: The use of scrap should be planned so that it will not be necessary to shift more than two successive formulas at any time. Violent shifts should not be made.

XX

PLAINTIFF'S EXHIBIT JM-2425

RETURN TO J-M RES... FILE !

Pld. In U.S.A.

Form 333-2

X — INDICATES CHANGE — REASON: X - Show correct nomenclature & add P.S. numbers
XX- Remove reference to GRAY-2403

AUTHORITY FOR CHANGE: X - Current Purch. Specs.
XX- L. L. Liggett's ltr. 10-9-57

SUPERSEDES: Page 1 of 423-2.[illegible] dtd. 6-30-56

MT-000207

| DIR. Q.C. | MGR. Q.C. | SUPR. Q.C. | PROD. SUPT. | PLNT. ENG. | RES. & DEV. | Ind. Eng. | Insp. Supv. | Lab. | Foreman | DATE ISSUED | NOV 5 1959 |
|---|---|---|---|---|---|---|---|---|---|---|---|

| MANUFACTURING SPECIFICATION | Colorbestos Sidewall Shingles Dover White, Cedargrain - All Styles | SPEC NO. | 423-2.24 |
|---|---|---|---|
| | | PAGE NO. | 1 of 1 |

**Formulas:** "B" Type

CANCELLED

| | Formula No. | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|
| | 6D20 Fibre | 300 | 300 | 300 | 300 |
| P.S. 1061 | Type I Std. Portland Cement | 501 | 501 | 501 | 501 |
| P.S. 1281 | J-M Spec. Silica Flour | 333 | 333 | 333 | 333 |
| | Shingle Scrap (Note 1, 2) | 450 | 425 | 400 | 375 |
| | Minimum Batch Weight | 1584 | 1559 | 1534 | 1509 |
| | Other Scrap (Note 3) | 100 | 125 | 150 | 175 |

X

Note 1: (a) Shingle Scrap should be blended 1 part normal cured to 2 parts steam cured.

From 0 to 100 lbs. of the Shingle Scrap may be replaced by any of the following approved Mineral Fillers: Mastic Filler, Limestone Dust, Limestone Aggregate, Ground Trap Rock, Graystone and Transite Pipe Scrap and Rock Wool Shot.

(b) Rock Wool Shot must be introduced at the Shingle Scrap grinders and must be evenly distributed throughout the scrap.

Note 2: At Waukegan Plant, when Fiberizer is in operation, an additional 100# of Shingle Scrap may be added to the formulas above.

Note 3: (a) Wet Machine Scrap, Corrugated Transite or Transite Pipe Scrap may be added to the formulas above up to amounts shown.

(b) Up to 75# of material from the Dust Collectors and/or 75# of Machine Drop from the same or other machines producing similar stock may be added to the above formulas.

Caution: The use of scrap should be planned so that it will not be necessary to shift more than two successive formulas.

XX

RETURN TO J-M RE... FILE ...

| X— INDICATES CHANGE | —REASON: | X - Show correct nomenclature & add P.S. numbers<br>XX - Remove reference to 6DAX-2498 Fibre. |
|---|---|---|
| AUTHORITY FOR CHANGE | | X - Current Purch. Specs.<br>XX - L. L. Liggett's letter of 10-9-57 |

SUPERSEDES: Page 1 of 423-2.14 dated 6-30-58

MT-000175

| DIR. Q.C. | MGR. Q.C. | SUPR. Q.C. | PROD. SUPT. | PLNT. ENG. | RES. & DEV. | Ind. Eng. | Insp. Supv. | Lab Foreman | DATE ISSUED |
|---|---|---|---|---|---|---|---|---|---|
| | | | | | | | | | NOV 5 1959 |

Form 333-2 Ptd. in U.S.A.

| MANUFACTURING SPECIFICATION | Colonial Sidewall Shingles Cedar White, Cedargrain - Mill Styles | SPEC NO. | 423-2.2A |
|---|---|---|---|
| | | PAGE NO. | 1 of 1. |

**Formulas:** "B" Type

CANCELLED

| | Formula No. | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|
| | 6D20 Fibre | 300 | 300 | 300 | 300 |
| X P.S. 1061 | Type I Std. Portland Cement | 452 | 452 | 452 | 452 |
| | J-M Bulk Silica Flour | 382 | 382 | 382 | 382 |
| | Shingle Scrap (Note 1, 2) | 450 | 425 | 400 | 375 |
| | Minimum Batch Weight | 1584 | 1559 | 1534 | 1509 |
| | Other Scrap (Note 3) | 100 | 125 | 150 | 175 |

**Note 1:** (a) Shingle Scrap should be blended 1 part normal cured to 2 parts steam cured.

From 0 to 100 lbs. of the Shingle Scrap may be replaced by any of the following approved Mineral Fillers: Mastic Filler, Limestone Dust, Limestone Aggregate, Ground Trap Rock, Graystone and Transite Pipe Scrap and Rock Wool Shot.

(b) Rock Wool Shot must be introduced at the Shingle Scrap grinders and must be evenly distributed throughout the scrap.

**Note 2:** At Waukegan Plant, when Fiberizer is in operation, an additional 100# of Shingle Scrap may be added to the formulas above.

**Note 3:** (a) Wet Machine Scrap, Corrugated Transite or Transite Pipe Scrap may be added to the formulas above up to amounts shown.

(b) Up to 75# of material from the Dust Collectors and/or 75# of Machine Drop from the same or other machines producing similar stock may be added to the above formulas.

**Caution:** The use of scrap should be planned so that it will not be necessary to shift more than two successive formulas.

RETURN TO J-M RESEARCH FILE ROOM

MT-000174

Pat. In U.S.A.

Form 333-2

X— INDICATES CHANGE —REASON: X-Show Silica to Cement ratio 0.85
1X-Show use of bulk Silica Flour

AUTHORITY FOR CHANGE: X-PP-Res-423-86; Prod. Info. Chg. 041-34-60 enacted 10-24-60
1X-Correction

SUPERSEDES: Page 1 of same spec. issued 11-5-59

| DIR. Q.C. | MGR. Q.C. | SUPR. Q.C. | PROD. SUPT. | PLNT. MGR. | Tech. Lab. | Prod. Chg. | Insp. Supv. | Lab Foreman | DATE ISSUED |
|---|---|---|---|---|---|---|---|---|---|
| | | | | | | | | | 10-26-60 |

| MANUFACTURING SPECIFICATION | Johnsonburg Chemical Shingles | SPEC NO. | 423-2.23 |
|---|---|---|---|
| | | PAGE NO. | 1 of 1 |

Dover White - Serragrain Texture, All Styles CANCELLED

**Formulas:** **"D" Type**

| | Formula No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| | 6D20 Fibre * | 300 | 300 | 300 | 300 | 300 | 300 | 300 |
| X PS 1061 | Type I Std. Portland Cement | 415 | 415 | 415 | 415 | 415 | 415 | 415 |
| X | J-M Bulk Silica Flour | 355 | 355 | 355 | 355 | 355 | 355 | 355 |
| | Shingle Scrap (Note 1) | 500 | 475 | 450 | 425 | 400 | 375 | 350 |
| | Minimum Batch Weight | 1570 | 1545 | 1520 | 1495 | 1470 | 1445 | 1420 |
| | Other Scraps (Note 2) | 100 | 125 | 150 | 175 | 200 | 225 | 250 |

Note 1: (a) Shingle Scrap should be blended 1 part normal cured to two parts of steam cured.

From 0 to 100% of the Shingle Scrap may be replaced by any of the following approved Mineral Fillers: Mastic Filler, Limestone Dust, Limestone Aggregate, Ground Trap Rock, Greystone and Ironsite Pipe Scrap and Rock Wool Shot.

(b) Rock Wool Shot must be introduced at the Shingle Scrap grinders and must be evenly distributed throughout the scrap.

Note 2: (a) Wet Machine Scrap, Corrugated Ironsite Scrap or Ironsite Pipe Scrap may be added to the Formulas above up to the amounts shown.

(b) Up to 75% of material from the Dust Collectors and/or 75% of Machine Drop from the Nash or other machines producing similar stock may be added to the above formulas.

Caution: The use of scrap should be planned so that it will not be necessary to shift more than two necessaire formulas at any time. Violent shifts should not be made.

RETURN TO J-M RESEARCH FILE ROOM

X— INDICATES CHANGE — REASON: X-Show Silica to Cement ratio 0.85
1X-Show bulk Silica Flour

AUTHORITY FOR CHANGE: X-PP-Res 423-86; Prod. Lit. Chg. 041-34-60 enacted 10-24-60
1X-Correction

SUPERSEDES: Page 1 of same spec. issued 11-5-59

MT-000206

10-26-60

Form 333-S
Printed in U.S.A.

| Johns Manville MANUFACTURING SPECIFICATION | Dover White Sidewall Shingles New Colorbestos Process | Manville EP | |
|---|---|---|---|
| | | SPEC NO. | RS-F-5 |
| | | PAGE NO. | 1 |

**PRODUCTS:**

Dover White - Cedargrain, #105 and #109 Styles

**BASE FORMULAS:**

CANCELLED

"D" Type

| | Formula No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| | 6D20 Fibre | 300# | 300# | 300# | 300# | 300# | 300# | 300# |
| X | Portland Cement | 415 | 415 | 415 | 415 | 415 | 415 | 415 |
| X | Silica Flour (Note A) | 355 | 355 | 355 | 355 | 355 | 355 | 355 |
| | Shingle Scrap (Note 1) | 500 | 475 | 450 | 425 | 400 | 375 | 350 |
| | Minimum Batch Weight | 1570# | 1545# | 1520# | 1495# | 1470# | 1445# | 1420# |
| | Other Scraps (Note 2) | 100 | 125 | 150 | 175 | 200 | 225 | 250 |

Note A: Use "I" Bldg. Silica Flour when available.

Note 1: From 0 to 100 lb. of the Shingle Scrap may be replaced within the scope of basic formulas by any one of the following approved Mineral Fillers: Mastic Sand, Limestone Dust, Limestone Aggregate, Ground Trap Rock or Mill Fines, Graystone, Reclaimed Granules, Rock Wool Shot or Transite Pipe Scrap ground to small size.

Note 2: (a) Wet Machine Scrap, Corrugated Transite Scrap, or Transite Pipe Scrap (large size) may be added to the formulas above up to the amounts shown.

(b) Up to 75 lb. of material from the Dust Collectors and/or 75 lb. of Machine Drop from the same or other machines producing similar stock may be added to the above formulas.

Caution: The use of scrap should be planned so that it will not be necessary to shift more than two successive formulas at any time. Violent shifts should not be made.

Note 3: 6D20 Fibre is considered to be standard. 6D28 Fibres may be substituted for 6D20 Fibre in whole or in part on a pound for pound basis. Munro 6 Grade Fibre may also be substituted in proportions up to 1/3 of the total fibre content of the base mix.

MT-000185

| | | |
|---|---|---|
| X— INDICATES CHANGE —REASON: | Increase Silica-Cement Ratio to .85 | RETURN TO |
| AUTHORITY FOR CHANGE | Product Proposal Research 423-86 | J-M RESEARCH |
| SUPERSEDES: | Page 1 of same Spec. Issued 2/19/59 | FILE ROOM |

| DIR. Q.C. | MGR. Q.C. | SUPR. Q.C. | PROD. SUPT. | PLNT. FIN. | RES. LAB. | Ind. Eng. | | | DATE ISSUED 10/27/60 |
|---|---|---|---|---|---|---|---|---|---|

Form 333-2 Pd. in U.S.A.

| MANUFACTURING SPECIFICATION | Colonnade Fibrewall Shingles | SPEC NO. | 423-2.25 |
|---|---|---|---|
| | | PAGE NO. | 1 of 1 |

Dover White - Cedargrain Texture, All Styles

by 423-2.21 pv

**Formulas:** "W" Type

| Formula No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|
| 6D20 Fibre | 300 | 300 | 300 | 300 | 300 | 300 | 300 |
| X Type II Std. Portland Cement | 415 | 415 | 415 | 415 | 415 | 415 | 415 |
| J-M Bulk Silica Flour | 355 | 355 | 355 | 355 | 355 | 355 | 355 |
| Shingle Scrap (Note 1) | 500 | 475 | 450 | 425 | 400 | 375 | 350 |
| Minimum Batch Weight | 1570 | 1545 | 1520 | 1495 | 1470 | 1445 | 1420 |
| Other Scraps (Note 2) | 100 | 125 | 150 | 175 | 200 | 225 | 250 |

Note 1: (a) Shingle Scrap should be blended 1 part normal cured to two parts of steam cured.

From 0 to 100% of the Shingle Scrap may be replaced by any of the following approved Mineral Fillers: Mastic Filler, Limestone Dust, Limestone Aggregate, Ground Trap Rock, Greystone and Granite Pips Scrap and Rock Wool Shot.

(b) Rock Wool Shot must be introduced at the Shingle Scrap grinders and must be evenly distributed throughout the scrap.

Note 2: (a) Wet Machine Scrap, Corrugated Granite Scrap or Granite Pips Scrap may be added to the formulas shown up to the amounts shown.

(b) Up to 75% of material from the Dust Collectors and/or 75% of Machine Drop from the saws or other machines producing similar scrap may be added to the above formulas.

Caution: The use of scrap should be planned so that it will not be necessary to shift more than two successive formulas at any time. Violent shifts should not be made.

MT-000205

| X — INDICATES CHANGE | REASON: Show Type IX Cement |
|---|---|
| AUTHORITY FOR CHANGE | Liggett's letter 11-10-60; Enact. Bulletin 11-15-60 |
| SUPERSEDES: | Page 1 of Same Spec. issued 10-26-60 |

RETURN TO J-M RESEARCH FILE ROOM

| O.K. | INIT. | CONT. | LOG. | ENG. | DATE: 11-17-60 |
|---|---|---|---|---|---|

Form 233-2 Rd. in U.S.A.

| MANUFACTURING SPECIFICATION | Colorbestos Sidewall Shingles Dover White, Cedargrain - All Styles | SPEC NO. | 423-2.24 |
|---|---|---|---|
| | | PAGE NO. | 1 of 1 |

**Formulas:** "B" Type

423-2.21 P

| | Formula No. | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|
| | 6D20 Fibre | 300 | 300 | 300 | 300 |
| X | Type II Std. Portland Cement | 452 | 452 | 452 | 452 |
| | J-M Bulk: Silica Flour | 382 | 382 | 382 | 382 |
| | Shingle Scrap (Note 1, 2) | 450 | 425 | 400 | 375 |
| | Minimum Batch Weight | 1584 | 1559 | 1534 | 1509 |
| | Other Scrap (Note 3) | 100 | 125 | 150 | 175 |

**Note 1:** (a) Shingle Scrap should be blended 1 part normal cured to 2 parts steam cured.

From 0 to 100 lbs. of the Shingle Scrap may be replaced by any of the following approved Mineral Fillers: Mastic Filler, Limestone Dust, Limestone Aggregate, Ground Trap Rock, Graystone and Transite Pipe Scrap and Rock Wool Shot.

(b) Rock Wool Shot must be introduced at the Shingle Scrap grinders and must be evenly distributed throughout the scrap.

**Note 2:** At Waukegan Plant, when Fiberizer is in operation, an additional 100# of Shingle Scrap may be added to the formulas above.

**Note 3:** (a) Wet Machine Scrap, Corrugated Transite or Transite Pipe Scrap may be added to the formulas above up to amounts shown.

(b) Up to 75# of material from the Dust Collectors and/or 75# of Machine Drop from the same or other machines producing similar stock may be added to the above formulas.

**Caution:** The use of scrap should be planned so that it will not be necessary to shift more than two successive formulas.

MT-000173

X— INDICATES CHANGE —REASON Show Type II Cement

AUTHORITY FOR CHANGE Liggett's letter 11-10-60; Enact. Bulletin 11-15-60

SUPERSEDES: Page 1 of same spec. issued 10-26-60

RETURN TO J-M RESEARCH FILE ROOM

| DIR. Q.C. | MGR. Q.C. | SUPR. Q.C. | PROD. SUPT. | PLNT. FIN. | RES. Lab. | Prod. Eng. | Insp. Supv. | Lab. Foreman | DATE ISSUED |
|---|---|---|---|---|---|---|---|---|---|
| | | | | | | | | | 11-17-60 |

Form 3332 Ptd. In U.S.A.

| Johns-Manville MANUFACTURING SPECIFICATION | PRODUCT: Colorbestos Sidewall Shingles Dover White | PLANT & DIV. | Asbestos B.P. |
|---|---|---|---|
| | | SPEC NO. | ~~RS-S-1~~ 423:1 ✓ |
| | | PAGE NO. | 1 on 3 |

Dover White Sidewall Shingles - #109 (Straight butt) only.

I. FORMULA:

1. Base Mix - See Spec. RS - 2
2. Silicone Water Repellant Solution - See Spec. RS - 6

II. INSTRUCTIONS FOR GRAIN ROLL MACHINE OPERATIONS:

1. Apply warm water (130-160° F) to the machine belt, together with a light coating of sand to prevent sticking of stock to the belt.
2. Drop mixed stock on to the moving belt, adjusting the picker roll so that the weight of 15 slabs at the take-off will weigh 56 lbs. (± 2 lbs).
3. Pass stock under magnet, then through series of perforated rolls and the smooth forming roll (gauge at 20 psi).
4. Apply sufficient warm water from water boxes to properly wet the stock.
5. Pass the wetted stock through smooth press rolls immediately before slitting and cutting the stock to slabs.

FORMULA: DOVER WHITE VENEER:

| P. S. No. | Ingredients | Batch | % |
|---|---|---|---|
| - | 7F04 Asbestos Fiber | 140# | 6.8 |
| CA 1001 | White Portland Cement | 525 | 25.4 |
| 63386 | #10 Dry Ground Whiting | 770 | 37.3 |
| CA 1281 | J.M. Special Silica Flour | 420 | 20.3 |
| CA 3126 | Titanox "A" - 168 | 70 | 3.4 |
| CA 1272 | 80 Mesh Sand | 140 | 6.8 |
| | | 2065 lbs. | 100.0% |

RETURN TO J-M RESEARCH FILE ROOM

Veneer Mixing Instructions:

Add materials in the order shown to the top mixer of the veneer mixing system and mix for 15 - 20 minutes.
Drop the batch into bottom mixer and feed continuously through the Rietz Disintegrator, from which point the mixed veneer is screw-conveyed to the feed elevator above the Selectro Screen.

6. Apply the veneer (as above) to slabs, adjusting the rate of feed through the Selectro Screen so that a uniform coverage of between 22.5 to 24.3 lb per 100 sq. ft. of base sheet area will result.
For control purposes this will be between 7-1/4 to 7-3/4 ozs per 2 sq. ft.

MT-000188

Pd. in U.S.A.

Form 333-2

| X— INDICATES CHANGE | —REASON: All Smoothgrain Type Shingles and #105 Type obsoleted. |
|---|---|
| AUTHORITY FOR CHANGE | Tel. - G.A.H. to H.C.L. of 11/7/60. |
| SUPERSEDES: | Page 1 (3/13/57) & Page 2 (6/17/59) of Spec. RS-S-1 (Cedargrain Design) |

| DIR. Q.C. | MGR. Q.C. | SUPR. Q.C. | PROD. SUPT. | PLNT. FIN. | RES. LAB. ✓ | I.E. | Dept | G.P.L. | DATE ISSUED | January 20, 1961 |
|---|---|---|---|---|---|---|---|---|---|---|

| Johns-Manville MANUFACTURING SPECIFICATION | Dover White Sidewall Shingles New Colorbestos Process | PLANT & DIV. | Manville BP |
|---|---|---|---|
| | | SPEC NO. | RS-P-5 |
| | | PAGE NO. | 1 |

**PRODUCTS:** Dover White - Cedargrain, #105 and #109 Styles

**BASE FORMULAS:** "D" Type

| Formula No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---|---|---|---|---|---|---|---|---|
| X 7R06 Fibre | -- | -- | -- | -- | -- | -- | -- | 300# |
| 6D20 Fibre | 300# | 300# | 300# | 300# | 300# | 300# | 300# | 200 |
| Portland Cement | 415 | 415 | 415 | 415 | 415 | 415 | 415 | 464 |
| Silica Flour-(Note A) | 355 | 355 | 355 | 355 | 355 | 355 | 355 | 396 |
| Shingle Scrap-(Note 1) | 500 | 475 | 450 | 425 | 400 | 375 | 350 | 640 |
| Minimum Batch Wt. | 1570# | 1545# | 1520# | 1495# | 1470# | 1445# | 1420# | 2000# |
| Other Scrap (Note 2) | 100 | 125 | 150 | 175 | 200 | 225 | 250 | |

Note A: Use "I" Bldg. Silica Flour when available

Note 1: From 0 to 100 lb. of the Shingle Scrap may be replaced within the scope of basic formulas by any one of the following approved Mineral Fillers: Mastic Sand, Limestone Dust, Limestone Aggregate, Ground Trap Rock or Mill Fines, Graystone, Reclaimed Granules, Rock Wool Shot or Transite Pipe Scrap ground to small size.

Note 2: (a) Wet Machine Scrap, Corrugated Transite Scrap, or Transite Pipe Scrap (large size) may be added to the formulas above up to the amounts shown.

(b) Up to 75 lb. of material from the Dust Collectors and/or 75 lb. of Machine Drop from the same or other machines producing similar stock may be added to the above formulas.

Caution: The use of scrap should be planned so that it will not be necessary to shift more than two successive formulas at any time. Violent shifts should not be made.

Note 3: 6D20 Fibre is considered to be standard. 6D28 Fibres may be substituted for 6D20 Fibre in whole or in part on a pound for pound basis. Munro 6 Grade Fibre may also be substituted in proportions up to 1/3 of the total fibre content of the base mix.

MT-000184

RETURN TO J-M RESEARCH FILE ROOM #139

X— INDICATES CHANGE —REASON: Show formula with 7R06 Fibre Substitution

AUTHORITY FOR CHANGE: L. L. Liggett's letter to W. F. Fischer 5/16/61 also Bulletin

SUPERSEDES: Page 1 of same Spec. issued 10/27/60

| DIR. Q.C. | MGR. Q.C. | SUPR. Q.C. | PROD. SUPT. | PLNT. FIN. | RES. LAB. | Ind. Eng. | | | DATE ISSUED 6/9/61 |
|---|---|---|---|---|---|---|---|---|---|

Form 333-2 Ptd. in U.S.A.

| Johns-Manville MANUFACTURING SPECIFICATION | PRODUCT: Colorbestos Sidewall Shingles Dover White | PLANT & DIV. | Asbestos B.P. |
|---|---|---|---|
| | | SPEC NO. | 423.1 (3) |
| | | PAGE NO. | 1 on 3 |

Dover White Sidewall Shingles - #109 (Straight butt) - Standard.
#105 (Wavy Butt) - When specially ordered.

I. FORMULA:

1. Base Mix - See Spec. 423 (RS-2)
2. Silicone Water Repellent Solution - See Spec. 423.0 (RS-6)

II. GENERAL INSTRUCTIONS FOR MACHINE OPERATION:

1. Apply warm water (130-160° F) to the machine belt, together with a light coating of sand to prevent sticking of stock to the belt.
2. Drop mixed stock on to the moving belt, adjusting the picker roll so that the weight of 15 slabs at the take-off will weigh 56 lbs. (± 2 lbs).
3. Pass stock under magnet, then through series of perforated rolls and the smooth forming roll (Gauge pressure of the smooth roll at 2 - 5 psi).
4. Apply sufficient warm water from the water boxes to properly wet th stock.
5. Pass the dampened stock through the smooth press roll immediately before slitting and cutting the stock to slabs.

FORMULA: DOVER WHITE VENEER:

| P. S. No. | Ingredients | Batch | % |
|---|---|---|---|
| - | 7F04 Asbestos Fiber | 140 lbs. | 6.8 |
| CA 1001 | White Portland Cement | 525 | 25.4 |
| 63386 | #10 Dry Ground Whiting | 770 | 37.3 |
| CA 1281 | JM. Special Silica Flour | 420 | 20.3 |
| CA 3126 | Titanox "A" - 168 | 70 | 3.4 |
| CA 1272 | 80 mesh sand | 140 | 6.8 |
| | | 2065 lbs. | 100.0% |

RETURN TO J-M RESEARCH FILE ROOM

X NOTE: The above veneer is used on Permatone "Shasta White" and "Sunglo", and on Rock Shake "SnoWhite" and "Jonquil", with the exception that 7F05 fiber is substituted for the 7F04.

Veneer Mixing Instructions:

Add materials in the order shown to the top mixer of the veneer mixing system and mix for 15 - 20 minutes. Drop the batch into the bottom mixer and feed continuously through the Rietz disintegrator, from which point the mixed veneer is screw-conveyed to the feed elevator above the Selectro Screen.

7. Adjust the rate of feed through the Selectro screen so that a uniform coverage of between 22.5 to 24.3 per 100 sq. ft. of base sheet will result. For control purposes this will be between 7-1/4 to 7-3/4 ozs. per 2 sq. ft.

MT-000187

Pld. in U.S.A.

| X— INDICATES CHANGE | —REASON: X. To show veneer used on Permatone & Rock Shake light colours. |
|---|---|
| AUTHORITY FOR CHANGE | X. Plant Management (On Rigid Shingle Developments) |
| SUPERSEDES: | Page #1 dated 1/20/[illegible], and Deviation Notice #542 dated January 14, 1963 |

| DIR. Q.C. | MGR. Q.C. | SUPR. Q.C. | PROD. SUPT. | PLNT. FIN. | [illegible] Dept. | I.E. | G.P.L. | DATE ISSUED | January 24, 1963 |
|---|---|---|---|---|---|---|---|---|---|

Form 333-2

| COPY FORM | INITIALS | DATE |
|---|---|---|
| | | 12/3/2000 |

| BOX NUMBER | SEGMENT NO. | REQUESTING PARTY |
|---|---|---|
| P-458 | | Baron & Budd |

NOTES