The charts below show camber degrees (+) or (−) with the approximate toe effect for each degree of camber listed in relationship with the outside tire diameter.

To order, the corresponding part number or combination of part numbers are listed on the left.

RED SHIM

APPLICATION:

CHRYSLER
- LeBaron
- New Yorker (from 1983)

DODGE
- Aries 400
- Omni 600
- Rampage Truck

PLYMOUTH
- Horizon
- Reliant
- Scamp Truck

VOLKSWAGEN
- Dasher
- Jetta
- Pickup Truck
- Rabbit
- Scirocco

		OUTSIDE TIRE DIAMETER					
		22"	23"	24"	25"	26"	27"
PART NO.	CAMBER DEGREE	TOE CHANGE					
264-2701	1/4°	3/32"	3/32"	3/32"	1/8"	1/8"	1/8"
264-2702	1/2°	3/16"	3/16"	7/32"	7/32"	7/32"	7/32"
264-2703	3/4°	9/32"	9/32"	5/16"	5/16"	11/32"	11/32"
264-2704	1°	3/8"	3/8"	7/16"	7/16"	7/16"	15/32"
264-2701 264-2704	1-1/4°	15/32"	1/2"	17/32"	17/32"	9/16"	9/16"
264-2702 264-2704	1-1/2°	9/16"	9/16"	5/8"	21/32"	11/16"	23/32"
264-2703 264-2704	1-3/4°	11/16"	11/16"	23/32"	3/4"	25/32"	13/16"
264-2708	2°	25/32"	25/32"	13/16"	7/8"	29/32"	15/16"
264-2702 264-2708	2-1/2°	31/32"	1"	1-1/32"	1-3/32"	1-1/8"	1-3/16"
264-2704 264-2708	3°	1-5/32"	1-7/32"	1-1/4"	1-5/16"	1-3/8"	1-13/32"
Use (2) of 264-2708	4°	1-17/32"	1-5/8"	1-11/16"	1-3/4"	1-13/16"	1-7/8"

BLUE SHIM

APPLICATION:

BUICK
- Skyhawk
- Skylark

CADILLAC
- Cimarron

CHEVROLET
- Cavalier
- Citation

OLDSMOBILE
- Firenza
- Omega

PONTIAC
- J2000
- Phoenix

PART NO.	CAMBER DEGREE	TOE CHANGE					
264-2713	1/4°	3/32"	3/32"	3/32"	1/8"	1/8"	1/8"
264-2714	1/2°	3/16"	3/16"	7/32"	7/32"	7/32"	7/32"
264-2715	3/4°	9/32"	9/32"	5/16"	5/16"	11/32"	11/32"
264-2716	1°	3/8"	3/8"	7/16"	7/16"	7/16"	15/32"
264-2713 264-2716	1-1/4°	15/32"	1/2"	17/32"	17/32"	9/16"	9/16"
264-2714 264-2716	1-1/2°	9/16"	9/16"	5/8"	21/32"	11/16"	23/32"
264-2715 264-2716	1-3/4°	11/16"	11/16"	23/32"	3/4"	25/32"	13/16"
264-2720	2°	25/32"	25/32"	13/16"	7/8"	29/32"	15/16"
264-2714 264-2720	2-1/2°	31/32"	1"	1-1/32"	1-3/32"	1-1/8"	1-3/16"
264-2716 264-2720	3°	1-5/32"	1-7/32"	1-1/4"	1-5/16"	1-3/8"	1-13/32"
Use (2) of 264-2720	4°	1-17/32"	1-5/8"	1-11/16"	1-3/4"	1-13/16"	1-7/8"

YELLOW SHIM

APPLICATION

BUICK
- Century 1982 & up
- Riviera 1979 & up

CADILLAC
- Eldorado 1979 & up
- Seville 1980 & up

CHEVROLET
- Celebrity

OLDSMOBILE
- Cutlass Ciera
- Toronado 1979 & up

PONTIAC
- 6000

PART NO.	CAMBER DEGREE	TOE CHANGE					
264-2725	1/4°	3/32"	3/32"	3/32"	1/8"	1/8"	1/8"
264-2726	1/2°	3/16"	3/16"	7/32"	7/32"	7/32"	7/32"
264-2727	3/4°	9/32"	9/32"	5/16"	5/16"	11/32"	11/32"
264-2728	1°	3/8"	3/8"	7/16"	7/16"	7/16"	15/32"
264-2725 264-2728	1-1/4°	15/32"	1/2"	17/32"	17/32"	9/16"	9/16"
264-2726 264-2728	1-1/2°	9/16"	9/16"	5/8"	21/32"	11/16"	23/32"
264-2727 264-2728	1-3/4°	11/16"	11/16"	23/32"	3/4"	25/32"	13/16"
264-2732	2°	25/32"	25/32"	13/16"	7/8"	29/32"	15/16"
264-2726 264-2732	2-1/2°	31/32"	1"	1-1/32"	1-3/32"	1-1/8"	1-3/16"
264-2728 264-2732	3°	1-5/32"	1-7/32"	1-1/4"	1-5/16"	1-3/8"	1-13/32"
Use (2) of 264-2732	4°	1-17/32"	1-5/8"	1-11/16"	1-3/4"	1-13/16"	1-7/8"