SHOCK ABSORBER, COIL OVERLOAD HELPERS, LEAF HELPER SPRINGS

APPLICATION CHART

Make	Rear Shock Absorber Springs 3-4470	Models	Front Shock Absorber Springs 3-4471	Models	Coil Over-Load Helpers 3-4472/ 3-4473	Models	Leaf Helper Springs 3-4465/ 3-4466	Models
BUICK	56-69	All	54-56 66-69	All Ex. Riviera	61-65	All	—	—
CADILLAC	50-65	All	50-69	All	40-60	All	40-57	All
CAMARO	67-69	All	67-69	All	67-69	All	67-69	All
CHEVELLE	64-69	All	64-69	All	—	—	—	—
CHEVROLET	49-69	All	49-69	All	40-69	All	40-57	All
CHEVY II	62-69	All	62-69	All	64-68	All	62-69	All
CHEVROLET TRUCK	*	*	55-67-69	½, ¾ Ton	55-67-69	½, ¾ Ton	—	—
CHRYSLER	38-69	All	55-56, 62-65	All	40-69	All	40-69	All
COMET	60-69	All	60-69	All	60-61, 66-69	All	60-69	All
CORVAIR	66-68	All	60-68	All	—	—	—	—
CORVETTE	60-63	All	53-69	All	—	—	—	—
DESOTO	38-61	All	55-56	All	38-61	All	40-61	All
DODGE	39-69	All	55-56, 62-69	Ex. '66-69 Monaco & Polara	39-69	All	40-69	All
DODGE LANCER	61-62	All	61-63	All	1961	All	61-65	All
DODGE TRUCK	*	*	55-69	½, ¾ Ton	55-69	½, ¾ Ton	—	—
EDSEL	58-60	All	58-60	All	58-60	All	58-60	All
FALCON	60-69	All	60-69	All	60-61, 66-69	All	60-69	All
FORD	47-69	(Ex. Mustang)	49-69	All	40-64, 66-69	(Ex. Mustang)	47-65	(Ex.'65-'66 Galaxie)
FORD BRONCO	66-69	All	66-69	All	66-69	All	66-69	All
FORD FAIRLANE	62-69	All	62-69	All	62-69	All	62-69	All
FORD TRUCK	*	*	55-69	½, ¾ Ton	55-69	½, ¾ Ton	—	—
FORD TORINO	68-69	All	68-69	All	68-69	All	68-69	All
HUDSON & FRAZER	40-54	All	—	—	40-54	All	—	—
INC SCOUT	*	*	62-69	All	62-69	All	—	—
IMPERIAL	55-69	All	55-56, 62-65	All	40-69	All	57-69	All
JEEP 4 W.D. Front & Rear	55-69	All	(All Models)	All	—	—	—	—
KAISER & HENRY J	47-54	All	—	—	47-54	All	—	—
KAISER FRAZER	—	—	47-55	All	—	—	—	—
LINCOLN	49-51/57-59	All	49-54	All	40-60	All	49-57 & 63-69	All
MERCURY	49-69	(Ex. '56 & Parklane)	49-69	All	40-64 & 67-69	All	49-64 & 67-69 Montego 67 Sta. Wgn.	All
MERCURY COUGAR & XR7	67-69	All	67-69	All	67-68	All	67-69	All
METROPOLITAN	54-62	All	—	—	54-61	All	—	—
MUSTANG	65-69	All	65-69	All	65-69	All	65-69	All
OLDSMOBILE	51-56/60-69	(Ex. '51 Std. 88)	57-69	All	51-63	All	51-60	All
OLDSMOBILE F-85	61-69	All	61-69	All	61-63	All	—	—
OLDSMOBILE TORONADO	66-69	All	66-69	All	—	—	—	—
PACKARD	40-56	(Ex. 55-56 Series 60-80-88)	51-58	All	40-56	All	49-56	All
PLYMOUTH	39-69	All	55-56 & 62-69	(Ex. '66-'69 VIP & Fury)	40-69	All	40-69	All
PLYMOUTH BARRACUDA	65-69	All	65-69	All	65-69	All	65-69	All
PONTIAC	37-69	All	49-69	All	40-61	(Ex. Tempest)	40-57	(Ex. Tempest)
RAMBLER	52-66/68-69	(Ex. Early '52)	61-69	All	52-61	(Ex. Early '52)	67-69 1969	American Javelin & Rambler
STUDEBAKER	50-66	All	50-66	All	50-66	All	40-66	All
THUNDERBIRD	55-69	All	58-69	All	55-69	All	55-56	All
VALIANT	60-69	All	57-69	All	60-65, 68-69	(Ex. 1962)	60-69	All
VOLKSWAGEN†	—	—	—	—	—	—	—	—
WILLYS	41-69	All	—	—	51-61	All	40-67	All

*CAN ALSO BE USED ON MOBILE HOMES, TRAILERS AND MOST ½ & ¾ TON PICKUP TRUCKS

†3-4474 Shock Absorber Spring fits all 1957-69 Volkswagen Front & Rear.