

FIG 20-6 – Standard hand signals suitable for locomotive and other boom cranes One-hand signal for extending or retracting telescoping boom (not shown above) Extend boom – one fist in front of chest with thumb topping chest Retract boom – one fist in front of chest, thumb pointing outward and heel of fist