# SHERWIN-WILLIAM

ONE U. S. GALLON

3.785 LI




# SHINGLE STAIN

## SILVER GRAY

Rx A14 A Y1

0007-SWP-048392

# SHERWIN-WILLIAMS

2a (1-62)

**CAUTION!**
**COMBUSTIBLE**
**Keep Away From Heat and Open Flame**
**CONTAINS LEAD**
**HARMFUL IF EATEN**

Do not apply on any interior surfaces of a dwelling, or a place used for the care of children, or on window sills, toys, cribs and other furniture which might be chewed by children. Avoid breathing vapor or spray mist and prolonged contact with skin. Wash thoroughly after handling and before eating or smoking. Keep container closed when not in use.

Use with adequate ventilation.

**KEEP OUT OF REACH OF CHILDREN**

Sherwin-Williams Shingle Stain Silver Gray is especially designed to protect and beautify vertical surfaces of homes and buildings constructed of shakes, wooden shingles and rough lumber. It is not recommended for roofs.

IMPORTANT—TO INSURE A UNIFORM COLOR, ALL PACKAGES OF STAIN THAT ARE INTENDED FOR USE ON ANY ONE JOB SHOULD FIRST BE MIXED TOGETHER.

STIR THOROUGHLY WITH A WOODEN PADDLE BEFORE USING AND FREQUENTLY WHILE USING. BEST RESULTS ARE OBTAINED ONLY WHEN PIGMENT AND LIQUIDS ARE THOROUGHLY INCORPORATED.

Since the same stain will produce different tones on different kinds of wood, it is impossible to guarantee that exactly the same tone will be obtained on every kind of wood. The samples in our Shingle Stain Color Cards, approximate the shades which may be obtained on Red Cedar.

Be sure the shingles are thoroughly dry before staining. Best time to paint is during a period of dry weather when humidity is low. Most finishes or coatings dry best at 65° F. or higher.

This stain may be applied either by dipping or by brushing. For new work always apply two coats. Allow at least two days drying between coats or until the first coat is thoroughly dry.

When a dip-coat is given do not soak the shingles in the stain but dip the thick end to about two-thirds of its length rapidly in and out of the stain, allowing the excess stain to drain back into the original package or dipping tank. Then throw the shingles in a loose pile to dry thoroughly before being laid. After the shingles have been laid, a brush coat should be applied—this insures a more uniform appearance.

For the first coat the stain should be used just as it comes from the package but for the final coat the addition of about one pint pure raw linseed oil to the gallon of stain will be beneficial. This applies particularly where the stain is being used on old work.

When this stain is used on old shingles that have weathered or on shingles previously stained, the color effect will differ somewhat from that secured when it is used on new shingles. 9-58

**THE SHERWIN-WILLIAMS CO.**
GENERAL OFFICES: CLEVELAND 1, OHIO
MADE IN U. S. A.

0007-SWP-048393