BRAKE DRUMS (Cont.)

WHEREVER TWO DIFFERENT NUMBERED BOLTS AND NUTS ARE SHOWN FOR AN APPLICATION THE TOP LISTINGS ARE THE RIGHT HAND THREADS.

Car & Year	Models	Front Drums	Front Bolt	Qty.	Front Nut	Qty.	Rear Drums	Rear Bolt	Qty.	Rear Nut	Qty.
CORVAIR (Cont.)											
1960	Pass. Car & Sta. Wgn. (Early) 9" x 1-3/4" Brakes (Ex. w/Metallic Lining)	3-2584	3-1729	8	358501	8	3-2584	3-1729	8	358501	8
CORVAIR TRUCK											
1961-68	All Series R1200 (F.C.) Corvair 95, Greenbriar	3-2503	3-1734	10	358501	10	3-2503	3-1734	10	358501	10
CORVETTE											
1963-68	All (Ex. w/Metallic Lining)	3-2524	3-1734	10	358501	10	3-2503	3-1734	10	358501	10
1960-62	All (Late '60) (Ex. w/Metallic Lining)	3-2503	3-1734	10	358501	10	3-2503	3-1734	10	358501	10
1960	Early (Ex. w/Metallic Lining)	3-2503	3-1729	10	358501	10	3-2503	3-1734	10	358501	10
1953-59	All (Ex. w/Metallic Lining)	3-2503	3-1729	10	358501	10	3-2503	3-1729	10	358501	10
DART											
1960-68	All w/10" Brakes	3-2479	3-1689	5	358501	5	3-2485	3-1735	5	358501	5
			3-1690	5	3-1772	5		3-1736	5	3-1772	5
1960-68	All w/9" Brakes	3-2498	3-1689	5	358501	5	3-2497	3-1735	5	358501	5
			3-1690	5	3-1772	5		3-1736	5	3-1772	5
DESOTO											
1959-61	All 11" x 2-1/2" Brakes	3-2592	3-1680	5	GP1012	5	3-2592	3-1680	5	GP1012	5
			3-1681	5	GP1013	5		3-1681	5	GP1013	5
1957-61	All 12" x 2-1/2" Brakes Do not use w/14 x 5:00 or 14 x 5:50 Wheels	3-2428	3-1680	5	GP1012	5	3-2428	3-1680	5	GP1012	5
			3-1681	5	GP1013	5		3-1681	5	GP1013	5
1957-58	All 11" x 2-1/2" Brakes	3-2592	3-1680	5	GP1012	5	3-2592	3-1680	5	GP1012	5
			3-1681	5	GP1013	5		3-1681	5	GP1013	5
DODGE PASS. (SEE DART, LANCER)											
1968	Polara, Monaco, Police, Taxi w/426 Eng. & w/Trailer Tow Pkg. - Cast	3-2466+	3-1655	5	GP1012	5	3-2472	3-1698	5	GP1012	5
			3-1656	5	GP1013	5		3-1699	5	GP1013	5
1967-68	Polara, Monaco Marked M.W. - Cast	3-2432+	3-1655	5	GP1012	5					
			3-1656	5	GP1013	5					
1967-68	Polara, Monaco Marked "B" - Cast	3-2432+	3-1685	5	GP1012	5					
			3-1684	5	GP1013	5					
1967-68	Polara, Monaco 11" x 3" Brakes	3-2445+	3-1680	5	GP1012	5	3-2472+	3-1698	5	GP1012	5
			3-1681	5	GP1013	5		3-1699	5	GP1013	5
1967-68	Coronet, Charger Marked CB 51 - Cast	3-2406+	3-1685	5	GP1012	5					
			3-1684	5	GP1013	5					
1967-68	Coronet, Charger Marked K.H.E. 223 and M.W. 35386	3-2495+	3-1680	5	GP1012	5					
			3-1681	5	GP1013	5					
1967-68	Coronet, Charger Police, Taxi w/383, 426 Eng. 11" x 3" Brakes	3-2427+	3-1680	5	GP1012	5	3-2446+	3-1698	5	GP1012	5
			3-1681	5	GP1013	5		3-1699	5	GP1013	5
1966-68	Coronet, Charger (Ex. Sta. Wgn.) 10" x 1-3/4" Brakes						3-2906+	3-1698	5	GP1012	5
								3-1699	5	GP1013	5
1965-68	Coronet, Charger 10" x 2-1/2" Brakes (Ex. 67-68 Front)	3-2495+	3-1680	5	GP1012	5	3-2908+	3-1698	5	GP1012	5
			3-1681	5	GP1013	5		3-1699	5	GP1013	5

+Original car manufacturer equipped these vehicles with 3 types of Brake Drums: these were all cast or composite (some smooth and/or ribbed). It is IMPORTANT that you check and identify the drum you are removing BEFORE ordering a Brake Drum for the specific application.