BRAKE DRUMS (Cont.)

WHEREVER TWO DIFFERENT NUMBERED BOLTS AND NUTS ARE SHOWN FOR AN APPLICATION THE TOP LISTINGS ARE THE RIGHT HAND THREADS.

Car & Year	Models	Front Drums	Front Bolt	Qty.	Front Nut	Qty.	Rear Drums	Rear Bolt	Qty.	Rear Nut	Qty.
FAIRLANE (Cont.)											
1966	All Models 54, 62, 63 w/8 Cyl. 390 Eng.						3-2440+	3-1693	10	B1012	10
1962-65	All w/10" x 2" H.D. Brakes						3-2440+	3-1693	10	B1012	10
1963-65	All (After June '63 to 12-6-65) Cast Frt.	3-2431+	3-1688	10	B1012	10	3-2593+	3-1693	10	B1012	10
1963	All (Ex. H.D. & S.W.) Before June 1963	3-2595+	3-1677	10	B1012	10	3-2593+	3-1693	10	B1012	10
1962	All (Ex. H.D.)	3-2595+	3-1677	10	B1012	10	3-2593+	3-1693	10	B1012	10
FALCON											
1966-68	All w/10" x 2" Brakes						3-2440+	3-1693	10	B1012	10
1966-68	Models 54-62, 6 Cyl. 9" x 2-1/4" Brakes	3-2484	3-1677	8	B1012	8	3-2556	3-1693	8	B1012	8
1965-68	V8 (Prod. After 5-1-65) Cast	3-2431+	3-1688	10	B1012	10	3-2593+	3-1693	10	B1012	10
1962-68	All w/10" x 1-3/4" Brakes						3-2593+	3-1693	10	B1012	10
1966-67	Model 71 Sta. Wgn.						3-2440	3-1693	10	B1012	10
1966	Model 66 Rancheros 6 Cyl.						3-2440	3-1693	10	B1012	10
1966	Std. Pass. Car w/9" Brakes						3-2556	3-1693	8	B1012	8
1966	Std. Pass. Car w/9" x 2-1/2" Brakes from 5-1-65	3-2555	3-1677	8	B1012	8					
1966	V8 10" x 2-1/2" Brakes						3-2487+	3-1693	10	B1012	10
1964-65	Station Wagon						3-2555	3-1693	8	B1012	8
1963-65	V8 Before 5-1-65 w/10" Drums	3-2578+	3-1677	8	B1012	8	3-2593	3-1693	8	B1012	8
1960-65	Std. Pass. Car w/9" x 2-1/2" Brakes	3-2555	3-1677	8	B1012	8	3-2556	3-1693	8	B1012	8
1962-63	V8 Before June 1963 w/10" Drums	3-2595+	3-1677	8	B1012	8	3-2593	3-1693	8	B1012	8
1960-63	Station Wagon w/9" Drums	3-2555	3-1677	8	B1012	8	3-2555	3-1693	8	B1012	8
FORD PASS. (SEE FAIRLANE, FALCON, MUSTANG, THUNDERBIRD)											
1967-68	All (Ex. Taxi)	3-2590	3-1675	10	B1012	10	3-2590	3-1693	10	B1012	10
1965-66	All 11" x 2-1/2" Brakes (Ex. Taxi)	3-2590	3-1675	10	B1012	10	3-2569	3-1693	10	B1012	10
1965-66	All 11" x 3" Brakes (Ex. Taxi)	3-2557	3-1675	10	B1012	10	3-2569	3-1693	10	B1012	10
1960-64	3" Frt. Brakes	3-2557	3-1677	10	B1012	10	3-2569	3-1693	10	B1012	10
1960-64	2-1/2" Frt. Brakes	3-2590	3-1677	10	B1012	10	3-2569	3-1693	10	B1012	10
1957-59	All (Ex.S.W.,Sed.Del.; H.T.Conv.; Ranchera; Pol.Intercepter; Taxi)	3-2562	3-1677	10	B1012	10	3-2576	A9A-1107A	10	B1012	10
1957-59	All S.W.; Sed.Del.; H.T. Conv.; Ranchero; Police Intercepter	3-2562	3-1677	10	B1012	10	3-2425	A9A-1107A	10	B1012	10
1955-56	Pass. Cars Only	3-2577	3-1677	10	B1012	10	3-2596	A9A-1107A	10	B1012	10
1955-56	All Station Wagon	3-2577	3-1677	10	B1012	10	3-2577	A9A-1107A	10	B1012	10
1952-54	All Station Wagon	3-2577	3-1677	10	B1012	10	3-2596	A9A-1107A	10	B1012	10
1949-54	All Pass. Cars	3-2578	3-1677	10	B1012	10	3-2597	A9A-1107A	10	B1012	10
1949-51	All Station Wagon	3-2578	3-1677	10	B1012	10					
FORD TRUCK											
1966-68	Bronco w/11" Brakes						3-2561	3-1693	10	B1012	10
1964-68	F-250 (Ex. 4 Wheel Drive)	3-2442	3-1662	16	B1012	16	3-2422	8D-1107A	16	B1012	16

+ Original car manufacturer equipped these vehicles with 3 types of Brake Drums: these were all cast or composite (some smooth and/or ribbed). It is IMPORTANT that you check and identify the drum you are removing BEFORE ordering a Brake Drum for the specific application.