practical cases it is desirable to treat convection and radiation as a single combined process, using a first-power equation:

$$q_{rc} = h_{rc} A (t_1 - t_2) \quad (4)$$

where q_{rc} is the total heat flow due to radiation and convection, in Btu per hour. Values of h_{rc}, the surface or film conductance for combined

TABLE 6. RADIATION FACTORS OR EMISSIVITIES, ε.
For the determination of factor F_E in Equation 3

CLASS	SURFACES	FRACTION OF BLACK-BODY RADIATION		ABSORPTIVITY FOR SOLAR RADIATION
		At 50–100 F	At 1000 F	
1	A small hole in a large box, sphere, furnace, or enclosure	0.97 to 0.99	0.97 to 0.99	0.97 to 0.99
2	Black non-metallic surfaces such as asphalt, carbon, slate, paint, paper	0.90 to 0.98	0.90 to 0.98	0.85 to 0.98
3	Red brick and tile, concrete and stone, rusty steel and iron, dark paints (red, brown, green, etc.)	0.85 to 0.95	0.75 to 0.90	0.65 to 0.80
4	Yellow and buff brick and stone, firebrick, fire clay	0.85 to 0.95	0.70 to 0.85	0.50 to 0.70
5	White or light-cream brick, tile, paint or paper, plaster, whitewash	0.85 to 0.95	0.60 to 0.75	0.3 to 0.5
6	Window glass	0.90 to 0.95	.....	Transparent[a]
7	Bright aluminum paint; gilt or bronze paint	0.4 to 0.6	.....	0.3 to 0.5
8	Dull brass, copper, or aluminum; galvanized steel; polished iron	0.2 to 0.3	0.3 to 0.5	0.4 to 0.65
9	Polished brass, copper, monel metal	0.02 to 0.05	0.05 to 0.15	0.3 to 0.5
10	Highly polished aluminum, tin plate, nickel, chromium	0.02 to 0.04	0.05 to 0.10	0.10 to 0.40

[a]Reflects about 8 per cent

radiation and convection, are given in Chapter 6, Table 1 and Fig. 3. Complete tables for the combined heat transfer of steam and hot water radiators, pipes, coverings, etc., will be found in the appropriate chapters.

When dealing with the effect of operating temperatures upon the combined heat transfer of a given piece of equipment (as for instance a steam radiator), another form of equation is frequently used:

$$q_{rc} = B A (t_1 - t_2)^n \quad (5)$$

Values of n in this equation usually range from 1.3 to 1.5 (see Chapter 25). The chief advantage of this equation is the convenience of representing heat transfer performance on logarithmic coordinates, and the factor B should be regarded as a simple constant of proportionality.

HEAT-FLOW RESISTANCE

In most of the steady-state heat transfer problems encountered in air conditioning applications, more than one of the heat transfer mechanisms are effective, and the thermal current flows through several resistances in series or in parallel. In using the resistance concept the calculations involved are analogous to the application of Ohm's Law in electricity, *viz.*, the heat flow or thermal current is directly proportional to the thermal

TABLE 7. HEAT TRANSMISSION BY RADIATION FOR BLACK-BODY CONDITIONS[a]
Expressed in Btu per (square foot) (hour)

TEMP F DEG	0	−1	−2	−3	−4	−5	−6	−7	−8	−9
−30	59.3	58.7	58.2	57.7	57.2	56.7	56.2	55.7	55.2	54.7
−20	65.2	64.7	64.1	63.5	62.9	62.3	61.7	61.1	60.5	59.9
−10	71.4	70.8	70.1	69.5	68.9	68.3	67.7	67.1	66.4	65.8
0	78.0	77.4	76.7	76.0	75.4	74.7	74.0	73.4	72.7	72.1
	0	+1	+2	+3	+4	+5	+6	+7	+8	+9
0	78.0	78.7	79.4	80.1	80.8	81.5	82.2	82.9	83.6	84.3
10	85.0	85.7	86.5	97.2	88.0	88.7	89.4	90.2	90.9	91.7
20	92.4	93.3	94.0	94.8	95.6	96.4	97.2	98.0	98.8	99.6
30	100	101	102	103	104	105	105	106	107	108
40	109	110	111	112	112	113	114	115	116	117
50	118	119	120	121	122	123	123	124	125	126
60	127	128	129	130	131	132	133	134	135	136
70	137	138	139	140	142	143	144	145	146	147
80	148	149	150	151	152	153	154	155	156	157
90	159	160	161	162	163	164	166	167	168	169
100	170	171	173	174	175	176	178	179	180	182
110	183	184	185	187	188	189	191	192	193	195
120	196	197	199	200	201	203	204	206	207	209
130	211	212	214	215	217	218	220	221	222	224

[a]*Example:* Radiation from walls of room at 32 F to surface at − 25 F for effective emissivity of 0.95 = (102 − 62.3) 0.95 = 37.7 Btu per (square foot) (hour).

potential or temperature difference, and inversely proportional to the thermal resistance:

$$q_{rc} = \frac{t_1 - t_2}{R} \quad (6)$$

Following the electrical analogy, when there is a thermal current flowing through several *resistances in series*, the resistances are additive:

$$R_T = R_1 + R_2 + R_3 + \ldots + R_n \quad (7)$$

Similarly, conductance is the reciprocal of resistance, and for heat flow through several *resistances in parallel*, the conductances are additive:

$$C_T = \frac{1}{R_T} = \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3} + \ldots + \frac{1}{R_n} \quad (8)$$

Practical Heat Transfer Problems

The use of these relations for resistance and conductance makes possible the solution of many practical heat transfer problems. As discussed in Chapters 6, 7 and 28, the practical analyses of heat transfer in building walls, in fin-tube coils and in pipe coverings, are usually computed by this