JOB 11087 — TANK FARM & TANK CAR LOADING AREA
CLEANUP & POLLUTION CONTROL

Leaks and spillage around the Aroclor tank farm area should be cleaned up. Only if this area is concreted and curbed, can spills be contained. Curbing this area will provide for a means of handling all rain water which contacts spilled Aroclor. Facilities for area drainage will tie in with this. Present drainage will be to the 12" sewer line running parallel, North & South, and just a few feet to the East of the railroad tracks to the N.W. corner of the warehouse, at which point a 90° elbow and 6" line to the NE corner of the warehouse; at this point a concrete lined sump can handle all second phase. This will be a valuable last step in eliminating PCB from our effluent, which without would be very detrimental to our hopes of reaching PCB pollution limits.

Small localized curbing & concreting for individual pump leaks and spills within the tank farm would be also a total concrete job to contain any spills. This will be complete.

MONS 038387

Rainwater is going to contact Aroclor leaks & spills producing second phase. This is why a sump is needed to separate PCB from this effluent

① a Concreting and curbing the tank farm area will estimated [redacted] KO GPM of rainwater to [redacted] the sump.

① Send the water to the present sump. The present sump is designed to handle 250 GPM. This figure doesn't necessarily mean that the sump [redacted] receiving an add'l 125 GPM will cause a backflow of water in present [redacted] drains to the sump. The sump is designed to handle a velocity of water [redacted] which is kept below a certain level will not allow any small PCB particles to escape a chance to settle and leave with [redacted] the effluent. If [redacted] this figure will [redacted] overrun & PCB [redacted] escapes, then our pollution limit is overrun.

② Drain the water to the mentioned [redacted] line and send to [redacted] small [redacted] sump [redacted]

A future concrete pad job will be done to the east side of the aroclor dept. which when finished will add an additional 40 GPM to the sump as a result of rainwater. This is really an unwanted addition to the sump, but is needed for the purpose of being able to clean up aroclor spills.

Concreted Tank Farm Area 120 x 80 = 9600 ft²

$\frac{9600 \times 2.1 \text{ in/hr}}{12} = \frac{19,200}{12} = 1600 \text{ ft}^3/\text{hr}$

$1600 \times 7.5 = 12{,}000 \frac{\text{gal}}{\text{hr}} \times \frac{\text{hr}}{60} = 200$ max gpm + Reinvento

Too much to add to the sump

Area of tanks = $\pi r^2 = 3.14 \times (6.25')^2 = 123 \text{ ft}^2$/tank

$123 \text{ ft}^2/\text{tank} \times 12 \text{ tanks} = 1460 \text{ ft}^2$ taken up by tanks

9600 ft² area total
−1460 ft² of tanks
7540 ft² of concrete
− 100 ft² concrete pads for pumps
7440
−2440 ft other pads

(Won't include Tank or berm area.)

MONS 038389

$7000 \text{ ft}^2 \times \frac{6''}{12} = 3500 \text{ ft}^3$ of concrete for tanks from pad