the thin bars has disappeared, since the small air jets have reunited and the air stream has not yet spread beyond the core dimensions. With deflecting grilles the exploring jet should be turned to the angle giving a maximum reading. With suitable traversing tips and calibration, this instrument may also be used on exhaust grilles if proper grille factors are applied.[31] Those contemplating such measurements should consult the references cited.

Smoke is a qualitative tool which is very useful in studying air movements. Satisfactory smoke can be obtained from titanium tetra-chloride (which, however, is very irritating to nasal membranes) or by mixing potassium chlorate and powdered sugar (a non-irritating smoke) and firing the mixture with a match. This latter process evolves considerable heat, and it should be confined in a pan away from flammable materials. The titanium tetra-chloride smoke lends itself to spot determinations, particularly for leakage through casings and ducts, as it can be easily handled in a small pistol-like ejector. The fumes of aqua ammonia and of sulfuric acid, if permitted to mix, form a white precipitate which is useful for some purposes. Two bottles, one containing ammonia water and the other acid, are connected to a common nozzle by means of rubber tubing. Air is forced over the surfaces of the liquids in the bottles by means of a syringe, and the two streams, upon mixing at the nozzle, form a white cloud.

The Kata Thermometer

The measurement of air current velocities within enclosed spaces, such as the rooms of a house, is usually a tedious undertaking. However, useful data can be obtained by using the instruments described in following paragraphs if they are maintained in calibration, and the user understands the operation and limitations of the instruments.[32]

One of the instruments useful for determining the velocity of air currents in free spaces is the Kata thermometer which is essentially an alcohol thermometer with a large bulb. The instrument is heated above 100 F, and then the time in seconds required for it to cool from 100 to 95, when located in the air current, gives a measure of the air speed. It is important to have the Kata thermometer dry before taking the reading. Each Kata has its own factor etched on the stem, and this factor must be used with its cooling formula or chart for obtaining the velocity. The Kata thermometer is useful in exploring ventilated spaces to determine whether the proper air movement and distribution are being maintained. It is also used in determining the cooling power of the atmosphere, since it loses heat by radiation and convection when dry, and by radiation, convection, and evaporation when the bulb is equipped with a wetted cloth covering.[33]

Thermal Anemometers

If a suitable sensing element is heated electrically at a fixed rate and exposed to an air stream, the temperature difference between the element and the stream becomes a measure of velocity by calibration. In the *hot-wire anemometer*, a very fine heated wire is employed as a resistance-thermometer element whose temperature may be determined accurately.[34, 35] In the *heated-bulb thermometer* type, a heating wire is wound around the bulb of a mercury-in-glass thermometer, and the temperature difference between this thermometer and a similar unheated one serves as an index of air speed.[36] The *heated-thermocouple anemometer* is calibrated to give velocity in terms of the differential *emf* between heated and

unheated thermo-junctions exposed to an air stream.[34, 37] Combined measurements of air temperature and velocity are particularly useful for air distribution studies, and automatic recording potentiometers or resistance-thermometer devices facilitate spatial traverses. A correct calibration of thermal anemometers requires consideration of the effects of temperature, humidity and pressure upon the air properties which influence convective heat transfer.[37] With sensing elements of simple shapes for which convection data are known, thermal anemometers may be designed, both thermally and electrically, for desired characteristics. Directional sensitivity is controllable. Thermal anemometers are convenient and practical for low velocities.

Infiltration or Air Change Measurement

The total air leakage into an existing building caused by wind and temperature difference forces can be determined with considerable accuracy by determining the decrease in concentration of a tracer gas. Hydrogen and helium have both been used rather successfully as tracer gases in conjunction with a sensitive thermal conductivity comparator.[39] About one percent of tracer gas by volume is introduced into the room or building, and the tracer gas is thoroughly mixed with the air. The decrease in concentration of the tracer gas is observed at regular time intervals with a thermal conductivity meter as infiltration dilutes the mixture. The following formula is used to calculate the infiltration from the observed concentration measurements:

$$C = C_o e^{-\frac{kt}{v}} \tag{7}$$

where

C_o = initial tracer gas concentration, percent.
C = concentration of tracer gas after t minutes, percent.
v = volume of room or building, cubic feet.
k = infiltration rate, cubic feet per minute.
e = 2.718, for natural logarithms.

Closets and cupboards should be left open during such infiltration tests so the entire space will have the same rate of change of tracer-gas concentration.

HUMIDITY MEASUREMENT

Psychrometers

Any instrument capable of measuring the humidity or hygrometric state of the air is a hygrometer. A psychrometer is a particular kind of hygrometer which consists of two mercury thermometers, one of which has a cloth wick or *sock* applied to its bulb. For use, the wick is wetted with water and ventilated with air moving at a recommended rate of 900 fpm or more, relative to the instrument.[40] In the simpler and more common type, known as the sling psychrometer, the two thermometers are mounted side by side on a frame fitted with a handle by which the device can be whirled through the air. The motion is arrested for reading the thermometers, and continued until the thermometer readings become steady. Due to evaporation, the wet-bulb thermometer will indicate a lower temperature than the dry-bulb thermometer, and the difference is known as the wet-bulb depression. Charts and tables are available showing the relation between the thermometer readings and the humidity.[41, 42] Data are usually based on a total pressure of one standard atmosphere. For precise work, a correction is necessary for barometric pressure and is usually made by multiplying