DUP 0913292

ADRIAN LINCH –

Filter – a man-made synthetic filter, 8/10 micron holes, & filters on equal & similiar one to the other.

BE SURE BOTH PLUGS ARE IN PLACE WHEN YOU RECEIVE FILTERS. If not, throw filter away.

1. Remove plug from end of filter closest to filter paper.
2. Attach sample tube to filter opening.
3. Remove top cap on opposite end – when ready to sample.
4. Sample.
5. ~~Remove~~ Replace top ring and tape together for shipment. Use any self-adhesive tape, and over end to keep red & blue plugs in place
6. In case of site calibration – Use electrical tape – pulled tight!
7. Wrap in paper towel packing to keep it from breaking in shipment. Can obtain a box or tube from Stationery for shipment – check Stationery catalog. (Linch prefers tube). Tube is 1¾" or 2" x 6" long.