separately for part of the boilers, and not connected in manifold with another chimney, in order to avoid the difficulty described previously.

In domestic installations it is sometimes necessary to serve a space heater or cooking stove and a water heater with the same chimney flue. This is not desirable, especially for low chimneys, since doors left open on one device, while it is unfired, will tend to annul the draft on another device. Gas burning devices, with their draft hoods and lack of draft dampers, are especially bad in this respect. The traditional method of avoiding this with brick chimneys has been to construct multiple-flue chimneys, so that each fuel-burning device could be served by a separate opening. If two devices must be served by one flue-opening in a chimney, their connections to the chimneys should not be located opposite each other. The connection from the larger device should be reasonably low down, and that from the smaller, up near the ceiling, so that each device can be serviced as well as possible, regardless of the treatment of the other.

Excessive height in a chimney does no harm, but means for controlling the draft are more than ordinarily essential if the chimney is too large in capacity. Coal-burning devices often have air leaks around the firebox, and the draft doors sometimes fit so poorly that the fire cannot be controlled at a low rate. The simplest remedy for such cases is the barometric damper which admits air into the flue pipe and thus reduces draft.

Where a chimney serves a fireplace, it is important that no other heating device be connected to it unless the fireplace is effectively sealed.

REFERENCES

[1] A Study of Flow Phenomena in the Wake of Smokestacks, by R. H. Sherlock and B. A. Stalker (*Department of Engineering Research, University of Michigan, Bulletin* No. 29, 1941).

[2] Notes on Power Plant Design, by E. F. Miller and James Holt (*Massachusetts Institute of Technology*, 1930).

[3] Friction Factors for Pipe Flow, by L. F. Moody (*A.S.M.E. Transactions*, Vol. 66, 1944, p. 671).

[4] Mechanical Engineers' Handbook, Eleventh Edition, by R. T. Kent, Editor in Chief (John Wiley and Sons, Inc.).

[5] Handbook of Building Construction, by G. A. Hool and N. C. Johnson (McGraw-Hill Book Co., Inc., New York, 1929).

[6] Performance of Residential Chimneys, by L. B. Schmitt and R. B. Engdahl (A.S.H.V.E. JOURNAL SECTION, *Heating, Piping and Air Conditioning*, November 1948, p. 111).

[7] Observed Performance of Some Experimental Chimneys, by R. S. Dill, P. R. Achenbach and J. T. Duck (A.S.H.V.E. TRANSACTIONS, Vol. 48, 1942, p. 351).

[8] Performance of Fourteen Masonry Chimneys Under Steady State Conditions, by P. R. Achenbach and S. D. Cole (A.S.H.V.E. JOURNAL SECTION, *Heating, Piping and Air Conditioning*, October 1948, p. 119).

[9] Performance of Masonry Chimneys for Houses, by Robert K. Thulman (*Housing and Home Finance Agency, Technical Paper No. 18*, Aug. 1949).

[10] *National Bureau of Standards Commercial Standards:* CS101-43 Oil-Burning Space Heaters Equipped With Vaporizing Pot-Type Burners, CS75-42 Automatic Mechanical Oil Burners Designed for Domestic Installations, CS(E)104-43 Warm Air Furnaces Equipped With Vaporizing Pot-Type Burners; and *Trade Standards:* TS3536a Solid-Fuel Burning Forced Air Furnaces, TS3518 Oil-Burning Floor Furnaces Equipped With Vaporizing Pot-Type Burners.

[11] Comfort Heating, 1938, p. 71 (*American Gas Association*).

[12] Comfort Heating, 1938, p. 74 (*American Gas Association*).

[13] Chimneys and Draft (Chapter 32 in Winter Air Conditioning, by S. Konzo, published by *National Warm Air Heating and Air Conditioning Association*, 1939).

CHAPTER 17

ESTIMATING FUEL CONSUMPTION FOR SPACE HEATING

Basis of Fuel Estimates, Calculated Heat Loss Method, Degree-Day Method, Estimating Fuel Consumption, Degree-Day as an Operating Unit, Maximum Demands and Load Factors, Seasonal Efficiency

MANY methods are in use for estimating in advance of actual operation the anticipated heat or fuel consumption of heating plants over long or short periods. With suitable modification in procedure these same general methods are frequently useful in checking the degree of effectiveness with which heat or fuel is utilized during plant operation.

In applying any of these estimating methods to the consumption of a particular building plant it should be noted that (*a*) reliable records of past heat or fuel consumptions of the building under consideration will usually produce more trustworthy estimates of future consumptions than will any data obtained by averages or from other similar buildings; (*b*) where no past records exist useful data can sometimes be obtained from records of similar types of buildings with similar plants *in the same locality;* (*c*) records of consumption, which are averages from many types of plants in many types of buildings in various localities, can produce no better than an average estimate which may be far from accurate; (*d*) estimates based on computed heat losses without the benefit of operating data are wholly dependent on the degree to which the computation represents the actual facts.

Estimates based on computed heat losses alone are especially necessary where unusual operating conditions, such as excessive ventilation, abnormal inside temperatures, heat gains from external sources, etc., are encountered or where no information is available as to former consumption, as in the case of proposed buildings of unusual design.

In preparing, interpreting and evaluating heat or fuel consumption estimates it is well to realize that any estimating method used will produce a more reliable result over a long period operation than over a short period. Nearly all of the methods in common use will give trustworthy results over a full *annual* heating season, and in some cases such estimates will prove consistent within themselves for monthly periods. As the period of the estimate is shortened there is more chance that some factor not allowed for in the estimating method will become controlling, and thus give discrepant and even ridiculous results.

Of the various estimating methods in use attention is directed in this discussion to only two as they are illustrative of all, namely, (1) calculated heat loss method, and (2) degree-day method.

CALCULATED HEAT LOSS METHOD

This method is theoretical, and constant temperatures are assumed for very definite hours each day throughout the entire heating season. It does not take into account factors which are difficult to evaluate such as opening of windows, abnormal heating of the building, poor heating systems, winter