PLAINTIFF'S EXHIBIT

DOW-822

81-2795

SAFEWORK PROCEDURE FOR REMOVING ASBESTOS FROM ABANDONED LINES IN B-1000, B-1700, B-3300 & B-3400

1. HARD HAT MUST BE WORN.
2. SIDESHIELD GLASSES MUST BE WORN.
3. APPROVED DUST RESPIRATOR MUST BE WORN DURING MATERIAL REMOVAL AND CLEANUP.
4. DISPOSABLE COVERALLS WITH HOODS MUST BE WORN. DISPOSABLE COVERALLS MUST BE DISPOSED OF DAILY BY PLACING IN PROPERLY SEALED PLASTIC BAGS AND SENT TO DESIGNATED ASBESTOS LANDFILL.
5. RUBBER BOOTS ARE REQUIRED AND MUST BE WASHED BEFORE LEAVING THE ISOLATED AREA.
6. TAPE OFF SECTION OF PIPELAY BEING STRIPPED.
7. FILL OUT ASBESTOS SAFETY CHECK LIST PRIOR TO DOING THE JOB.

SPECIAL PRECAUTIONS -

1. USE WATER TO WET DOWN INSULATION BEFORE, DURING AND AFTER REMOVAL AS NECESSARY TO PREVENT AIR-BORNE EMISSIONS. AVOID EXCESSIVE AMOUNTS OF WATER - USE HAND SPRAYER AS MUCH AS POSSIBLE
2. ASBESTOS MUST NOT BE DROPPED TO GROUND. POLYETHYLENE MUST BE USED ON GROUND TO FACILITATE CLEANUP OF ANY ASBESTOS WHICH MAY FALL. POLY SHOULD BE DISPOSED OF AS ASBESTOS.
3. PLACE ASBESTOS DIRECTLY INTO POLYETHYLENE BAGS UPON REMOVAL AND SEAL.
4. AFTER ASBESTOS REMOVAL, A THOROUGH INSPECTION AND CLEANUP MUST BE MADE TO REMOVE ALL ASBESTOS FROM AREA BEFORE REMOVING TAG & SIGNS.

6-16-86

AUGUST MOLINA
x T5757

ST0015082

3-2795	71	
4	72	44.08
5	73	36.52
7	74	65.49
8	75	LT 1.26
1-2990	76	52.90
2	77	748.3
3	78	214.1
4	79	279.6
5	80	243.1
6	81	605.7
7	82	7.56
		149.9

LT = less than

Ronald L. McKee, CIH

ST00150B3

SECTION V

ASBESTOS SAFETY CHECK LIST

JOB DESCRIPTION: ASBESTOS REMOVAL DATE 6-16-86
LOCATION B-1000, B-1700, B-3300, B-3400

PRE-JOB REQUIREMENTS:

1. Environmental Services Contacted (ph. 1505)? Yes ✓ No ___
   Name: RANDY SNELGROVE Date: 6-18-86
   Dow Project Supervisor: AUGUST MOLINA
2. Safe Work Procedure Written? Yes ✓ No ___ Date: 6-16-86
3. Project Review Held? Yes ✓ No ___
   Industrial Hygienist: LINDA BULLARD Date: ___
   Safety Director: JERRY HINOJOSA Date: 6-16-86
   Craftsmen: SAM MASON Date: 6-16-86

	YES	NO
Safe Work Procedure Approved:	✓	
Hygiene Monitoring Required:	✓	
Audit Required:	✓	
Auditor Assigned: LINDA BULLARD Phone: 5757	✓	

JOB REQUIREMENTS:

	YES	NO
1. Safe Work Procedure reviewed:	✓	
2. Area taped off and signs up to warn others:	✓	
3. Have all involved personnel been informed?	✓	
4. Block personnel informed?	✓	
5. Auditor notified:	✓	
6. Water available to control dust:	✓	
7. Has disposal of asbestos debris been arranged?	✓	
8. Arrangements for clean-up made?	✓	

9. Safety Equipment Required
   - ✓ Disposable Coveralls with Hood
   - ✓ Dust Respirator
   - ✓ Side Shield Glasses
   - ✓ Rubber Boots
   - ___ Other: See Safe Work Permit

   NOTE: Work may commence when Safe Work Permit issued.

10. Final clean up complete (all traces of asbestos removed) Yes ✓ No ___
11. Job Complete: Dow Project Supervisor: [signature] Date: 8-12-86
12. Send completed Checklist to Industrial Hygiene Services - B-101.

ST0015084