

INTER-OFFICE MEMO **TENNECO CHEMICALS, INC.**

TO	Route List	AT		DATE	January 20, 1972
FROM	H.B. Carr	AT	Burlington	COPY TO	Distribution
SUBJECT	Testing Method 4-115				List Attached

Attached is Testing Method 4-115 entitled "Wet Screen Analysis, Blending Resins" which is to be placed in Section 4 of your Quality Control Manuals.

Also attached is your revised Index for Section 4. This index supersedes the one dated December, 1970. Please discard the obsolete copy and insert the revised one.

W. B. Carr

H.B. Carr

Attachments (2).

HBC/jt

TENNECO INTERMEDIATES DIVISION

TENNECO CHEMICALS, INC.

INDEX SECTION 4

<u>TITLE</u>	<u>METHOD NUMBER</u>
% Total Solids Content of Methocel Solutions	4-100
Wet Fisheye Determination	4-101
% Total Solids Determination of Centrifuge Effluent	4-102
Determination of Contamination (Wet Slurry)	4-103
Quantitative Analysis of Recovered Monomers	4-104
Viscosity Measurement (Ford Cup)	4-105
Ether Extract	4-106
Filtration Time of Plastisol Latex	4-107
Hot Plate Determination of % TSC of DHW-80	4-108
Titration of 1755 and 0565 Latex	4-109
Calibration of Pycnometer	4-110
Refractive Index Measurement of Liquids	4-111
Pressed Plaque Evaluation	4-112
Filterability of Plastisol Latex (Filter Leaf Test)	4-113
Evaluation of Methocel Solution for Undissolved Methocel	4-114
Wet Screen Analysis, Blending Resins	4-115

Effective January, 1972

Supersedes Index Dated December, 1970

TENNECO INTERMEDIATES DIVISION

TENNECO CHEMICALS, INC.

QUALITY CONTROL

TESTING METHOD

DATE: January, 1972

METHOD NO.: 4-115

TITLE: Wet Screen Analysis, Blending Resins

SCOPE: The quantitative determination of resin retained on a 200 mesh screen.

APPARATUS: Torsion Balance
U.S. Standard Screen, 200 mesh
Oven, forced air

CHEMICALS: Sample to be tested.
Tap water.

PROCEDURES:

1. To a tared 200 mesh screen add 50 grams of resin to be tested.
2. Place under running tap water and agitate with the fingers until the only sample remaining is that which cannot pass through the screen.
3. Place the wet screen in a forced air oven until dry.
4. Remove from oven and cool to room temperature.
5. Weigh on torsion balance. The increase of weight recorded (A).

CALCULATIONS: $A \times 2 = \% \text{ retained}$

REPORT: Report to the nearest 0.1%.

Written by: E.L. Kanyok

Issued by: H.B. Carr
H.B. Carr
Supervisor - Quality Control

COLORITE 016679