

EQUIPMENT	PAGE 2 CG 46 CODE YW-811-P (B) EST. WGT.	LBS.	USE LBS.	N CODE	ACCT LBS.
	22 While homogenizing at 5-10 min intervals, jog agitator on ALM to maintain color suspension				
	23 Rinse ALM with 2 1/4 # water calculated in S 3 thru homogenizer at 2000-5000 PSI				
	24 Drain lines from homog to CV into drum & pour into CV				
	25 Add & stir 30 min 4:35 PM To 5:05 PM		4 ozs	816-A	1
	26 Record: pH 11.4 (10.0-12.0)				
	27 If necessary, adjust to pH 10.0-12.0 Assume 50%			7-D	
	Record: pH Assume 75%			30-D	
	28 Discharge +25 G thru packout line & pour into CV				
	29 Fill 1-16 ounce jar from packout line & deliver to CTL for color. Record in S 42				
	30 Fill 1-16 ounce jar from packout line & run 100 mesh screen test per SOP Record: results S 42				
	31 If screen test is OK, close manhole cover, turn off light, & leave agitator on. Note: If screen test is not OK, notify supervisor				
Homog 6	32 Clean Homog per SOP		25	3-A	25
CV 7	33 Add # water as required to CV Note: If test is satisfactory, omit S's 33-36				
	34 Start agitator & stir 20 min or longer to uniformity				
	35 Fill 1-16 ounce jar from packout line & deliver to CTL for color. Record in S 42				
	36 Shut off agitator until test is available				
	37 When test is satisfactory, start agitator				
	38 Stir 5 min or longer				
	39 Check packout scale accuracy: 50# 500#				
	40 Discharge thru packout screen as follows:				
	PACKAGE N-CODE SCHEDULED PACK TOTAL NET PACK				
	N-1775 1 8550				
	N-1775 1 249				
	GRAND TOTAL NET PACK 8799				
	Note: After discharging +25 G, fill 2-16 ounce jars from packout line, mark "FINAL." Deliver to CTL when packout is completed. Record in S 42				
	41 Stop agitator				
	42 Record: Results Time Supv				
	S30 Screen tested				
	S29 Color sample to CTL 12% weak 10:20 PM J.H.				
	S35 Resample to CTL				
	S40 Samples during packout				
	S40 Delivered to CTL				
	START 10:30 AM 3:00 PM	FINISH 3 PM	OPERATOR 428 211		

