bone ash.

III - INSULATING OPERATIONS

Insulation plays an important part in the processing of petroleum products. The two types of insulating material most frequently used are "Sponge Felt" (asbestos with ground sponge to give dead air space and thus increase the effectiveness of the insulation) and a mixture of 85% magnesia and 15% asbestos. Rock wool is used to a considerably lesser degree. In the ordinary commercial form, Rock Wool, as used at our refineries, does not present a dust hazard. It is also used for house insulation, and is available in small nodule form which can be blown into place. "85% magnesia" is a mixture of magnesia and granulated asbestos and pressed into blocks of various sizes and shapes (usually 16" x 18" x 1-1/2"). The most dust comes from dismantling old insulation and grinding scrap material for use as a plaster or "ganister". The average service of men engaged in insulating operations is about fifteen years. Most of these men have been transferred from the Common Labor Department. They work nine out of fourteen eight-hour shifts, in gangs of from two to six men, and are actually exposed to dust for less than sixty per cent. of their working time. Goggles are sometimes provided, and occasionally MSA "Comfo" Respirators, but this equipment is not used as much as it should be. Generally speaking, about 85% of their work is with sponge felt and 15% with 85% magnesia insulation. At one of the larger southern refineries about 300,000 square feet of sponge felt and 50,000 square feet of 85% magnesia are handled a year.

A - What Physiological Reactions are Provoked by Insulating Materials? According to Dr. Leroy U. Gardner (Journ. Indust. Hyg. Mar. 1937, Vol. 19, No. 3, P. 121) asbestos dust with its fibrous particles does not seem to be readily handled by the protective mechanism of the lungs. Quoting from his article:

> "They are not removed to the lymphoid tissue but remain in contact with the delicate walls of the air spaces. They become surrounded by an iron-containing coating that fractures and gives rise to the peculiar structures known as 'asbestosis bodies'. The fibers are irritating, perhaps because of their form, and they excite a fibrosis which begins about the terminal bronchioles and spreads to form diffuse patches in the parenchyma. Often the distribution is sub-pleural. In the presence of infection, the reaction to asbestos dust is much more severe than that caused by the dust alone."

There is nothing in the pertinent literature, nor does the Bureau of Mines know of any evidence, which would demonstrate magnesite (a natural magnesium carbonate) to be harmful. It would fall in the class of "nuisance dusts" such as gypsum. While many of the so-called "nuisance dusts" have never been found to be harmful, it is the opinion of most investigators in the field of industrial hygiene that no worker should be exposed to any dust in a concentration exceeding 75 or 100 millions of particles per cubic foot of air.

B - What are the Principal Insulating Operations and How Much Dust is Produced During Such Operations? There is, of course, a wide variation in the amount of insulation work and the amount of dust produced. A few examples, however, will give a good general idea:

> INSULATING 12" STEAM LINES: 6" x 18" x 1-1/2" blocks of 85% magnesia are tied on the steam line with 14-gauge galvanized wire and covered with roofing paper to make it waterproof. Often times this work is performed on scaffolds twelve to fifteen feet above the ground, with men lying on their backs under the line part of the time.