

"DIXIE MADE FOR DIXIE TRADE"

Climatic

SHEEN
SEMI-GLOSS
4600 WHITE

THE AMERICAN PAINT WORKS
DIVISION
THE GLIDDEN COMPANY
★ NEW ORLEANS, LOUISIANA ★

GL031597

TIME TESTED

PAINTS · VARNISHES · LACQUERS · ENAMELS

SHEEN SEMI-GLOSS

Recommended for walls, ceilings, furniture and woodwork in kitchens, bathrooms, breakfast nooks, bedrooms, or any other room in the house where a velvet-like, washable finish is desired. Its ability to withstand repeated washing makes it ideal for hospitals, hotels, offices, schools.

DIRECTIONS

Stir Thoroughly With a Lifting Motion.

ON PLASTER SURFACES—Be sure surface is dry and free from dirt, grease and loose particles. All new plaster or cement walls that show indication of alkali or active lime after testing with Phenolphthalein should be given a wash coat of Zinc Sulphate solution (two pounds of Commercial Zinc Sulphate dissolved in one gallon of water.)

OLD PAINTED SURFACES—WALLS—If old paint has become porous and worn with age and repeated washings, apply a coat of Interior Base Coat and then proceed as recommended for New Unpainted Surfaces. If old paint is in good condition, one coat of Sheen Semi-Gloss is often sufficient. If two coats are considered necessary, apply a first coat of Sheen Semi-Gloss mixed with equal parts of Interior Base Coat. Allow this to dry then apply a coat of Sheen Semi-Gloss as it comes from the can. On woodwork in place of Base Coat use Under-Name! (Enamel Undercoater).

NEW UNPAINTED SURFACE—On unpainted walls make sure that all water resulting from washing has dried out. For first coat apply Interior Base Coat. Allow to dry overnight then apply a mixture of one-half Sheen Semi-Gloss and one-half of Interior Base Coat. After this has dried 24 hours apply a finishing coat of Sheen Semi-Gloss as it comes from the can. On woodwork use Under-Name! (Enamel Undercoater) in place of Base Coat.

82

↑
Pyrex 41.3°/s - Titium Calcium 10°/s

GL031598