

INTER-OFFICE LETTER

FROM	Cleveland	TO	Cleveland	DATE	January 31, 1972
SUBJECT		DATE			
MR. R. A. Moore		SUBJECT			Cleveland Contingency Laboratory Newsletter
REFER TO LETTER OF		DICTATED BY			

REDACTED

0007-SWP-037410

N22950

TRADE SALES...

Mildew Studies--Panels of Super White and Peace Yellow containing two pounds Skane M-8 were prepared for mildew cabinet exposure. In addition, three Morrow production batches representing Tinting White were included. Panels without M-8 will be used as controls...A-100 Super White containing various levels of Lysol were read after 30 days in mildew cabinet. Panels were equal to or poorer to control of A6 W 40 with no Lysol for mildew growth...Prepared card #1 on A80 V 12 Mildew Resistant Additive which will be a fill from John & Haas Skane M-8. Each one-ounce unit is to contain 0.6 oz. of undiluted M-8 equivalent to 4 lbs. M-8/100 gal. when added to one gallon paint...Prepared slides of various mildew panels of bare wood showing variations of mildew with grain types...Various panels were prepared using A6 W 40 with various mildewicides for exposure at the John & Haas site at Jacksonville, Florida...Exposure series being planned for exposing Skane M-8 in both white and dark colored solvent type paints...South Atlantic region reports that mildew is becoming a problem in solvent based house paint. Both S-W and competitors are experiencing flash mildew...Met with Sales to map out program for fast availability of mildewicide additive based on M-8.

0007-SWP-037411

0007-SWP-000112777