

10/18/82
(DATE)K2K75
(LOT)5527* LBS.
(EST WT)

YC-10-B

COMTYP JOB NAME: 01YE698BDMT

H2JS4

200

FWP 11/1/82

BLENDED BACK: CG 01, PQ 98,

(CODE)

(LOT)

(POUNDS)

EQUIP MENT	NAME: MOLYBDATE ORANGE	USE LBS	N-CODE	ACCT LBS
PREP				
1	1 OBTAIN SODIUM SULFATE FOR S-13	84	108-A	84
	2 CALCULATE & SET ON BADGER METER FOR 64.46% (NITRIC ACID WEAK)	93	33-D	60
	3 OBTAIN SODIUM CHLORIDE FOR S-33	734	4-A	734
	4 OBTAIN SODA ASH FOR S-37	146	3-A	146
	5 OBTAIN SODIUM SILICATE FOR S-39	237	32-D	237
	6 OBTAIN SODA ASH FOR S-43	350	3-A	350
	7 OBTAIN ANTIMONY TRIOXIDE FOR S-44	70	711-B	70
351	8 WEIGH SODIUM CHROMATE INTO V-351	4963	10-D	1885
2	OPTR MK 253, 37.98%			
	OPTR MK			
359	9 WEIGH IN SODIUM MOLYBDATE SOLUTION	859	423-D	303
3	OPTR MK 84, 35.27%			
	OPTR MK			
358	10 RUN 10" (500 G) WATER INTO V-358			
4	11 RUN V-359 INTO V-351 & PUMP IN V-351			
	12 ADJ TO 55" (2600 G)			
	13 SIFT IN N-108-A FROM S			
	14 STIR 5 MIN & RECORD: PH 9.9 (9.0-10.0)			
	15 ADJ TO PH 9.8-9.9 & RECORD: PH			
	(CAUSTIC SODA SOLUTION)			
	ASSUME 50%		7-D	
	ASSUME 66%		33-D	
	16 ADD N-33-D FROM S 2 USING BADGER METER			
	17 ADJ TO 66" (3121 G) AT 67-69*F			
	RECORD: VOL 66" & 69*F			
	18 STIR 5 MIN & RECORD: PH 7.6 (7.4-7.6) &			
	G/ML 1.082 (1.080-1.083)			
	NOTE IF G/ML OUT OF LIMITS FILL OUT CHECK			
	LIST & ATTACH. TAKE 1 QT SAMPLE			
SV	19 RUN 20" (996 G) WATER INTO V-247			
5	RECORD N-41-D STORAGE TANK TO PUMP FROM.			
	CIRCLE ONE: 402 410 411 420 424 425			
	20 CHECK WITH CU SUPV:			
	*STORAGE TANK MUST CONTAIN AT LEAST 2376			
	GAL: 402=49", 410=25", 411=48", 420=25",			
	424=25", 425=31"			
	*STORAGE TANK MUST HAVE STIRRED AT LEAST			
	20 MIN SINCE LAST ADDITION OR ADJUSTMENT			
	*STORAGE TANK MUST BE ISOLATED UNTIL ALL			
	PUMPING FOR THIS BATCH IS COMPLETE			
	21 SET METER FOR 300 G & PUMP TO SV 247			
	22 AT APPROX 100 G WHILE CONTINUING TO PUMP,			
	CHECK PH & DENSITY. RECORD BELOW. IF NOT			
	IN RANGE, STOP PUMPING & SEE SUPV.			
	* PH: 2.0 (2.2-3.7)			
	* DENSITY: 1.307 G/ML (1.270-1.328)			

OCT 25 1982

EQUIP MENT	USE LBS	N- CODE	ACCT LBS
---------------	------------	------------	-------------

23 IF S-22 OK & WHEN S-21 COMPLETE, RECORD DENSITY 1.307 G/ML ON TRAPPED SAMPLE FROM END OF S-21 PUMPING.

24 USING DENSITY FROM S-23, FIND METER SETTING FOR SECOND PUMPING IN TABLE BELOW. NOTE: TABLE ACCOUNTS FOR 300 G ALREADY PUMPED IN S-21. CIRCLE DENSITY & SETTING IN TABLE BELOW.

**** TABLE ****

G/ML	SETTING	G/ML	SETTING	G/ML	SETTING
1.270	1678	1.291	1534	1.312	1410
1.271	1670	1.292	1527	1.313	1404
1.272	1663	1.293	1521	1.314	1399
1.273	1656	1.294	1515	1.315	1394
1.274	1649	1.295	1509	1.316	1388
1.275	1641	1.296	1503	1.317	1383
1.276	1634	1.297	1497	1.318	1378
1.277	1627	1.298	1490	1.319	1372
1.278	1620	1.299	1484	1.320	1367
1.279	1614	1.300	1478	1.321	1362
1.280	1607	1.301	1473	1.322	1357
1.281	1600	1.302	1467	1.323	1351
1.282	1593	1.303	1461	1.324	1346
1.283	1586	1.304	1455	1.325	1341
1.284	1580	1.305	1449	1.326	1336
1.285	1573	1.306	1444	1.327	1331
1.286	1566	1.307	1438	1.328	1326
1.286	1566	1.307	1438	1.328	1326
1.287	1559	1.308	1432	1.329	1543
1.288	1553	1.309	1427	1.330	1537
1.289	1546	1.310	1421	1.331	1532
1.290	1540	1.311	1415	1.332	1526

25 SET METER & PUMP 1438G (RECORD FROM TABLE) FLUSH LINE WITH WATER INTO SV FOR APPROXIMATELY 30 SECONDS

26 ADJ LEAD NITRATE TO 76" (3625 G) AT 67-69°F. RECORD: 68 *F

27 STIR 5 MIN & RECORD PH: 2.5 (2.2-3.7)

28 IF NECESSARY ADJ TO PH 3.0-3.1 ASSUME 66% & RECORD PH: 3.0 ASSUME 50% 2

NOTE: DILUTE N-7-D 10:1 WITH WATER BEFORE ADDING

29 RECORD: 1.145 G/ML (1.143-1.144) IF OUT OF SPEC FILL OUT CHECK LIST & ATTACH.

30 STIR AT 67-69°F FOR S-31. TAKE 1 QT. SAMPLE.

31 OBTAIN 1 QT SAMPLES OF S-18 & S-30 SOLUTIONS & TITRATE TWICE

NOTIFY SUPV IF ML N-10-D IS NOT IN RANGE

7.1-7.4 OR IF THE TWO TITRATIONS DIFFER BY

MORE THAN 0.10 ML N-10-D (IF YES, FLUSH ALL

EQUIPMENT & REPEAT TITRATIONS). DO NOT PROCEED

IF N-10-D TITRATION IS OUT OF RANGE 1.90 - 2.00

ADJUST V-358 FOR A TITRATION PH OF 2.10 TO 2.20

FROM FINAL IN-LINE TITRATION, RECORD LOWEST

PH _____ & ML N-10-D _____

41-D 5110
57-A

33-D
7-D 1

33-D
7-D

