

SCHEDULE OF INSPECTION

To be carried out every three months

A. Canister Mask

- (1) Remove seal at bottom of canister.
- (2) Close with hand and test for fit and presence of leaks.
- (3) Check remaining life of canister - replace canister each year regardless of length of time in use.
- (4) Check head bands for life.
- (5) Wash face piece with soap and warm water, rubbing well.
- (6) Replace in box properly, taking care that tube deflectors are in proper position.

B. Air-line Respirator

- (1) Test all couplings, inspect gaskets and tighten well.
- (2) See that plug cap on second blower outlet is tight.
- (3) Affix face piece and operate blower to check air delivery.
- (4) Check hose by bending, inspecting for cracks and breaks.
- (5) Inspect safety belt.
- (6) Inspect head bands.
- (7) Affix face piece, place hand over Y and test for leaks and fit.
- (8) Wash face piece with soap and warm water, rubbing well.
- (9) Replace in case, using clean paper bag for face piece and tubes. Take care that the wrench and blower handle are in proper position.

C. One-half Hour Oxygen Mask

- (1) See that "Cardoxide" receptacle is full. If mask has not been used, change once a year.
- (2) Affix face piece, see that gaskets are in place.