

# BENTON & BOWLES COMPANY TECHNICAL REPORT

## Addendum Report #3: Additional Studies on VCM Adsorption

M. M. O'Mara/G. A. Lees

LOCATION

Avon Lake Technical Center

DATE May 25, 1974

Typed: May 28, 1974

PROJECT NO

A number of VCM exposures involving new adsorbants, commercial adsorbants at low VCM exposures, and a variety of exposure conditions have been carried out. During the course of this continuing study we have replaced the Century OVA with a Bendix Hydrocarbon Analyzer. In summary we have found:

- (1) The Bendix analyzer far outperforms the Century analyzer in terms of stability, background and accuracy,
- (2) carbon remains to be the best adsorbant for VCM,
- (3) the life-time of the Welsh cartridge in terms of 1 ppm breakthrough ranges between 30 minutes and 90 minutes,
- (4) the Welsh canister outperforms anything evaluated to date.

GROUP FILE TAGGING

J. L. Nelson  
E. W. Harrington  
G. D. Schaaf  
B. A. DiLiddo  
E. G. Schwaegerle  
W. Wilcox

B. M. G. Zwicker  
H. Waltemate  
E. B. Katzenmeyer, Jr.  
F. E. Krause  
R. M. Kreager  
J. Pausch  
P. Zakriski

A. L. Schultz  
R. W. Strassburg  
M. N. Johnson  
L. B. Crider  
E. A. Collins  
L. A. Chandler

R. J. Meyer  
C. Flynn  
D. L. Kent  
Plant Managers  
Plant Safety  
Engineers

20224001

BFG02470

## Introduction

Our last report (B.F.G. Technical Report, March 8, 1974) on the subject of VCM adsorption covered evaluations of new adsorbants and larger carbon canisters and cartridges. Since that report we have continued our studies in this area and have also prepared VCM standards in support of other investigations (gas chromatographic, chemical desorption, x-ray studies). This current report is a summary of this work. A summary of all experiments is provided in Table I. No detail is given for the Analytical Gas Standards (A.G.S.) prepared for other studies; a permanent record of this work will be retained.

During the course of this work we replaced the Century OVA with a Bendix Total Hydrocarbon Analyzer. One of the advantages with the Bendix instrument is the ability to determine VCM breakthrough times below  $T_5$ . An attempt was made to do this with the Century OVA at  $T_5$  (see #33, 34) but there is considerable error in the values. The main reason is due to the inherent 5-10 ppm background in the Century analyzer. This background can be zero suppressed with the Bendix instrument. We have also found that the baseline is much steadier with the Bendix instrument. Baseline drift is probably the greatest source of error with the Century OVA analyzer, especially in the 0-5 ppm region. The agreement between the two methods considering the above limitations with the Century is not that bad. Testing the Welsh cartridge (7500-1) at 15 liters/min. and 10 ppm of VCM we obtained the following breakthrough times ( $T_5$ )\* for the two analyzers:  $T_5 = 162$  (Century) and  $T_5 = 120$  (Bendix) (see Experiments #33 and #63). Previously we had determined a 12% deviation in determining  $T_5$  with the Century analyzer.

In Table I, we have analyzed the Welsh 7500-1 cartridge at 30 l/min. and 10 ppm two times (#64 and #71) with the Bendix analyzer. The average  $T_0$  is  $50 \pm 4$  minutes which represents an 8% deviation. In our next report we will broaden the data base on this deviation analysis but reproducibility seems better with the Bendix instrument.

## Effect of Rate on Breakthrough Time

Comparing experiments #63 and #64 a significant decrease in  $T_0$  (initial breakthrough) takes place when the rate is increased from 15 l/min. to 30 l/min. A number of people have requested that more experiments be carried out at the 15 l/min. rate rather than the 30 l/min. rate. While the information obtained at 15 l/min. is of interest, it should be remembered that in our approach we correlate to the OSHA standard when we test at 30 l/min. not at 15 l/min. Since final acceptance of any device is based on the OSHA standard, most of our testing should be in the 30 l/min. range (or whatever rate best correlates to the standard).

## $T_1$ Values

Our initial data involving the Welsh cartridge at 10-20 ppm (30 l/min.) indicates that  $T_1$  is reached between 1 and  $1\frac{1}{2}$  hours. Although we have not yet

\*  $T_5$  is defined as the time to .5 ppm VCM/

determined  $T_1$  at 50 ppm, previous work with the Century analyzer at 50 ppm indicates a  $T_1 \approx 41$ . We believe this value is high, again due to the inherent problems with the Century analyzer at these low levels. Nevertheless in terms of the problem, the values ( $T_1$ ) indicate the approximate life-time of the Welsh cartridge. If the concern is worker exposure to 1 ppm of VCM, the Welsh cartridges exhibit a life of  $\frac{1}{2}$  to  $1\frac{1}{2}$  hours depending on the concentration of VCM in the atmosphere.

#### Welsh Canisters

In our last report we showed the significant increase in protection offered by the Welsh canister (7800-1M). At 30 l/min. and 100 ppm,  $T_5$  was reached after 11 hours. Recent studies with this canister (Experiment #70) indicate that initial breakthrough,  $T_0$ , at 10 ppm and 30 l/min is almost 17 hours and  $T_1$  is not reached until  $\sim 20$  hours. To date we have seen nothing that approaches the performance of the Welsh canister.

#### Other Adsorbants

A number of other adsorbants involving a number of principles of chemistry were tried. Nothing, so far evaluated, approached the effectiveness of carbon in scavenging VCM. In our last report we found that the coconut charcoal was not as effective as the petro-charcoal. Since that report, Harvard has also tested the coconut charcoal in their apparatus and have arrived at the same conclusion. Thus at this time, coconut charcoal offers no real advantage over the more abundant petroleum based charcoal.

#### Future Studies

We will continue our studies along the following lines:

- (1) determine reproducibility ( $T_0$ ,  $T_{.5}$ ,  $T_1$ ) at the low (5-20 ppm) exposure concentration,
- (2) follow the Harvard work now in progress in which engineering redesign experiments with the entire masks are underway,
- (3) continue to evaluate new adsorbants, and
- (4) evaluate the standard cartridges and canisters at low levels of VCM (1-5 ppm).

  
M. M. O'Mara

ch

Attachment

20224003

BFG02472

Table 1

## Summary of VCM Adsorption Data Obtained with the VCM Flow Chamber

| Experiment No.       | Experiment Involving                       | Flow Rate l/min. | VCM Concentration ppm | T <sub>5</sub> <sup>①</sup> (minutes)                               |
|----------------------|--------------------------------------------|------------------|-----------------------|---------------------------------------------------------------------|
| 31, 32 <sup>③</sup>  | A.G.S. <sup>②</sup>                        |                  |                       |                                                                     |
| 33                   | Welsh 7500-1                               | 15               | 10                    | T <sub>.5</sub> = 162; T <sub>5</sub> = 278                         |
| 34                   | Welsh 7500-1L                              | 15               | 10                    | T <sub>.5</sub> = 291                                               |
| 35 - 39              | A.G.S.                                     |                  |                       |                                                                     |
| 40                   | MSA Cartridge 44135                        | 30               | 100                   | 13.0                                                                |
| 41                   | Willson R-13                               | 30               | 100                   | 0.0 <sup>④</sup>                                                    |
| 42                   | Willson R-21                               | 30               | 100                   | 57.0                                                                |
| 43 - 46 <sup>⑤</sup> | calcium carbonate absorbant                | 30               | 100                   | all 0.0                                                             |
| 47                   | repeat of #42 (R-21)                       | 30               | 100                   | 46.5                                                                |
| 48 - 53              | A.G.S.                                     |                  |                       |                                                                     |
| 54                   | MSA Cartridge 459315                       | 30               | 50                    | 32.0                                                                |
| 55                   | MSA Cartridge 459315                       | 30               | 100                   | 25.0                                                                |
| 56                   | Willson R-25                               | 30               | 100                   | 11.0                                                                |
| 57 - 61 <sup>⑤</sup> | TiO <sub>2</sub> , Lead Acetate absorbants | 30               | 100                   | All 0.0                                                             |
| 62 <sup>⑥</sup>      | Welsh 7500-1                               | 15               | 20                    | data in error; will be repeated                                     |
| 63                   | Welsh 7500-1                               | 15               | 10                    | T <sub>0</sub> = 98, T <sub>.5</sub> = 120; T <sub>1</sub> = 148    |
| 64                   | Welsh 7500-1                               | 30               | 10                    | T <sub>0</sub> = 54, T <sub>1</sub> = 92                            |
| 65                   | Welsh 7500-1                               | 30               | 20                    | T <sub>0</sub> = 35, T <sub>1</sub> = 57; T <sub>5</sub> = 77       |
| 66 <sup>⑤</sup>      | Various carbon filters containing mixtures | 30               | 100                   | 13.0                                                                |
| 67 <sup>⑤</sup>      | of carbon and other adsorbants; #67 is     | 30               | 100                   | 32.0                                                                |
| 68 <sup>⑤</sup>      | the control containing                     | 30               | 100                   | 12.0                                                                |
| 69 <sup>⑤</sup>      | <u>only</u> carbon.                        | 30               | 100                   | 0.0                                                                 |
| 70                   | Welsh canister, 7800-1M                    | 30               | 10                    | T <sub>0</sub> = 1010, T <sub>1</sub> = 1220, T <sub>3</sub> = 1335 |
| 71                   | Welsh cartridge 75001 (repeat of #64)      | 30               | 10                    | T <sub>0</sub> = 46, T <sub>1</sub> = 81                            |

① T<sub>5</sub> is the time (in minutes) in which the concentration of VCM downstream from the cartridge becomes 5 ppm.

② Analytical Gas Standard.

③ Runs 31 to 61 were made with the Century O.V.A.

④ 0.0 means immediate breakthrough; no VCM adsorption was evident.

⑤ Materials submitted by L. Chandler for evaluation as VCM adsorbants.

⑥ Runs 62 - 71 and all future experiments were made with our new Bendix Total Hydrocarbon Analyzer.

20224004

BFG02473