

TABLE 1. ANALYSIS OF TETRACHLOROPHTHALIC ANHYDRIDE

<u>Sample</u>	<u>Cl₂</u>	<u>Cl₃</u>
Tetrathal #1	ND	ND
Tetrathal #2	ND	ND
Tetrathal #3	ND	ND
Tetrathal #4	ND	ND
Tetrathal #5	ND	ND
Tetrathal #5 (replicate)	ND	ND
Tetrathal #6	ND	ND
Tetrathal #7	ND	ND
Tetrathal #8	ND	ND
Tetrathal #9	ND	ND
Tetrathal #10	ND	ND
Tetrathal #11	ND	ND
Tetrathal #11 (replicate)	ND	ND
Tetrathal #12	ND	ND
Method Blank #1	ND	ND
Method Blank #2	ND	ND
Method Detection Limit	1	1
Spike Level	25	28
Tetrathal #1 (high spike)	7.7	14
Recovery %	31	50
Spike Level	2.6	28
Tetrathal #3 (low spike)	1.0	1.9
Recovery %	38	68
Spike Level	26	29
Tetrathal #8 (high spike)	16	17
Recovery %	62	59
Spike	2.5	2.8
Tetrathal #9 (low spike)	1.2	<22
Recovery %	48	-

SUBJECT TO REVIEW

CONFIDENTIAL

FOR POLYCHLORINATED DIBENZO-P-DIOXINS (PCDDs)

ng PCDDs/gm Sample (ppb)				
Cl ₄	Cl ₅	Cl ₆	Cl ₇	Cl ₈
ND	ND	9.7	77	190
ND	ND	ND	5.4	99
ND	ND	ND	5.1	27
ND	ND	4.6	25	57
ND	ND	ND	8.0	150
ND	ND	ND	4.4	74
ND	ND	1.3	9.0	530
ND	1.8	4.4	20	63
ND	ND	ND	6.8	390
ND	1.8	6.0	28	65
ND	16	82	210	87
ND	ND	4.5	35	110
ND	ND	5.5	39	130
1.5	14	43	110	250
ND	ND	ND	ND	ND
ND	ND	ND	ND	ND
1	1	1	1	1
20	24	23	25	20
11	13	24	101	250
55	54	62	-	-
2.1	2.5	2.4	2.6	2
1.5	1.6	2.4	8.3	29
71	64	100	-	-
21	25	24	26	21
17	19	23	38	790
81	76	96	120	-
2.0	2.4	2.3	2.5	2.0
1.5	3.9	9.8	41	87
75	88	165	-	-