

**Table 4. Fibres - as percentage of total particles
 observed**

Sample	Fibre proportion - %	
	Un-Incinerated	Incinerated
Brake lining material	28	12.3
Brake drum dust	0.6	1.6
Air-borne dust	-	1.3

Table 5. Analysis of Brake drum dust

Sample	Electron diffraction microscopy	X-ray diffraction (normal specimen)	X-ray diffraction (extracted specimen)
1.Anglia Van	Chrysotile present	Iron & quartz present. No chrysotile detected.	Less than 5% chrysotile, possibly 0.1% to 1%.
2.Cortina Mk.II	"	"	Less than specimen 1.
3.Anglia car	"	"	As specimen 1.