

P5

WRITTEN BY: OPERATORS
APPROVED BY: SW
DATE: 06/29/92

PRIMING A LIFT STATION PUMP

PAGE 1 OF 1

OPERATOR'S NAME: _____

DATE: _____

CHECK	ACTION STEPS (Capital letters) and Comments (Small letters)
-------	---

- | | |
|-------|---|
| _____ | 1. CHECK THE PUMP TO BE SURE IT IS PROPERLY ASSEMBLED. |
| _____ | 2. OPEN THE 1" KYNAR BLEED ON THE DISCHARGE. CLOSE THE DISCHARGE VALVE. |
| _____ | 3. TURN THE SHAFT ON THE PUMP TO BE SURE IT IS NOT FROZEN. |
| _____ | 4. OPEN PRIMING WATER TO THE SUCTION POT.
Note: Make sure the seal is not leaking. The pump will not hold the prime with a leaking seal. |
| _____ | 5. START UP THE PUMP ON MANUAL AND PUMP OUT OF THE KYNAR BLEED. |
| _____ | 6. START CLOSING OFF THE PRIMING WATER AND WATER THE KYNAR BLEED TO BE SURE THE PUMP IS HOLDING PRIME. |
| _____ | 7. WHEN THE PUMP IS PRIMED, OPEN THE DISCHARGE VALVE AND CLOSE THE DISCHARGE BLEED. |
| _____ | 8. RETURN THE SWITCH TO AUTOMATIC |

SL 010734

CONFIDENTIAL:
Subject to Protective Order
of 14th Judicial District Court
No. 91-1145