

Monsanto

MONSANTO COMPANY / DAYTON LABORATORY / DAYTON, OHIO 45407

AUTHORS: B. M. Hughes
TITLE: ANALYSIS FOR INCIDENTAL PCB'S IN VARIOUS PRODUCTS

REPORT NO.: MDA-504
COPY NO.: 1

ESC/DAYTON
(Department/Section)

45068

ANALYTICAL
(Type of Report)

REPORT NO.: MDA-504

JOB/PROJECT NO.: 484.3110

DATE: 18 July 1984

PERIOD COVERED:

TITLE: ANALYSIS FOR INCIDENTAL PCB'S IN VARIOUS PRODUCTS

AUTHORS: B. M. Hughes

ABSTRACT: Samples of various products from the Chocolate Bayou Plant were analyzed for possible concentrations of PCB's. The results of these analyses are shown in this report.

TECHNICAL APPROVAL:

J. M. Brooks (Hain)
J. M. Brooks
Senior Research Group Leader

APPROVED BY:

R. F. Ivory
R. F. Ivory
Environmental Sciences Center
Service Project Manager

APPROVAL DATE:

7-18-84

RESTRICTED DISTRIBUTION

RESTRICTED DISTRIBUTION: (see over)

COMPANY CONFIDENTIAL

This document is the property of Monsanto Company and the recipient is responsible for its safekeeping and disposition. It contains CONFIDENTIAL INFORMATION which must not be reproduced, revealed to unauthorized persons or sent outside Monsanto Company without proper authorization.

MONS 022972

DISTRIBUTION

COPY NUMBER		ABSTRACT ONLY
1	J. N. Blanchard	1200
2	R. B. Gray	1200
3	B. M. Hughes	1250
4	R. F. Ivory	1250
5	Central Files	1250
6	Technical Reports Library R2C	

H. A. Woltermann

NOTE: Distribution of this report is restricted. Requests for additional copies should be made through the principal contact at the Monsanto location involved or the Manager, Environmental Sciences Center, Dayton Laboratory, Dayton, Ohio.

ACKNOWLEDGEMENT

Contributions of the following Dayton Laboratory personnel to this project are gratefully acknowledged:

Analyses: B. M. Hughes
D. McKenzie
B. Williams

COMPANY CONFIDENTIAL

ANALYSIS REPORT

DATE: July 6, 1984

LOG NUMBER: 1-84-04-10-01
1-84-04-11-01
1-84-04-12-02

PROJECT NO: 494.31118

TO: Chocolate Bazaar/IVORY

FROM:

Environmental Sciences Center
Monsanto Company/Dayton Laboratory
1515 Nicholas Road
Dayton, Ohio 45416

Phone No: (513) 266-3411

Title: Analysis of Incidental PCBs in Various Products

Standard Sampling Method Note: Samples supplied by customer

Standard Extraction Method Note: PCEx27, PCEx10

Standard Analysis Method Note: MSALC

Final Report File Note: A31118

Table File Note: B31118, C31118, D31118, E31118, F31118, G31118, H31118
I31118

Tables 1 through 8 summarize Incidental PCB Results for the analysis of various Chocolate Bazaar Plant products.

Also included are:

- 1) A brief explanation of the tables.
- 2) Summaries of the above referenced extraction and analysis methods.
- 3) Analysis request information generated for this project.
- 4) A brief description of my interpretation of the Incidental PCB regulation.
- 5) A copy of the ESC/UAQ GLP Manual.

PLEASE NOTE:

If the results shown in the tables demonstrate that these products contain no quantifiable Incidental PCBs. However Tables 6 and 7 show that the extraction method used in the analysis of A-215 d6 D/H, A-230 T23-1, and A-228 d6 S/D destroys CL1-BP through CL3-BP congeners and therefore

MONS 022974

these three products must be reanalyzed for these three classes of compounds. Due to the high stability of the sample matrix (which consists primarily of linear alkyl benzenes), these three products may not be analyzable for CL1-SP through CL3-SP with LODs of 1 ug/g. Incidental PCBs should be analyzed in the starting materials used to produce these three products in order to circumvent these problems.

ANALYST(S): B. Mason Hughes, David McKenzie and Barbara Williams

ANALYST APPROVAL: B. Mason Hughes

MONS 022975

Table 1. Results of Incidental PCB Analyses.

Project No: 404.31118

Date: July 6, 1984

Sample Identification				
Therminol VP-1 Tank 5B75				
Therminol VP-1 (Duplicate)				
Congener Class	Analytical Method	LOQ(a) (ug/g)	Concentration (ug/g)	
CL1-BP	MSAND?	1(N)	NQ(b)	NQ
CL2-BP	"	"	"	"
CL3-BP	"	"	"	"
CL4-BP	"	"	"	"
CL5-BP	"	"	"	"
CL6-BP	"	"	"	"
CL7-BP	"	"	"	"
CL8-BP	"	"	"	"
CL9-BP	"	"	"	"
CL10-BP	"	"	"	"

Surrogate Spiking Compound	Amount Added(ug/g)	Recovery (%)	
3,4,3',4'-CL4-06	1.0	78	89

Documentation

ESC Extraction Method	PCEX10	PCEX10
Date of Extraction	6/20/84	6/20/84
Sample Amount Extracted (g)	1.0940	1.0633
Extract Final Volume (ml)	1.0	1.0
Extract Dilution	1:1	1:1
ESC Extract or Sample Number	PCB-461	PCB-462
Date of CGC/MS Analysis	6/29/84	6/29/84
MS FRN	19491,19496	19492,19497

Footnotes:

- (a) LOQ - Limit of Quantitation in ug/g. Signal-to-noise ratio is greater than 10 when this amount is analyzed using the above referenced Analytical and Extraction Methods. The following letters indicate how this value was determined:
 E - estimated from PCB congener standard analyzed under the same conditions.
 N - measured from native spiking of sample matrix.
 S - estimated from surrogate spiking of sample matrix.
 V - measured in validation experiments of similar sample matrix.
 (b) NQ - Not Quantifiable. The congener concentration is below the LOQ value.

Table stored in file: B31118:MM:19

Analyst(s): B. Mason Hughes and David McKenzie

Analyst Approval: B. Mason Hughes

MONS 022976

Table 2. Results of Incidental PCB Analyses.

Project No: 484.31110

Date: July 6, 1984

Sample Identification				
Diphenyl Oxide Tank 5873		Method Blank (Thermalol + DPO)		
Congener Class	Analytical Method	LOQ(a) (ug/g)	Concentration (ug/g)	
CL1-BP	MSAN-3	1(N)	NQ(b)	NC
CL2-BP	"	"	"	"
CL3-BP	"	"	"	"
CL4-BP	"	"	"	"
CL5-BP	"	"	"	"
CL6-BP	"	"	"	"
CL7-BP	"	"	"	"
CL8-BP	"	"	"	"
CL9-BP	"	"	"	"
CL10-BP	"	"	"	"

Surrogate Spiking Compound	Amount Added(ug/g)	Recovery (%)
3,4,3',4'-CL4-d6	1.0	79
		95

Documentation

ESC Extraction Method	PCEX10	PCEX10
Date of Extraction	6/20/84	6/20/84
Sample Amount Extracted (g)	1.0510	0.0
Extract Final Volume (ml)	1.0	1.0
Extract Dilution	1:1	1:1
ESC Extract or Sample Number	PCB-463	PCB-466
Date of GC/MS Analysis	6/29/84	6/29/84
MS FRN	19481,19498	19482,19499

Footnotes:

- (a) LOQ - Limit of Quantitation in ug/g. Signal-to-noise ratio is greater than 10 when this amount is analyzed using the above referenced Analytical and Extraction Methods. The following letters indicate how this value was determined:
 E - estimated from PCB congener standard analyzed under the same conditions.
 N - measured from native spiking of sample matrix.
 S - estimated from surrogate spiking of sample matrix.
 V - measured in validation experiments of similar sample matrix.
 (b) NQ - Not Quantifiable. The congener concentration is below the LOQ value.

Table stored in file: C31110:MM:19

Analyst(s): B. Mason Hughes and David McKenzie

Analyst Approval: B. Mason Hughes

MONS 022977

Table 3. Results of Incidental PCB Analyses.

Project No: 484.31118

Date: July 6, 1984

Sample Identification					
		Formaldehyde Tank 8302	Formaldehyde (Duplicate)	Method Blank (Formaldehyde)	
Congener Class	Analytical Method	LOQ(a) (ug/g)	Concentration (ug/g)		
CL1-BP	MSA433	1(N)	NQ(b)	NQ	NQ
CL2-BP	"	"	"	"	"
CL3-BP	"	"	"	"	"
CL4-BP	"	"	"	"	"
CL5-BP	"	"	"	"	"
CL6-BP	"	"	"	"	"
CL7-BP	"	"	"	"	"
CL8-BP	"	"	"	"	"
CL9-BP	"	"	"	"	"
CL10-BP	"	"	"	"	"

Surrogate Spiking Compound	Amount Added(ug/g)	Recovery (%)		
3,4,3',4'-CL4-d6	1.0	83	93	141

Documentation

ESC Extraction Method	PCEX07	PCEX07	PCEX07
Date of Extraction	7/2/84	7/2/84	7/2/84
Sample Amount Extracted (g)	1.3494	1.1519	0.0
Extract Final Volume (ml)	1.0	1.0	1.0
Extract Dilution	1:1	1:1	1:1
ESC Extract or Sample Number	PCB-515	PCB-516	PCB-519
Date of CGC/MS Analysis	7/2,7/3	7/2,7/3	7/2,7/3
MS FWH	19532,19561	19533,19562	19534,19563

Footnotes:

- (a) LOQ - Limit of Quantitation in ug/g. Signal-to-noise ratio is greater than 10 when this amount is analyzed using the above referenced Analytical and Extraction Methods. The following letters indicate how this value was determined:
 E - estimated from PCB congener standard analyzed under the same conditions.
 N - measured from native spiking of sample matrix.
 S - estimated from surrogate spiking of sample matrix.
 V - measured in validation experiments of similar sample matrix.
- (b) NQ - Not Quantifiable. The congener concentration is below the LOQ value.

Table stored in file: D31118:RM:19

Analyst(s): B. Mason Hughes and David McKenzie

Analyst Approval: B. Mason Hughes

MONS 022978

Table 4. Results of Incidental PCB Analyses.

Project No: 484.31110

Date: July 6, 1984

Sample Identification				
NTA Lot A (sodium nitrilotriacetate)				
IDA Lot B (acid, no/bn, dry)				
Congener Class	Analytical Method	LOQ(a) (ug/g)	Concentration (ug/g)	
CL1-BP	MSANC3	1(N)	NQ(b)	NQ
CL2-BP	"	"	"	"
CL3-BP	"	"	"	"
CL4-BP	"	"	"	"
CL5-BP	"	"	"	"
CL6-BP	"	"	"	"
CL7-BP	"	"	"	"
CL8-BP	"	"	"	"
CL9-BP	"	"	"	"
CL10-BP	"	"	"	"

Surrogate Spiking Compound	Amount Added(ug/g)	Recovery (%)
3,4,3',4'-CL4-d6	1.0	86
136		

Documentation

ESC Extraction Method	PCEX07	PCEX07
Date of Extraction	6/22/84	6/22/84
Sample Amount Extracted (g)	1.1418	1.0889
Extract Final Volume (ml)	1.0	1.0
Extract Dilution	1:1	1:1
ESC Extract or Sample Number	PCB-467	PCB-468
Date of GC/MS Analysis	7/2,7/3	7/2,7/3
MS FRN	19516,194545	19517,19546

Footnotes:

- (a) LOQ - Limit of Quantitation in ug/g. Signal-to-noise ratio is greater than 10 when this amount is analyzed using the above referenced Analytical and Extraction Methods. The following letters indicate how this value was determined:
 E - estimated from PCB congener standard analyzed under the same conditions.
 N - measured from native spiking of sample matrix.
 S - estimated from surrogate spiking of sample matrix.
 V - measured in validation experiments of similar sample matrix.
 (b) NQ - Not Quantifiable. The congener concentration is below the LOQ value.

Table stored in file: E31110:RM:19

Analyst(s): B. Mason Hughes and David McKenzie

Analyst Approval:

B. Mason Hughes

MONS 022979

Table 5. Results of Incidental PCB Analyses.

Project No: 484.31118

Date: July 6, 1984

		Sample Identification			
		MMBA Tank 326T12-2 (all met feed suppl.)	MMBA (dup)	Method Blank (MMBA)	
Congener Class	Analytical Method	LOQ(a) (ug/g)	Concentration (ug/g)		
CL1-BP	MSAND3	1(N)	NQ(b)	NQ	NQ
CL2-BP	"	"	"	"	"
CL3-BP	"	"	"	"	"
CL4-BP	"	"	"	"	"
CL5-BP	"	"	"	"	"
CL6-BP	"	"	"	"	"
CL7-BP	"	"	"	"	"
CL8-BP	"	"	"	"	"
CL9-BP	"	"	"	"	"
CL10-BP	"	"	"	"	"

Surrogate Spiking Compound	Amount Added(ug/g)	Recovery (%)		
3,4,3'4'-CL4-d6	1.0	102	89	91

Documentation

ESC Extraction Method	PCEX07	PCEX07	PCEX07
Date of Extraction	6/22/84	6/22/84	6/22/84
Sample Amount Extracted (g)	1.1626	1.0227	0.0
Extract Final Volume (ml)	1.0	1.0	1.0
Extract Dilution	1:1	1:1	1:1
ESC Extract or Sample Number	PCB-469	PCB-470	PCB-476
Date of CGC/MS Analysis	7/2,7/3	7/2,7/3	7/2,7/3
MS PMN	19518,19547	19519,19548	19525,19553

Footnotes:

- (a) LOQ - Limit of Quantitation in ug/g. Signal-to-noise ratio is greater than 10 when this amount is analyzed using the above referenced Analytical and Extraction Methods. The following letters indicate how this value was determined:
 E - estimated from PCB congener standard analyzed under the same conditions.
 N - measured from native spiking of sample matrix.
 S - estimated from surrogate spiking of sample matrix.
 V - measured in validation experiments of similar sample matrix.
- (b) NQ - Not Quantifiable. The congener concentration is below the LOQ value.

Table stored in file: F31118:MM:19

Analyst(s): B. Mason Hughes and David McKenzie

Analyst Approval: B. Mason Hughes

MONS 022980

Table 6. Results of Incidental PCB Analyses.

Project No: 484.31110

Date: July 6, 1984

Sample Identification

A-215 d5 O/H

A-230 T23-1

Method Blank

Congener Class	Analytical Method	LOQ(a) (ug/g)	Concentration (ug/g)		
CL1-BP	MSANC3	-	NA(b)	NA	NA
CL2-BP	-	-	-	-	-
CL3-BP	-	-	-	-	-
CL4-BP	-	115	NQ(c)	NQ	NQ
CL5-BP	-	-	-	-	-
CL6-BP	-	-	-	-	-
CL7-BP	-	-	-	-	-
CL8-BP	-	-	-	-	-
CL9-BP	-	-	-	-	-
CL10-BP	-	-	-	-	-

Surrogate Spiking Compound	Amount Added(ug/g)	Recovery (%)		
3,4,3',4'-CL4-d5	1.0	63	123	86

Documentation

ESC Extraction Method	PCEX10	PCEX10	PCEX10
Date of Extraction	6/22/84	6/22/84	6/22/84
Sample Amount Extracted (ug)	1.01E3	1.01E3	1.0
Extract Final Volume (ml)	1.0	1.0	1.0
Extract Dilution	1:1	1:1	1:1
ESC Extract or Sample Number	PCB-474	PCB-476	PCB-483
Date of CGC/MS Analysis	7/2,7/3	7/2,7/3	7/2,7/3
MS FPN	19525,19554	19527,19555	19530,19559

Footnotes:

- (a) LOQ - Limit of Quantitation in ug/g. Signal-to-noise ratio is greater than 10 when this amount is analyzed using the above referenced Analytical and Extraction Methods. The following letters indicate how this value was determined:
 N - measured from native spiking of sample matrix.
 (b) NA - Not Analyzed. The ESC extraction method used in these analyses destroys CL-BP through CL3-BP congeners. Therefore no LOQ can be established for these compounds in these samples.
 (c) NQ - Not Quantifiable. The congener concentration is below the LOQ value.

Table stored in File: G31110:PM:19

Analyst(s): B. Mason Hughes and David McKenzie

Analyst Approval: B. Mason Hughes

MQNS 022981

Table 7. Results of Incidental PCB Analyses.

Project No: 484.31110

Date: July 6, 1984

Sample Identification				
A-228 de S/O				
A-228 de S/O (Duplicate)				
Congener Class	Analytical Method	LOQ(a) (ug/g)	Concentration (ug/g)	
CL1-BP	MSANCS	-	NA(b)	NA
CL2-BP	-	-	-	-
CL3-BP	-	-	-	-
CL4-BP	-	1.0	NA(c)	NA
CL5-BP	-	-	-	-
CL6-BP	-	-	-	-
CL7-BP	-	-	-	-
CL8-BP	-	-	-	-
CL9-BP	-	-	-	-
CL10-BP	-	-	-	-

Surrogate Spiking Compound	Amount Added(ug/g)	Recovery (%)	
3,4,5-tri-C12-CC	1.0	72	72

Documentation

ES: Extraction Method	PCE:10	PCE:10
Date of Extraction	6/22/84	6/22/84
Sample Amount Extracted (g)	1.055	1.055
Extract Final Volume (mL)	1.0	1.0
Extract Dilution	1:1	1:1
ESC Extract or Sample Number	PCB-479	PCB-480
Date of GC/MS Analysis	7/2,7/3	7/2,7/3
MS FWH	19526,19557	19526,19558

Footnotes:

- (a) LOQ - Limit of Quantitation in ug/g. Signal-to-noise ratio is greater than 10 when this amount is analyzed using the above referenced Analytical and Extraction Methods. The following letters indicate how this value was determined:
N - measured from native spiking of sample matrix.
- (b) NA - Not Analyzed. The ESC extraction method used in these analyses destroys CL-BP through CL3-BP congeners. Therefore no LOQ can be established for these compounds.
- (c) NQ - Not Quantifiable. The congener concentration is below the LOQ value.

Table stored in file: M01110:MM19

Analyst(s): B. Mason Hughes and David McKenzie

Analyst Approval: B. Mason Hughes

MONS 022982

Table B. Results of Incidental PCB Analyses.

Project No: 484.31110

Date: July 6, 1984

Sample Identification					
KSL 50		SAX G		SA	
Lot CBC 9029		Lot CBO 031037		Lot CBC 102511	
Congener Class	Analytical Method	LOQ(a) (ug/g)	Concentration (ug/g)		
CL1-BP	MSAND3	1(N)	NQ(b)	NQ	NQ
CL2-BP	"	"	"	"	"
CL3-BP	"	"	"	"	"
CL4-BP	"	"	"	"	"
CL5-BP	"	"	"	"	"
CL6-BP	"	"	"	"	"
CL7-BP	"	"	"	"	"
CL8-BP	"	"	"	"	"
CL9-BP	"	"	"	"	"
CL10-BP	"	"	"	"	"
.....					
Surrogate Spiking Compound		Amount Added(ug/g)	Recovery (%)		
3,4,3'-4'-CL4-d5		1.0	89	154	142
.....					
Documentation					
ESC Extraction Method		PCEX07	PCEX07	PCEX07	
Date of Extraction		6/22/84	6/22/84	6/22/84	
Sample Amount Extracted (g)		1.0266	1.0382	1.0590	
Extract Final Volume (ml)		1.0	1.0	1.0	
Extract Dilution		1:1	1:1	1:1	
ESC Extract or Sample Number		PCB-471	PCB-474	PCB-475	
Date of CGC/MS Analysis		7/2,7/3	7/2,7/3	7/2,7/3	
MS FR#		19520,19549	19522,19551	19523,19552	

Footnotes:

- (a) LOQ - Limit of Quantitation in ug/g. Signal-to-noise ratio is greater than 10 when this amount is analyzed using the above referenced Analytical and Extraction Methods. The following letters indicate how this value was determined:
 E - estimated from PCB congener standard analyzed under the same conditions.
 N - measured from native spiking of sample matrix.
 S - estimated from surrogate spiking of sample matrix.
 V - measured in validation experiments of similar sample matrix.
- (b) NQ - Not Quantifiable. The congener concentration is below the LOQ value.

Table stored in file: 131110:RM:19

Analyst(s): B. Mason Hughes and David McKenzie

Analyst Approval: B. Mason Hughes

MONS 022983

DETAILED EXPLANATION OF INCIDENTAL PCB TABLES

In an effort to streamline reports generated by ESC on incidental PCBs present in a wide variety of materials, using a wide variety of techniques, Standard Extraction Methods (SEMs) and Standard Analysis Methods (SAMs) have been developed which can be easily interfaced with each other. An abbreviated form of these SEMs and SAMs has been stored on the Hewlett-Packard 3357-LAS computer system used by ESC. In an effort to communicate these details with customers of ESC, this information is supplied with each incidental PCB analysis. However, many projects involve a very small number of samples which are not necessarily the same matrix. Therefore, to reduce costs of generating reports for these small projects, major information on the technical details of an analysis are presented in tabular form within the same table which reports the data.

Each table includes a general title, ESC Project Number and Date on which the table was generated. The sample identification is the customer identification which was on the sample bottle. The next section of the table gives results for the particular PCB congener class listed. The level of quantitation (LOQ) using the Analytical and Extraction Methods shown in the table, is given for each congener class. This LOQ is determined in one of four ways and is described in the table footnotes.

The next section of the table deals with quality control used in each sample analysis. The surrogate spiking compound (if used) which is added to the sample before extraction and analysis, is listed, along with the amount added and % Recovery measured for each sample. The final section before the footnotes deals with how each sample was extracted and data documentation. The ESC Extraction Method, Date of Sample Extraction, Amount of Sample Extracted, Extract Final Volume, Extract Dilution and ESC Extract or Sample Number give critical extraction details of the analysis. The date of GC/MS analysis and the mass spectrometer file reference number (FRN) document how and when the extract or sample was analyzed and where the raw data is stored.

At the bottom of each table, analysts involved in extraction and analysis are listed, along with provisions for signature of the responsible analyst. This table format is both compact and precise. It was developed in an attempt to quickly and accurately generate data which the customer can quickly and accurately evaluate. It should include all required information for certification. If there are any suggestions concerning this format, please contact me at extensions 396, 209, or 409.

B. Mason Hughes
Senior Research Specialist

Environmental Sciences Center
Monsanto Company
Dayton Laboratory
1515 Nicholas Road
Dayton, Ohio 45407

File: INEXPT:MM:SP

MONS 022984

The following pages describe Standard Extraction Methods and Standard Analysis Methods used for this project.

MONS 022985

ESC Standard Analysis Method (SAM)
TITLE: Organic Compounds in Solvents

ESC Standard Analysis Method No:
MSAM03

ANALYTICAL INSTRUMENT AND MODE OF OPERATION: HP-5985B Capillary GC/MS-Selected Ion Monitoring with Revision-E Multi-drive software.

Typical Run Time: 3 - 40 min.
Typical Multiplier Voltage: 1000 - 2000 eV
Typical Dwell Times: 200 - 500 msec/mass
Maximum # of Masses: 20
Electron Energy: 70 eV

TYPICAL ANALYTE	TYPICAL INSTRUMENT LEVEL OF DETECTION (LOD) (ug/ml)	TYPICAL PRECISION @ 10X LOD (%)	TYPICAL ACCURACY @ 10X LOD (%)
-----------------	---	---------------------------------	--------------------------------

Organic Compounds eluting between

toluene and n-C34-ane 0.01 - 0.1

30

30

INTERFERENCES AND LIMITATIONS: Analyte characteristic mass must be chromatographically resolved from other eluting compounds which produce the same mass.

CHROMATOGRAPHIC COLUMN: 30-meter fused silica J&W DB-5 (0.25 um) with wide bore (0.32 mm)

COLUMN TEMPERATURE PROGRAM: 50(4)/8/30

INJECTION TYPE: Splitless

CALIBRATION AND STANDARDIZATION:

Quantitative: Use internal standard quantitation technique and calibrate instrument response factors from standard solutions of analytes of interest.

Qualitative: When multiple characteristic masses are monitored for a given analyte, the ratio of characteristic mass responses must be within 20% of those for the authentic standard. For PCB analyses, the characteristic masses which are monitored are the molecular ion containing all 35-Cl isotopes and the molecular ion containing one 37-Cl isotope. Since the above referenced analytical instrument can monitor no more than 20 masses in a single analysis, incidental PCB analyses require two injections of each sample in order to analyze from CL-biphenyl through CL10-biphenyl isomers, anthracene-d10 and the surrogate spiking compound. The following summarizes the masses and approximate retention time regions monitored in these two capillary GC/MS-SIM analyses.

ANALYSIS #1

Analyte	Masses	Retention Times (minutes)
-----	-----	-----
CL-BP isomers, anthracene-d10	188,190	11 - 21
CL2-BP isomers	222,224	11 - 21
3,4,3',4'-CL4-BP surrogate	296,298	21 - 28
CL5-BP isomers	323,325,9	21 - 28
CL7-BP isomers	391,8,393,8	28 - 39
CL9-BP isomers	461,6,463,6	28 - 39

ANALYSIS #2

anthracene-d10	186,188	14 - 23
CL3-BP isomers	255,9,257,9	14 - 23
CL4-BP isomers	289,8,291,8	23 - 29
CL6-BP isomers	357,8,359,8	23 - 29
CL8-BP isomers	427,7,429,7	29 - 39
CL10-BP isomers	497,6,499,6	29 - 39

 CALCULATIONS: Analyte concentration = (Analyte area)/(Analyte RRF)(area of IS)

where: Analyte area is the characteristic mass area of the analyte.
 RRF is the relative response factor for the analyte.
 IS is the internal standard and is usually anthracene-d10.

RRF = (analyte area in standard)/(conc. of analyte)(area of IS)

PCB concentrations are calculated in one of two ways:

1) If an Aroclor formulation can be identified from the patterns of PCB isomers, selected PCB isomers or classes of isomers (i. e. all CL4-biphenyl isomers) are used to quantify the Aroclor concentration. Relative Response Factors are calculated using the concentration of the total Aroclor formulation in the above RRF equation.

2) If no unique Aroclor formulation is present, then the total PCB concentration is calculated by using standard solutions containing known amounts of chlorobiphenyl through decachlorobiphenyl isomers to calculate Relative Response Factors in the above RRF equation. The RRFs for the corresponding PCB isomer classes are used to calculate total PCB isomer concentrations in unknown samples.

 SAFETY PRECAUTIONS: See PCB handling protocols in laboratory safety manual.

 DATES OF METHOD CREATION AND METHOD UPDATES: 12/9/83

ESC Standard Extraction Method (SEM)
TITLE: PCBs in matrices containing
acidic groups

ESC Standard Extraction Method No:
PCEN07

MATRIX (X), (CES):

carboxylic acids, chlorophenols, and
any alkyl or aromatic compound
that is acidic in nature

**TYPICAL SAMPLE
SIZE**
(g)

0.5 - 5g

**TYPICAL EXTRACT
VOLUME**
(ml)

1 - 10

TYPICAL ANALYTES: A1242, A1248, A1254, A1260, and PCB isomers mono- through deca-
chloro-biphenyl.

INTERFERENCES: Any electron capturing
species in the retention time region
of trichlorobiphenyl isomers through
octachlorobiphenyl isomers for ECAN01
and ECAN02. Any species in the
appropriate retention time region
which give the same relative charac-
teristic mass responses as PCB isomers
for MSAN03.

**TYPICAL
SURROGATES**

pentachlorobenzene
2,4,6-trichloro-
biphenyl
3,3',4,4'-tetrachloro-
biphenyl-d6

**TYPICAL
RECOVERIES (%)**

50 - 120
50 - 120
50 - 120

APPARATUS AND MATERIALS:

Burdick and Jackson hexane for sample extraction.
Potassium hydroxide solution (2 M) to ionize acidic functional groups.
Distilled deionized water for dilution of the potassium hydroxide.
Potassium hydroxide pellets.
Silica gel columns impregnated with potassium permanganate, sulfuric acid,
and potassium hydroxide.
Disposable glassware.

LIMITATIONS: Method applies only to matrices which are hydrolyzable using a
2M potassium hydroxide solution. EC SAMs are valid for CL3-BP through CL10-
BP. MS SAMs are valid for all PCBs from CL1- through CL10-BP.

SAFETY PRECAUTIONS: See PCB handling protocols in laboratory safety manual.

DATES OF METHOD CREATION AND UPDATES: 5/14/84, 6/20/84

FLOW SHEET PCF807
FOR ESC EXTRACTION METHOD PCEX07

SAMPLE ID: ----- MRC EXTRACT # -----

----- LOG NO: -----

EXTRACTION DATE and TIME: -----

WEIGH OUT SAMPLE INTO A 40
ML VIAL

[]

WEIGHT SAMPLE (1 g) -----

SURROGATE SPIKE OF SAMPLE

[]

SPIKE -----

ADD 15 ML 2 N KOH SOLUTION
TO VIAL

[]

[] RINSE COLUMN WITH 2 X 20 ML
HEXANE

SHAKE UNTIL SOLID IS INTO
SOLUTION

[]

CLEAN-UP
COLUMN DESCRIPTION:
25 ML DISPO PIPET

EXTRACT 3 X 5 ML HEXANE

[] [] [] []

1 cm Na₂SO₄
2 4

REDUCE SAMPLE VOLUME TO
1-2 ML WITH NITROGEN AND
APPLY TO COLUMN QUANTITATIVELY.

[]

4 cm 1% POTASSIUM
PERMANGANATE
SILICA GEL

ELUTE WITH 30 ML HEXANE

[]

1 cm SILICA GEL

NITROGEN BLOW DOWN TO 1 ML

[]

4 cm ACID SILICA
GEL

1 cm SILICA GEL

4 cm BASE SILICA
GEL

EXTRACT NO: -----

DATE/TIME COMPLETED -----

GLASS WOOL

ANALYST: -----

ESC JOB NO: -----

MONS 022989

ESC Standard Extraction Method (SEM)
TITLE: PCBs in biphenyl and aromatic
ethers

ESC Standard Extraction Method No:
PCEX10

MATRIX (X) (CES):

soil and oil mixtures

TYPICAL SAMPLE
SIZE
(g)

0.5 - 1g

TYPICAL EXTRACT
VOLUME
(ml)

1 - 10

TYPICAL ANALYTES: A1242, A1248, A1254, A1260, and PCB isomers mono through deca-
chloro biphenyl

INTERFERENCES: Any electron capturing
species in the retention time region
of trichlorobiphenyl isomers through
octachlorobiphenyl isomers for ECAN01
and ECAN02. Any species in the
appropriate retention time region
which give the same relative charac-
teristic mass responses as PCB isomers
for MSAN03.

TYPICAL
SURROGATES

pentachlorobenzene
2,4,6-trichloro-
biphenyl
3,3',4,4'-tetra
chloro biphenyl

TYPICAL
RECOVERIES (%)

50 - 120
50 - 120
50 - 120

APPARATUS AND MATERIALS:

Burdick and Jackson hexane for extraction solvent

Sulfuric acid fuming (15%) to oxidize the matrix

Sulfuric acid for acid wash

Sodium sulfate to dry the sample matrix

Silica gel columns impregnated with potassium permanganate, sulfuric acid,
and potassium hydroxide.

Disposable glassware.

50 mL centrifuge tubes

LIMITATIONS: Method applies only to matrices which do are hydrolyzable using
a fuming sulfuric acid (15%) solution. EC SAMs are valid for CL3-BP through
CL10-BP. MS SAMs are valid for all PCBs from CL1-BP through CL10-BP.

SAFETY PRECAUTIONS: See PCB handling protocols in laboratory safety manual.

DATES OF METHOD CREATION AND UPDATES: 6/20/84

**FLOW SHEET PCFS10
FOR ESC EXTRACTION METHOD PCFX10**

SAMPLE ID: ----- MRC EXTRACT # -----
----- LOG NO: -----

EXTRACTION DATE AND TIME: -----

WEIGH OUT SAMPLE INTO A 40
ML VIAL [] WEIGHT SAMPLE (1 g) -----

SURROGATE SPIKE OF SAMPLE [] SPIKE -----

ADD 10 ML HEXANE [] -----

ADD 5 ML FUMING SULFURIC ACID
(15%) SHAKE FOR 30 SECONDS AND []
REMOVE HEXANE BY 1 MINUTE

PIPET HEXANE ALONG WITH 2 X 5 ML
RINSES (DO NOT SHAKE) INTO A 40 ML
VIAL []

WASH EXTRACT WITH 80% SULFURIC ACID []
REMOVE EXTRACT QUANTITATIVELY INTO
A 50 ML CENTRIFUGE TUBE

REDUCE SAMPLE VOLUME TO []
3-5 ML WITH NITROGEN AND
APPLY TO COLUMN QUANTITATIVELY

ELUTE WITH 40 ML HEXANE []

NITROGEN BLOW DOWN TO 1 ML []

[] RINSE COLUMN WITH 2 X 20 ml
HEXANE

CLEAN-UP
COLUMN DESCRIPTION:
25 ML DISPO PIPE:

1 cm NA SC
2 "

4 cm 1% POTASSIUM
PERMANGANATE
SILICA GEL

1 cm SILICA GEL

4 cm ACID SILICA
GEL

1 cm SILICA GEL

4 cm BASE SILICA
GEL

XXXX/
\\

GLASS WOOL

EXTRACT NO: -----

DATE/TIME COMPLETED -----/-----

ANALYST: ----- ESC JOB NO: -----

MONS 022991

The following pages describe Analytical Request information generated for this project.

MONS 022992

NRC ENVIRONMENTAL SCIENCES CENTER

ANALYSIS REQUEST

DATE: APRIL 10, 1984

LOG NO: 1-84-04-10-01

REQUESTER:

PROJECT NO:

CHOCOLATE BAYOU/IVORY

484.31118

REPORT RESULTS TO: FILES/MEES, IVORY, BROOKS

ANALYSIS REQUESTS SENT TO: FILES, IVORY, BROOKS, HUGHES

SAMPLE PICKUP BY: H. HUGHES

SAMPLE LOCATION: LAB 20, BUILDING 2

SAMPLE DESCRIPTION FOR 3 SAMPLES

SAMPLE IDENTIFICATION	NUMBER OF BOTTLES	ESC NUMBER(S)
THERMINOL VP-1 TANK SBT5	1	PCB-461, PCB-462-DUP, PCB-464-LS
FORMALDEHYDE TANK 8302	1	PCB-456, PCB-457-DUP, PCB-458-LS, PCB-459-MS, PCB-515, PCB-516-DUP, PCB-517-LS, PCB-518-MS, PCB-519
RERUN		PCB-463, PCB-465-MS
METHOD BLANK FOR RERUN		
DIPHENYL OXIDE TANK SBT3	1	PCB-466
METHOD BLANK FOR THERMINOL AND DIPHENYL OXIDE		
METHOD BLANK FOR FORMALDEHYDE		PCB-460

RECORDED BY: P. MUPP

REQUIRED ANALYSES: INCIDENTAL PCB'S

ANALYTICAL TECHNIQUES:

DATE
COMPLETED
7/6/84

X GC/EC (18)

QUALITATIVE: YES

SEMIQUANTITATIVE:

QUANTITATIVE: YES

REQUIRED QA/QC: DUPLICATE ANALYSIS AND HIGH AND LOW SPIKES

COMPLETION DATE REQUESTED:

COMMENTS: LS AND MS REPRESENT LOW AND HIGH NATIVE SPIKES, RESPECTIVELY

SAMPLE DISPOSITION:

X HOLD FOR 30 DAYS

MONS 022993

SAFETY PRECAUTIONS: SEE PCB PROTOCOLS

ANALYSIS REQUEST FILE NAME: AA31101L1

MONS 022994

MRC ENVIRONMENTAL SCIENCES CENTER

ANALYSIS REQUEST

DATE: APRIL 11, 1984

LOG NO: 1-84-04-11-01

REQUESTER:

CHOCOLATE BAYOU/IVORY

PROJECT NO:

484.31118

REPORT RESULTS TO: FILES/MEES, IVORY, BROOKS

ANALYSIS REQUESTS SENT TO: FILES, IVORY, BROOKS, HUGHES

SAMPLE PICKUP BY: M. HUGHES

SAMPLE LOCATION: LAB 28 BUILDING 2

SAMPLE DESCRIPTION FOR 3 SAMPLES

SAMPLE IDENTIFICATION:	NUMBER OF BOTTLES	ESC NUMBER(S):
MTA LOT A (SODIUM NITRILOTRIACETATE)	1	PCB-467
IDA LOT B (ACID, HIGH DRY)	1	PCB-468
MHBA TANK 326712-2 (ALIMET FEED SUPPLEMENT)	1	PCB-469, PCB-470, PCB-471
METHOD BLANK		PCB-476

RECORDED BY: P. HUPP

REQUIRED ANALYSES: INCIDENTAL PCBs

ANALYTICAL TECHNIQUES:

X GC/EC (18)	DATE COMPLETED 7/6/84
--------------	-----------------------------

QUALITATIVE: YES

SEMIQUANTITATIVE:

QUANTITATIVE: YES

REQUIRED QA/QC: DUPLICATE, METHOD BLANK AND HIGH AND LOW NATIVE SPIKES

COMPLETION DATE REQUESTED:

COMMENTS: SAMPLES WERE PROCESSED ALONG WITH THOSE LISTED ON AC3110 ANALYTICAL REQUEST SHEET DUE TO SIMILARITY OF COMPOUNDS (ALL WERE ORGANIC ACIDS OR SALTS). HIGH AND LOW NATIVE SPIKES ARE LISTED ON AC3110.

SAMPLE DISPOSITION:

X HOLD FOR 30 DAYS

SAFETY PRECAUTIONS: SEE SAFE LABORATORY PRACTICES

ANALYSIS REQUEST FILE NAME: AB3110:LI

MONS 022995

HRC ENVIRONMENTAL SCIENCES CENTER

ANALYSIS REQUEST

DATE: APRIL 12, 1984

LOG NO: 1-84-04-12-02

REQUESTER:

PROJECT NO:

CHOCOLATE BAYOU/IVORY

484.31118

REPORT RESULTS TO: FILES/NEES, IVORY, BROOKS

ANALYSIS REQUESTS SENT TO: FILES, IVORY, BROOKS, HUGHES

SAMPLE PICKUP BY: M. HUGHES

SAMPLE LOCATION: LAB 28 BUILDING 2

SAMPLE DESCRIPTION FOR 6 SAMPLES

SAMPLE IDENTIFICATION	NUMBER OF BOTTLES	ESC NUMBER(S)
A-215 D6 C/H	1	PCB-477
A-230 T23-1	1	PCB-478
A-228 D6 S/O	1	PCB-479, PCB-480-DUP PCB-481-LS, PCB-482-HS PCB-483
METHOD: BLANK		
KSL 50 LOT CBC 9029	1	PCB-471, PCB-472-LS PCB-473-HS
SAK-G LOT CBC 031037	1	PCB-474
SA LOT CBC 102511	1	PCB-475
METHOD BLANK:		PCB-476

RECORDED BY: P. HUPP

REQUIRED ANALYSES: PCB

ANALYTICAL TECHNIQUES:

DATE
COMPLETED
7/6/84

X GC/EC (18)

QUALITATIVE: YES

SEMIQUANTITATIVE:

QUANTITATIVE: YES

REQUIRED QA/QC: 10% DUPLICATES, 10% METHOD BLANKS, 10% HIGH AND LOW NATIVE SPIKES

COMPLETION DATE REQUESTED:

COMMENTS: SAMPLES WERE PROCESSED ALONG WITH THOSE LISTED ON ANALYTICAL REQUEST SHEET AB3110. DUPLICATE ANALYSIS FOR THE ORGANIC ACID SAMPLES ARE FOUND ON SHEET AB3110.

SAMPLE DISPOSITION:

X HOLD FOR 30 DAYS

MONS 022996

SAFETY PRECAUTIONS: SEE SAFE LABORATORY PRACTICES

ANALYSIS REQUEST FILE NAME: AC3110-11

MONS 022997

The following is a detailed discussion of the Incidental PCB Regulation.

MONS 022998

**Analysis of Incidental PCBs in Monsanto
Products, Waste Streams, Emissions
and Effluents of Closed and Controlled
Waste Manufacturing Processes**

B. Mason Hughes
Environmental Sciences Center
Monsanto Company/Dayton Laboratory
1515 Nicholas Road
Dayton, Ohio 45407

The October 21, 1982 Federal Register (Vol. 47, No. 204) contains a very extensive definition of PCB-containing products, waste streams, emissions and effluents from manufacturing processes and general descriptions of methods which should be used for these analyses. The purpose of this present report is to outline the approach taken by Monsanto's Environmental Sciences Center in supplying analytical data which can be used for certification of Monsanto products, waste streams, emissions and effluents.

In order for the material to be certified as not containing PCBs, the EPA set various levels of Quantitation (LOQ), below which a product, waste stream, emission or effluent could be certified to contain no PCBs. The LOQ is defined on the basis of the concentration per resolvable chromatographic peak. Quoting from page 46996 of the Federal Register, Vol. 47, No. 204, "This means that for a process to be eligible for exclusion under the closed and controlled waste process exclusion, no single peak on a gas chromatogram registers PCBs in excess of: ten micrograms per cubic meter in air emissions, 100 micrograms per liter in water effluents, and two micrograms per gram in products and uncontrolled waste streams." Therefore there are very specific definitions which Monsanto can apply to its products, waste streams, emissions and effluents which determine whether these materials may be eligible for exclusion. It is the goal of the Environmental Sciences Center to supply Monsanto plants with the proper data and documentation for this exclusion.

Capillary gas chromatography/electron impact mass spectrometry (GC/MS) is the instrumental technique which the Federal Register suggests should be used in the analytical method for PCB congener analysis. However for most Monsanto products, waste streams, air emissions and water effluents, this instrumental method must be used in conjunction with an extraction method in order to determine what levels of PCB congeners, if any, are present in these various materials. The remainder of this report will therefore deal with how ESC will implement this instrumental method for the analysis of PCBs in various types of samples.

In order to analyze a sample for PCBs, using GC/MS techniques, a representative sample of interest, or a representative extract of a sample of interest must be injected into the capillary chromatographic system. The presence and quantities of PCB congeners present are determined by comparing the PCB congener responses in the sample of interest with the

responses in an analytical standard containing at least one PCB congener for each of the ten chlorine classes (i. e. Cl1-biphenyl through Cl10-biphenyl). The analysis of Monsanto products and waste streams can be divided into two types of CGC/MS analyses. The first is for products and waste streams which can be chromatographically resolved from Cl1-biphenyl through Cl10-biphenyl congeners, when the product or waste stream is present at ten million times the levels of the PCB congeners. This first type of analysis only requires the sample to be injected into the CGC/MS instrument and PCB congener areas compared to standard PCB congener areas.

The second type of analysis applies to Monsanto products and waste streams which cannot be chromatographically resolved from PCB congeners and for air emission and water effluent samples. This second type of analysis must first isolate into a solvent all PCB congeners which are present in a representative sample of the product, waste stream, air or water sample. This extracting solvent can then be analyzed for PCB congeners as described above in the first type of analysis, since the extracting solvent is chosen to be chromatographically resolved from the PCB congeners of interest. Therefore an integral part of the PCB congener analysis revolves around the validation of the extraction method used to isolate the PCB congeners and validation of the CGC/MS method used to analyze extracts. In order for Monsanto plants to understand the data that is generated for incidental PCB certification, the following sections outline how data will be obtained and validated for the presence or absence of PCB congeners in various Monsanto materials.

Extraction of products, waste streams, air emissions and water effluents:

If samples of interest cannot be directly analyzed for PCBs using CGC/MS techniques, they must first be extracted with an appropriate solvent which can be analyzed for PCBs. This not only applies to the products or waste streams, but also to air samples or water samples which may contain large amounts of products and waste stream components. Two major property differences between PCBs and major compounds in various samples can be used to isolate PCB congeners into an appropriate extraction solvent. These are: 1) reactivity; and 2) water solubility. Low levels of quantitation for PCB congeners in samples which contain major components in the PCB congener elution region cannot easily be obtained unless these major components can be removed by their reactivity or water solubility. The inherent stability of PCB congeners and their high affinity for organic solvents and low water solubility are chemical and physical properties which can be exploited for this separation. However it is important to demonstrate that, during this isolation phase, PCB congeners have not been removed during the extraction. This is done in two ways. The first way involves the use of a surrogate compound which acts exactly like PCB congeners, yet is mass spectrometrically different. This is normally accomplished by using either deuterated PCB congeners or congeners which contain carbon-13 rather than carbon-12 in the biphenyl structure. These surrogate spiking compounds are added to each sample for which PCB congener extraction is required, and their recovery is reported along with any PCB congener detected. However this approach is valid only if one has isotopically labelled PCB congeners for each congener class. Since at this time there are no surrogate compounds for all classes of PCB congeners (i. e. Cl1-biphenyl through Cl10-biphenyl), a second type of extraction validation is normally used. This validation step involves adding at least one native PCB congener for Cl1-biphenyl through Cl10-biphenyl congeners and measuring the recoveries of each of these native congeners when the product, waste stream, air emission or water effluent is extracted. These native spiking studies should be performed on representative types of matrices to demonstrate the validity of the

results. If no previous data is available for recovery of all PCB congener types from a specific matrix, this native spike should be performed in order to validate the data being reported.

Since it is not anticipated that incidental PCB generation will be detected for Monsanto processes, it is imperative that the above quality control steps be conducted on each sample or for each sample matrix type in order to validate the fact that if PCB congeners had been present in the Monsanto samples, they would have been detected at the levels required by this regulation.

CGC/MS analysis of extracts, products and waste streams:

As mentioned above, sample extracts, products and waste streams can be injected directly into the CGC/MS analytical system if the major components do not elute in the retention time regions of the Cl1-biphenyl through Cl10-biphenyl congeners. Data quality of this analysis step is also demonstrated by similar approaches outlined above for sample extraction. In order to verify that the instrument is functioning properly for each sample injected, an internal standard is added to each extract, product or waste stream before it is injected into the CGC/MS system. Anthracene-d10 is usually used for this purpose. The absolute areas of the internal standard in the extract, product or waste stream analysis must be within 30% of the area of the internal standard which is added to the PCB congener analytical standard.

This analytical standard, containing Cl1-biphenyl through Cl10-biphenyl congeners, is analyzed under the same conditions as the extract, product or waste stream samples and from the instrument responses for the ten PCB congener classes, levels of detection and quantitation are determined and the amounts of each congener class (if greater than the LOQ) is reported. Ideally, each sample should also be analyzed after spiking with at least one native PCB congener in each congener class at the level of quantitation (LOQ) in order to verify that the LOQ concentration could be detected and quantified in the presence of sample interferences. This is done in order to show that the CGC/MS instrumental analysis is valid for the sample matrix of interest. However some products and waste stream samples are not miscible with solvents in which PCB congener classes have been prepared and therefore it is not always possible to analyze a native spike of all products and waste stream samples. This is not a problem with sample extracts, since the extracting solvent has been chosen to be compatible with surrogate and native spiking studies which occur in the sample extraction step, described above.

Quantitation and Identification of PCB Congeners:

Tables 1 and 2 show how the 209 PCB congeners are distributed among the Cl1-biphenyl through Cl10-biphenyl classes. In addition these tables show the characteristic masses and theoretical relative abundances for each of the ten congener classes. In order to routinely obtain analytical data with levels of detection on the order of 0.1 ug/ml per congener, the mass spectrometer detector is operated in the Selected Ion Monitoring mode (SIM). This mode is a screening mode and monitors at least two molecular ion characteristic masses over the elution time region of the corresponding PCB congener class for all ten congener classes.

PCB congeners are tentatively identified from the ratio of the peak areas of the two molecular ion chromatograms. If the ratio agrees within

30% of the experimental ratio obtained from the PCB congener standard analysis, and the two peaks maximize within two mass spectrometer scans, then the sample is reanalyzed while monitoring all masses of interest for positive identification of the PCB congener. If the peak area ratio does not agree within 30% of the experimental ratio for a particular PCB congener, then this response is not due to a PCB congener.

Summary:

The above approach allows for rapid, routine analyses of extracts and samples of interest. Since few positives are expected, adequate quality control involving the use of internal standards, native spikes and surrogate spikes will be used to validate that the data can be used for the certification of the absence of incidental PCBs in Monsanto products, waste streams, air emissions and water effluents of closed and controlled waste manufacturing processes.

Text File: INPC01:MM:SP

Table Files: INT901:MM, INT902:MM

Table 1. Characteristic masses and isotope patterns of the characteristic masses for chlorobiphenyl through pentachlorobiphenyl congeners.

Characteristic Masses	Number of Chlorines	PCB Congener Class (Number of Congeners)				
		CL1-BP (3)	CL2-BP (12)	CL3-BP (24)	CL4-BP (42)	CL5-BP (46)
152	0	x(-)	x(-)			
153	0	x(-)				
186	1	-		x(100)		
187	1		x(100)			
188	1	x(100)		x(32.4)		
189	1		x(32.4)			
190	1	x(32.4)		-		
220	2		-		x(100)	
222	2		x(100)		x(64.8)	
224	2		x(64.8)		x(10.5)	
226	2		x(10.5)		-	
253.9	3			-		x(100)
255.9	3			x(100)		x(97.2)
257.9	3			x(97.2)		x(31.5)
259.9	3			x(31.5)		-
287.8	4				-	
289.8	4				x(77.2)	
291.8	4				x(100)	
293.8	4				x(48.6)	
295.8	4				x(10.5)	
321.8	5					-
323.8	5					x(61.7)
325.8	5					x(100)
327.8	5					x(64.8)
329.8	5					x(21)

Table 2. Characteristic masses and isotope patterns of the characteristic masses for hexachlorobiphenyl through decachlorobiphenyl congeners.

Characteristic Masses	Number of Chlorines	PCB Congener Class (Number of Congeners)				
		CL6-BP (42)	CL7-BP (24)	CL8-BP (12)	CL9-BP (3)	CL10-BP (1)
287.8	4	x(77.2)				
289.8	4	x(100)				
291.8	4	x(48.6)				
293.8	4	x(10.5)				
321.8	5		x(61.7)			
323.8	5		x(100)			
325.8	5		x(64.8)			
327.8	5		x(21)			
329.8	5		-			
355.8	6	-		x(51.4)		
357.8	6	x(51.4)		x(100)		
359.8	6	x(100)		x(81)		
361.8	6	x(81)		x(35)		
363.8	6	x(35)		-		
389.7	7		-		x(44.1)	
391.7	7		x(44.1)		x(100)	
393.7	7		x(100)		x(97.2)	
395.7	7		x(97.2)		(17)	
397.7	7		x(17)		-	
423.7	8			-		x(34)
425.7	8			x(34)		x(88.2)
427.7	8			x(88.2)		x(100)
429.7	8			x(100)		x(64.8)
431.7	8			x(64.8)		x(26.2)
433.7	8			x(26.2)		-
459.6	9				x(26.5)	
461.6	9				x(77.2)	
463.6	9				x(100)	
465.6	9				x(75.6)	
467.6	9				x(36.7)	
493.6	10					x(21.2)
495.6	10					x(68.6)
497.6	10					x(100)
499.6	10					x(86.4)
501.6	10					x(19)

The following is a copy of the ESC/UMG Good Laboratory Practices Manual.

MONS 023005


Copy Number: _____

GOOD LABORATORY PRACTICES MANUAL

A Guide to Quality Control/Quality Assurance

Ultratrace Analysis Group

March 1984


James J. Brooks
Group Leader, Ultratrace Analysis


H. A. Woltermann
Manager, Environmental Sciences Center

Issued to: _____

Date: _____

Environmental Sciences Center
Dayton Laboratory
Dayton, Ohio 45407

JL3/JOB A

MCNS 023006

TABLE OF CONTENTS

	<u>Page</u>
I Objectives	1
II Scope	1
III Analysis	1
A. Methods	1
B. QA/QC Program	2
1. Sample Preparation QA/QC	2
a. Method Blanks	2
b. Replicates	2
c. Spikes	2
2. Instrumental Analysis QA/QC	3
a. Instrumentation	3
b. Blanks	4
c. Quantitation Internal Standard	4
d. Standards	4
C. Degrees of Quantitation	4
1. Qualitative Analysis	7
a. Tentative	7
b. Confirmed	7
2. Semi-Quantitative Analysis	7
3. Quantitative Analysis	7
D. Quality Criteria and Remedial Action	8
1. Quality Criteria	8
a. Blanks	8
b. Recoveries	8
c. Precision	8
d. Limit of Detection	9
e. Accuracy	9
2. Remedial Action	9
IV Data	9
V Sample Disposal	10

FIGURES

<u>Figure</u>	<u>Page</u>
1 Example of GC/MS Logbook page	5
2 Example of GC/EC Logbook page	6
3 Example of Disc/Tape Logbook page	11

I. Objectives

The main objectives of the Ultratrace Analysis Group quality assurance/quality control program are: 1) to assure that our laboratory generates high quality results; and 2) to maintain the necessary records that document laboratory performance.

II. Scope

The scope of this manual includes areas of GLP not specifically addressed in the ESC section manual and expands upon certain areas where QA/QC practices differ from those described in the section manual. It is intended to be used along with the section manual to provide a complete picture of the GLP within the Ultratrace Analysis Group.

III. Analysis

The generation of analytical results within the Ultratrace Analysis Group routinely involves two processes: sample preparation and instrumental analysis. Sample preparation involves one or more of a variety of techniques including extraction, dilution, acid/base washes, column chromatography, concentration and numerous other techniques to render the sample in a suitable condition for instrumental analysis. Instrumental analysis takes the suitably prepared sample and introduces it into an analytical instrument to measure the desired parameter(s). Both of these processes can be described by clearly defined and separable methods called sample preparation methods (SPMs) and instrumental analysis methods (IAMs). SPMs and IAMs may be combined in numerous ways (depending upon the nature of the samples and the needs of the customer) to produce a successful analytical protocol. For example, several different SPMs may be used to produce samples that are suitable for analysis by a single IAM. The measures incorporated into each of these experimental processes to ensure that an assessment of the quality of the results can be made constitute the QA/QC program for a project. The following subsections describe the elements of the analysis process:

A. Methods

Methods are the written documentation that describe the analytical process. They contain sufficient detail such that a competent scientist or technician can readily perform the required analyses. The usual practice is to have methods that describe the sample preparation process (SPMs) and methods that describe the instrumental analysis process (IAMs). Each method developed within the Ultratrace Analysis Group is assigned a method number as described in the ESC Section Manual.

Methods are obtained from various sources including in-house development, modification/adaptation of literature methods, or specific protocol methods dictated by government agencies. Methods may be formally validated by a series of experiments that describe a classical validation protocol or may be less vigorously proven owing to factors such as frequency of use, customer needs and

cost/timing restrictions. In any case a QA/QC program is applied to the analysis process to provide a measure of the quality of the results. Unless a QA/QC program is prescribed by a required protocol (e.g., EPA 821-D in Soil protocol), certain minimum QA/QC measures (depending upon the analysis type) are incorporated into all Ultratrace Analysis projects. The following subsection describes the Ultratrace QA/QC program:

3. QA/QC Program

An effective QA/QC program incorporates experiments that provide information relative to each of the following questions:

- (1) Are there any impurities, background or contamination that will influence the results?
- (2) How reproducible are the results?
- (3) How well can the analyte be recovered from the sample matrix?
- (4) What is the limit of detection for the analysis?
- (5) What is the dynamic range of the analysis?
- (6) What is the accuracy of the analysis?

All of these questions are addressed by properly selecting/applying the use of blanks, replicates, spikes and standards in a QA/QC program. The discussion of the use of these QA/QC techniques as they apply to Ultratrace Analysis Group activities is best done by considering the sample preparation and instrumental analysis processes separately.

1. Sample Preparation QA/QC

- a. Method blanks - Representative glassware, solvents and reagents are used with sample matrices which are similar to those for which results are being reported, yet do not contain the analytes of interest. Method blanks are analyzed at a frequency equal to 10% of the analyzed samples for sample sets which are multiples of 10. At least one method blank is analyzed for sample sets containing between 1 and 9 samples.
- b. Replicates - If sufficient sample amounts have been submitted for analysis, replicate frequency is the same as the method blank frequency. If at all possible, replicates should be obtained from the same sample bottle in order to minimize sample inhomogeneity problems due to samples being taken at slightly different times.
- c. Spikes - If sufficient sample is available for each sample type, the sample is split and spiked at two levels with

the native (unlabeled) analyte(s). The levels are typically 2x (low) and 20x (high) the anticipated detection limit and serve as a technique for estimating the limit of detection for each matrix. These low and high spikes are conducted at a frequency equal to the Method Blank frequency. Obviously spiking with the native analyte cannot be done for widespread analysis since this presupposes knowledge of the identity of the analyte(s) in the sample.

Other spiking techniques are used to evaluate the extraction/recovery efficiencies for the analyte(s) of interest. Ideally extraction/recovery efficiencies are determined for each sample, since, in principle, each sample may represent a different matrix. This can be done very easily when the detection technique is mass spectrometry if an isotopically labeled version of the analyte(s) is available. Documentation of extraction/recovery efficiencies is not required for each sample if the sample matrix for a set of samples is constant. However, for a sample set for which the similarity of samples is not known, and for which adequate sample is available, each sample must be split and spiked with a known amount of the analyte(s) of interest to determine extraction efficiency. If adequate sample size is not available or the identity of the analyte(s) is not known before the fact (i.e., widespread analysis), surrogate spiking compounds may be used to assess extraction efficiencies in each sample without actually spiking each sample with the analyte(s) of interest. The choice of the surrogate spiking compound is tailored for each analyte. This surrogate must be chosen so that it is either chemically identical to the analyte of interest (for example using isotopically labeled analogues of the analytes), or is closely similar in terms of liquid/liquid partition properties, chemical reaction properties, column elution properties or other matrix isolation properties which are used to isolate the analyte(s) from the sample matrix. Another property of the surrogate spiking compound is that it not be present in the sample being analyzed.

2. Instrumental Analysis QA/QC

The final step in obtaining analytical results involves the use of an appropriate instrumental technique to produce the analytical data. Several QA/QC practices must be incorporated in this process to ensure validity of the data.

a. Instrumentation

Careful documentation of instrument usage, calibration, and maintenance is essential for the generation of high quality results. Each major instrument within the Ultratrace Analysis Group will be the assigned responsibility of a professional employee designated as the Instrument Steward. The Instrument Steward is responsible for making sure that logbooks are available and properly completed by instrument users. It is the

responsibility of each individual using the equipment to record all the pertinent data required in the logbook. An example of a page from a GC/MS logbook is given in Figure 1 and that of a GC/EC logbook is given in Figure 2.

Instruments will be calibrated according to the instrument manufacturers' specifications or according to the method being used with the instrument. A log of instrument calibration will be maintained with the instrument.

The Instrument Steward will be responsible for ensuring that preventative and corrective maintenance programs are carried out on all instruments under his/her responsibility. If a specific problem is noted by an instrument user, it should be noted in the logbook and the Instrument Steward notified so that appropriate corrective action can be taken.

b. Blanks

A solvent blank will be analyzed at a frequency equal to the method blank. The method blank can serve as the solvent blank provided it is clean in the area of the analyte(s) of interest. This practice eliminates the possibility of background instrumental contamination.

c. Quantitation Internal Standard

A quantitation internal standard will be added to each sample following sample preparation but prior to instrumental analysis. This compound will serve for determining relative response factors and for correcting for variations in sample injection volumes and evaporation of solvents.

d. Standards

Standards are solutions of the analyte(s) of interest used to determine the response of the detector over the range of analyte concentrations found in the samples. For Quantitative analyses, sufficient standards and replication of standards will be run to demonstrate linearity and precision of the detector response over the range of analyte concentrations. Should sample concentrations fall outside the demonstrated linear range, either additional standards are prepared to expand the range, or appropriate dilution/concentration of the sample is done to place it in the proper range.

C. Degree of Quantitation

The information provided for any particular analysis is tailored to the needs of the customer. In actual practice these needs vary across the broad continuum from the grossly qualitative to the precisely quantitative. It is informative to examine what is involved in providing the varying degrees of quantitation required by our customers.

HP 5985A

CHARTERED REGISTERED COMPANY
NUMBER 1488907

SUBJECT _____ ON TO _____ IS _____ READ AND CHECK RETURN BY ME _____
 DECLASSIFY _____ ON TO _____ IS _____
 AND BY _____

MUC-DA
NY 10007

[illegible]

FIGURE 1. Example of CC/MS Logbook page.

MONS 023012

HP 5080 GC/EC

SUBJECT _____ DATE _____ TO _____ FROM AND ORIGINATOR OF INFO _____
 DISPOSITION _____ DATE _____ TO _____
 AND BY _____

INOC-DA
NY 10000

NAME	AGE	SEX	DATE	TIME	LOCATION	REMARKS
John Doe	25	M	1945	10:30	Room 101	Admission
Jane Smith	22	F	1945	11:00	Room 102	Admission
Robert Johnson	30	M	1945	11:30	Room 103	Admission
Mary Brown	28	F	1945	12:00	Room 104	Admission
James Wilson	35	M	1945	12:30	Room 105	Admission
Elizabeth Davis	27	F	1945	13:00	Room 106	Admission
Charles Miller	32	M	1945	13:30	Room 107	Admission
Patricia Moore	24	F	1945	14:00	Room 108	Admission
William Taylor	38	M	1945	14:30	Room 109	Admission
Barbara White	26	F	1945	15:00	Room 110	Admission
Richard Black	33	M	1945	15:30	Room 111	Admission
Susan Green	29	F	1945	16:00	Room 112	Admission
Thomas King	31	M	1945	16:30	Room 113	Admission
Linda Lee	23	F	1945	17:00	Room 114	Admission
George Hall	36	M	1945	17:30	Room 115	Admission
Michelle Carter	25	F	1945	18:00	Room 116	Admission
Donald Evans	34	M	1945	18:30	Room 117	Admission
Kimberly Scott	27	F	1945	19:00	Room 118	Admission
Christopher Adams	37	M	1945	19:30	Room 119	Admission
Nicole Baker	24	F	1945	20:00	Room 120	Admission
Steven Nelson	39	M	1945	20:30	Room 121	Admission
Ashley Hunt	26	F	1945	21:00	Room 122	Admission
Gregory King	32	M	1945	21:30	Room 123	Admission
Heather Wright	28	F	1945	22:00	Room 124	Admission
Timothy Green	35	M	1945	22:30	Room 125	Admission
Crystal Reed	25	F	1945	23:00	Room 126	Admission
Benjamin Cook	38	M	1945	23:30	Room 127	Admission
Victoria Bell	27	F	1945	24:00	Room 128	Admission
Jonathan Hill	31	M	1945	24:30	Room 129	Admission
Stephanie Young	29	F	1945	25:00	Room 130	Admission
Eric Peterson	36	M	1945	25:30	Room 131	Admission
Rebecca Gray	26	F	1945	26:00	Room 132	Admission
Robert King	33	M	1945	26:30	Room 133	Admission
Michelle Lee	28	F	1945	27:00	Room 134	Admission
Christopher Hall	37	M	1945	27:30	Room 135	Admission
Nicole Scott	24	F	1945	28:00	Room 136	Admission
Steven Adams	39	M	1945	28:30	Room 137	Admission
Ashley Baker	26	F	1945	29:00	Room 138	Admission
Gregory Carter	32	M	1945	29:30	Room 139	Admission
Heather Evans	28	F	1945	30:00	Room 140	Admission
Timothy Green	35	M	1945	30:30	Room 141	Admission
Crystal King	25	F	1945	31:00	Room 142	Admission
Benjamin Lee	38	M	1945	31:30	Room 143	Admission
Victoria Scott	27	F	1945	32:00	Room 144	Admission
Jonathan Adams	31	M	1945	32:30	Room 145	Admission
Stephanie Baker	29	F	1945	33:00	Room 146	Admission
Eric Carter	36	M	1945	33:30	Room 147	Admission
Rebecca Evans	26	F	1945	34:00	Room 148	Admission
Robert Green	33	M	1945	34:30	Room 149	Admission
Michelle King	28	F	1945	35:00	Room 150	Admission
Christopher Lee	37	M	1945	35:30	Room 151	Admission
Nicole Scott	24	F	1945	36:00	Room 152	Admission
Steven Adams	39	M	1945	36:30	Room 153	Admission
Ashley Baker	26	F	1945	37:00	Room 154	Admission
Gregory Carter	32	M	1945	37:30	Room 155	Admission
Heather Evans	28	F	1945	38:00	Room 156	Admission
Timothy Green	35	M	1945	38:30	Room 157	Admission
Crystal King	25	F	1945	39:00	Room 158	Admission

FIGURE 2. Example of CC/EC Logbook page.

MONS 023013

1. Qualitative Analysis

Qualitative analysis implies no quantitation at all but rather seeks only the identity of the compound(s) present. GC/MS is particularly applicable to this type of analysis problem. Two types of identifications can be made:

a. Tentative

A tentative identification is made on the basis of the analyst's judgement of a match between the mass spectrum from the sample and a mass spectrum from a reference library. This is often done for the large number of compounds found in a widearea organic analysis.

b. Confirmed

A confirmed identification requires that the chromatographic retention time and the mass spectrum of the unknown compound match those of a known standard of the tentatively identified compound. This is often done in widearea analyses when standards can be obtained for tentatively identified compounds that are of concern.

The normal QA/QC requirements for qualitative analysis are (1) analysis of a blank, (2) analysis of duplicate samples and (3) use of a calibration compound (usually Dechlorotriphenylphosphine, DFTPP) to assure that the mass spectrometer will produce mass spectra that can be compared with library spectra.

2. Semi-Quantitative Analysis

Semi-Quantitative Analysis extends the information provided by a qualitative analysis to include some estimate of the amount of analyte(s) present. The method of semi-quantitation involves the comparison of detector response of the analyte(s) with that of an internal standard. The estimated concentration is obtained by assuming a unit response factor between the analyte(s) and the internal standard(s). An indication of recovery from the sample matrix is obtained from the recovery of the surrogate internal standard(s).

3. Quantitative Analysis

Quantitative Analysis provides for the accurate assessment of the amount of analyte(s) present in a sample. To be able to do quantitative analysis one must know the identity of the analyte so that standards can be prepared for spiking and for the generation of calibration curves. The method of quantitation is based on a three-point calibration curve using standards of the analyte(s) of interest over the range of concentrations in the samples. A one-point calibration method can be used (as with the laboratory data

system) provided that linearity has been demonstrated over the concentration range of the samples using standards of the analyte(s) at three concentrations in the range. This calibration curve is then used to provide concentrations of the analyte(s) in the samples via an external standards method or more preferably via an internal standards method. For the internal standards method, the quantitative internal standard is added to each of the standards (just as with the samples) prior to instrumental analysis and relative response factors are determined.

For quantitative analysis the mass spectrometer is operated as a gas chromatographic detector. The MS is therefore tuned and operated in a manner specified in the approved method rather than using a calibration compound as required for qualitative analyses.

D. Quality Criteria and Remedial Action

The inclusion of QA/QC measures into an analysis program has little meaning unless the results are interpreted and appropriate action is taken when necessary. The ability to do this assumes some set of criteria that will trigger a response or remedial action. The following subsections describe the criteria that are used in the Ultratrace Analysis Group to evaluate when quality control data indicate a need for corrective measures and what remedial action will be taken.

1. Quality Criteria

The overriding quality criterion above all others is: Do the results meet the needs of the customer. This determination will be made jointly between the customer and the analyst. The analyst must exercise caution in not allowing the customer to overstate, misinterpret or unintentionally misrepresent the data. In addition to this prime quality criterion, the following conditions must be met:

- a. Blanks - In the event that a blank produces a positive value, it may not be used as a valid blank if it exceeds 10% of any reported value for a sample.
- b. Recoveries - Recoveries for all surrogate and native spikes must lie in the range of 50% Recovery < 150%.
- c. Precision - Precision will be calculated based on the recoveries of surrogate internal standards. Average recoveries will be calculated with $\pm$ standard deviation for each sample set. Replicate analyses and low and high native spike recoveries may also be used to provide additional information/insight into the precision of the analysis.

- d. **Limit of Detection** - The limit of detection (LOD) will normally be stated as $\frac{1}{2}$ the value of the low level native spike if it is recovered and quantifiable. Should the low level native spike not be recovered, the LOD will be stated as $\frac{1}{2}$ the value of the high level native spike if it is recovered and quantifiable. Should neither spike be recovered, a decision must be made regarding the advisability of reprocessing the sample. Should all samples contain such large quantities of the analyte(s) that the levels of the low and high spikes are insignificant ($<10\%$) by comparison, the value of the LOD becomes less important and is simply stated as the LOD for the instrumental analysis process determined by the analysis of standards and the ability to recover the surrogate spikes.
- e. **Accuracy** - The accuracy of the analyses is best determined by analyzing some sample which contains the analyte at some predetermined level (e.g., an NBS standardized sample). If this type of standard is not available then the low level and high level spikes can be used as a measure of the accuracy of the analyses. Results must fall within a range of 75% to 120% of the accepted value for the analyses to be considered valid.

If the above quality criteria are not met the analyst will immediately assess the need for and extent of remedial action that may be necessary.

2. Remedial Action

The first course of action will be for the analyst and/or group leader to contact the customer and discuss the results pointing out the limitations of the data indicated by the quality control results. At this point the overriding quality criterion of customer needs will be addressed first. It could be that the customer's needs are met without meeting one or more of the other criteria. In such a case no remedial action is necessary. It could also be that the customer has such a demand for tightness in the results that his needs are not met even though the other quality criteria are. This would trigger further analyses with tighter quality control designed around the results obtained (e.g., replications of positives to better establish precision or spikes of non-detected samples to better establish the limit of detection).

In consultation with the customer additional experiments will be designed including the appropriate quality control to ultimately provide the results of sufficient quality to meet the customer's needs.

IV. Data

This section deals with the subject of data and how they are obtained, recorded and reduced so as to be useable in a report and yet readily available for referral and inspection.

The samples will be labeled with a log number at sample login according to the procedure described in the EEC Section GLP Manual. When delivered to the responsible technical person, the samples may then receive additional labeling as deemed necessary. This additional labeling will be documented in a laboratory logbook and/or notebook. These logbooks and notebooks will be used by the analysts to record all pertinent work and results obtained from the samples. The laboratory notebooks will be filled out in accordance with Monsanto Uniform Notebook Procedures.

All raw data generated for a given project, which cannot be conveniently placed in the laboratory notebook (e.g., chromatograms, computer output, etc.), will be filed under some prescribed order (i.e., log number) in a central file under the supervision of the Project Leader and/or QA Specialist.

Most of the data generated by the Ultratrace Analysis Group are computer data stored on magnetic discs. In order to archive these data the specific file name and disc number associated with the analysis will be written down in the laboratory notebook and/or instrument logbook. When the disc is completely full of data an entire unedited disc image or copy of the files on the disc will be transferred on magnetic tape. A logbook will be kept for recording the disc number, name and prefix associated with it, along with the associated tape and file number to which the disc was transferred. An example of such a logbook is given in Figure 3. When the data are transferred a verification program is used to check all transferred records for correctness. When tapes are filled (they typically hold seven to ten disc images) they should be stored in a fireproof vault.

All calculations of the results of the data will be specified in the method used. These calculations will be entered in the analysts laboratory notebook unless they are computer generated. In this case, a copy of the computer output will be filed with the raw data. The Project Leader will be responsible for checking the correctness of the data.

V. Sample Disposal

Samples will be disposed of in accordance with the instructions on the Analysis Request form. The only exception to this would result when the analysis reveals a problem which requires sample disposal in a manner other than that originally specified. If the Project Leader notes from the results of the analysis that a potentially toxic product was present in the samples then the samples will be disposed of in a manner deemed safe by the Safety Department. The date of sample disposal and the manner should be noted on the request form stored with the raw data completing the chain of custody of the sample.

CDN	(Multi-Drive Designation)	Person Opened	Date Opened	Person Taped	Date Taped	Tape # (File #)
100	(A00)	BWH	3/1/83	BWH	3/17/83	GD 69(1)
101	(A01/A02)	AWB	3/1/83			GD 69(5)
102	(A02)		3/1/83			GD 69(6)
103	(A03)					GD 69(7)
104	(A04)					GD 69(8)
200	(B01) JTB	AWB	3/1/83	BWH	3/1/83	GD 69(8)
105	(A005) [A0]	BWH	3/1/83	BWH	3/14/83	GD 69(9)
106	(A006) [A0]	BWH	3/1/83	LSK	5/12/83	GD 72(1)
107	(A007) [A0]	SM	3-11-83	LSK		GD 73(2)
108	(A008) [A0]	SM	3-11-83	LSK		GD 73(3)
1	(A000) [A0]	-	-	BWH	3/11/83	GD 69(0)
200	(A001) [A0] - A002	AWB	3/1/83	BWH	3/15/83	GD 71(1)
113	(A013) [A0]	BWH	3/1/83			GD 71(3)
114	(A014) [A0]	-				GD 71(4)
109	(A009) [A0]	SM	3/1/83	LSK	5/1/83	GD 73(4)
110	(A010) [A0]	SM	3/1/83	LSK	5/1/83	GD 73(5)
111	(A011) [A0]	AWB	3/1/83	SB	4/27/83	GD 73(6)
112	(A002)			SB	4/1/83	GD 73(7)
113	(A003)			SB	5/1/83	GD 73(8)
114	(A004)			SB	5/27/83	GD 73(9)
115	(A005)			SB	5/27/83	GD 73(10)
116	(A006)			SB	4/17/83	GD 72(2)
117	(A007)			SB	4/27/83	GD 72(3)
118	(A008)			SB	4/27/83	GD 72(4)
119	(A009)			SB	4/27/83	GD 72(5)
120	(A010)			SB	4/27/83	GD 72(6)
200	(B01) JTB	AWB	3/1/83	SB	4-2-83	GD 72(7)
101	(A001) [A0]	BWH	5/1/83	LSK	7/1/83	GD 72(7)
102	(A002)		5/1/83	LSK		(8)
103	(A003)		-	LSK		(9)

FIGURE 3. Example of DISC/Tape Logbook page.

CHAIN OF CUSTODY

Date of Collection: _____

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>SAK-G</u>	_____	_____	_____	_____	_____
_____	_____	_____	_____	_____	_____
_____	_____	_____	_____	_____	_____

Location of Sampling: CBD 031037 Producer SOFFER Mawler _____ Disposal Site
Other (Explain) _____

Address of Sampling: Monsanto Chocolate Bayou

Type of process producing sampled material: Organic Chemical Process

FIELD
INFORMATION

SHIPPER

Monsanto Company
P. O. Box 2001 711
Tomball, Texas 77058
Alvin 77511

Telephone: ²¹⁵ (800) 343-4571

Contact: R.B. Gray

COLLECTOR

Collector's Name: Dennis Maxton Telephone: (714) 571-7111

Collector's Affiliation: Monsanto Company

Address: P.O. Box 711 Alvin, Tx 77511

Company Contact: R.B. Gray Extension: 4571

SAMPLE
ALLOCATION

1. Name, address, and telephone number of organization receiving sample

2. Name, address, and telephone number of organization receiving sample

3. Name, address, and telephone number of organization receiving sample

CHAIN OF POSSESSION

Signature <u>Dennis Maxton</u>	Title <u>Inspector</u>	Inclusive Dates <u>3/29/84</u>
Signature <u>Nelson Snelker</u>	Title <u>ERT</u>	Inclusive Dates <u>4-9-84</u>
Signature <u>Pat Hays</u>	Title <u>Log Tech</u>	Inclusive Dates <u>4-12-84</u>
Signature _____	Title _____	Inclusive Dates _____

MONS 023019

CHAIN OF CUSTODY

Date of Collection: _____

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
54					

Location of Sampling: CRC 102511 Producer SAFIC Hauler _____ Disposal Site _____
Other (Explain) _____

Address of Sampling: Monsanto Chocolate Bayou

Type of process producing sampled material: Organic chemical process

FIELD
INFORMATION

SHIPPER

Monsanto Company
P. O. Box 4801 711
Canton, Texas 75009
Alvin 77511

Telephone: ²¹⁵ (800) 373-4531

Contact: R. B. Gray

COLLECTOR

Collector's Name: Bernie Maxton Telephone: ⁽²¹⁵⁾ 381-2161

Collector's Affiliation: Monsanto Company

Address: P.O. Box 711 Alvin, Tx 77511

Company Contact: R. B. Gray Extension: 7571

SAMPLE
ALLOCATION

1. Name, address, and telephone number of organization receiving sample

2. Name, address, and telephone number of organization receiving sample

3. Name, address, and telephone number of organization receiving sample

CHAIN OF POSSESSION

<u>Donnie M. Taylor</u> Signature	<u>Donnie M. Taylor</u> Title	<u>3/29/84</u> Inclusive Dates
<u>John Blanchard</u> Signature	<u>John Blanchard</u> Title	<u>4-9-84</u> Inclusive Dates
<u>Pat Hays</u> Signature	<u>Pat Hays</u> Title	<u>4-12-84</u> Inclusive Dates
_____ Signature	_____ Title	_____ Inclusive Dates

CHAIN OF CUSTODY

Date of Collection: _____

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>KSL-50</u>	_____	_____	_____	_____	_____
_____	_____	_____	_____	_____	_____
_____	_____	_____	_____	_____	_____
_____	_____	_____	_____	_____	_____

Location of Sampling: CBC 9029 Producer SABIC Hauler _____ Disposal Site
Other (Explain) _____

Address of Sampling: Monsanto Charlotte Bayou

Type of process producing sampled material: Organic Chemical Process

FIELD
INFORMATION

Monsanto Company
P. O. Box 2004 711
Houston, Texas 77000
Alvin 77511

Telephone: ⁷¹³ (409) 593-7571
Contact: R.B. Gray

Collector's Name: Pennie Maxton Telephone: (713) 581-2161

Collector's Affiliation: Monsanto Company

Address: P.O. Box 711 Alvin, TX 77511

Company Contact: R.B. Gray Extension: 4571

COLLECTOR

SAMPLE
ALLOCATION

1. Name, address, and telephone number of organization receiving sample

2. Name, address, and telephone number of organization receiving sample

3. Name, address, and telephone number of organization receiving sample

James W. M. Payton Chairman 3/28/84
Signature Title Inclusive Dates

Robert D. Dandridge EAAT 4-5-84
Signature Title Inclusive Dates

Pat Hays Lowin Tech 4-12-84
Signature Title Inclusive Dates

Signature Title Inclusive Dates

Signature Title Inclusive Dates

CHAIN OF POSSESSION

CHAIN OF CUSTODY

Date of Collection: 4-6-84

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>A215</u>	<u>1030</u>				

Location of Sampling: 16-04 Producer: Monsanto Hauler: _____ Disposal Site: _____
Other (Explain): _____

Address of Sampling: P.O. Box 711 ALVIN, TEXAS. 77511

Type of process producing sampled material: ORGANIC CHEMICAL PROCESS

FIELD INFORMATION

SHIPPER

Monsanto Company
P. O. Box 1004711
Kansas City, Texas 76600
Alvin 77511
Telephone: (809) 397-4521
Contact: R. B. Gray

COLLECTOR

Collector's Name: T. R. KENNEDY Telephone: 013 5812161
Collector's Affiliation: MONSANTO CO.
Address: P.O. Box 711 ALVIN, TEXAS. 77511
Company Contact: R. B. Gray Extension: 4571

SAMPLE ALLOCATION

- Name, address, and telephone number of organization receiving sample
- Name, address, and telephone number of organization receiving sample
- Name, address, and telephone number of organization receiving sample

CHAIN OF POSSESSION

Signature: <u>J.R. Kennedy</u>	Title: <u>Production Specialist</u>	Inclusive Dates: <u>4/6/84</u>
Signature: <u>John Hendrick</u>	Title: <u>EAST</u>	Inclusive Dates: <u>4-9-84</u>
Signature: <u>Pat H. Lee</u>	Title: <u>Logistics</u>	Inclusive Dates: <u>4-12-84</u>
Signature: _____	Title: _____	Inclusive Dates: _____

CHAIN OF CUSTODY

Date of Collection: 4-6-84

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>A-228</u>	<u>1030</u>				

Location of Sampling: 16-5/d Producer: MONSANTO Other (Specify): _____ Disposal Site: _____

Address of Sampling: PO. BOX 711, ALVIN TEXAS, 77511

Type of process producing sampled material: ORGANIC CHEMICAL PROCESS

FIELD INFORMATION

SHIPPER

Monsanto Company
P. O. Box 3001
ALVIN, TEXAS 77511

Telephone: (409) 393-4552

Contact: A.B. Gray

COLLECTOR

Collector's Name: T.R. Kennedy Telephone: 013 581216

Collector's Affiliation: MONSANTO CO

Address: PO. BOX 711, ALVIN, TEXAS, 77511

Company Contact: R.B. Gray Extension: 4571

SAMPLE ALLOCATION

1. Name, address, and telephone number of organization receiving sample

2. Name, address, and telephone number of organization receiving sample

3. Name, address, and telephone number of organization receiving sample

CHAIN OF POSSESSION

Signature: T.R. Kennedy Title: Production Specialist Inclusive Dates: 4/6/84

Signature: Nelson Planchard Title: EAAT Inclusive Dates: 4-9-84

Signature: Bob Hays Title: Logistics Tech Inclusive Dates: 4-12-84

Signature: _____ Title: _____ Inclusive Dates: _____

Signature: _____ Title: _____ Inclusive Dates: _____

Signature: _____ Title: _____ Inclusive Dates: _____

Signature: _____ Title: _____ Inclusive Dates: _____

MONS 023023

CHAIN OF CUSTODY

Date of Collection: 2-21-84

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>A-230</u>	<u>1600</u>				

Location of Sampling: T23-1 Producer MONSANTO Neuler _____ Disposal Site _____
Other (Explain) _____

Address of Sampling: P.O. Box 711 ALVIN, TEXAS 77511

Type of process producing sampled material: ORGANIC CHEMICAL PROCESS

FIELD INFORMATION

SHIPPER

Monsanto Company
P. O. Box 8004 711
Seawater, Texas 77511
Alvin 77511
Telephone: (409) 371-9521
Contact: R. B. GRAY

COLLECTOR

Collector's Name: J. R. KENNEDY Telephone: (409) 581-2111
Collector's Affiliation: MONSANTO CO.
Address: P.O. Box 711 ALVIN, TEXAS 77511
Company Contact: R. B. GRAY Extension: 4571

SAMPLE ALLOCATION

- Name, address, and telephone number of organization receiving sample
- Name, address, and telephone number of organization receiving sample
- Name, address, and telephone number of organization receiving sample

CHAIN OF POSSESSION

<u>J. R. Kennedy</u>	<u>Production Specialist</u>	<u>4-6-84</u>
Signature	Title	Inclusive Dates
<u>Nelson Blanchard</u>	<u>EAT</u>	<u>4-9-84</u>
Signature	Title	Inclusive Dates
<u>Keith H. 30</u>	<u>Logan Tech</u>	<u>4-12-84</u>
Signature	Title	Inclusive Dates
Signature	Title	Inclusive Dates

CHAIN OF CUSTODY

Date of Collection: 4/2/84

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>0135</u>	<u>0135</u>				
<u>0135</u>	<u>0135</u>				
<u>0135</u>	<u>0135</u>				

Location of Sampling: Chocolate Producer Monsanto Hauler _____ Disposal Site _____
As Eucalyptus Other (Explain) _____

Address of Sampling: P.O. Box 711, Abilene, Texas 79511

Type of process producing sampled material: _____

- ① Formaldehyde produced in formalin unit
② Diphenyl Oxide (DPO) generated from phenol
③ Terminus VP-1 is a blend of DPO and biphenyl

FIELD INFORMATION

SHIPPER

Monsanto Company
P. O. Box 3344 711
Tempe, Arizona 85284
Abilene, Texas 79511

Telephone: (409) 393-4571

Contact: Randy Gray

COLLECTOR

Collector's Name: Mark Lumpkin Telephone: (713) 393-4230

Collector's Affiliation: Monsanto processor

Address: P.O. Box 711, Abilene, Texas

Company Contact: Robin Fawcett Extension: 393-4572

SAMPLE ALLOCATION

1. Mark Lumpkin, Monsanto, P.O. Box 711, Abilene, Texas 79511 713-393-4230
Name, address, and telephone number of organization receiving sample

2. Robin Fawcett, Monsanto, P.O. Box 711, Abilene, Texas 79511 713-393-4572
Name, address, and telephone number of organization receiving sample

3. _____
Name, address, and telephone number of organization receiving sample

CHAIN OF POSSESSION

Mark Lumpkin PRECASSON (RESID) 4-2-84
Signature Title Inclusive Dates

RE Bourcett Production Engineer 4-2-84
Signature Title Inclusive Dates

W. Fawcett EAT 4-2-84
Signature Title Inclusive Dates

Robin Fawcett _____ 4-10-84
Signature Title Inclusive Dates

MONS 023025

CHAIN OF CUSTODY

Date of Collection: 3-30-84

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>B</u>	<u>1500</u>				

Location of Sampling: 40M-3 Producer IDA Hauler _____ Disposal Site _____
Other (Explain) _____

Address of Sampling: Monsanto Chocolate Bayou

Type of process producing sampled material: Chemical Process

FIELD
INFORMATION

SHIPPER

Monsanto Company
P. O. Box 1344-711
Texas City, Texas 77590
ALCOA 77511

Telephone: (409) 313-4521

Contact: R. B. Gray

COLLECTOR

Collector's Name: S. H. Poole Telephone: () 3034621

Collector's Affiliation: Monsanto

Address: P.O. Box 711 Alvin, TX 77511

Company Contact: Randall Gray Extension: 4571

SAMPLE
ALLOCATION

1. Name, address, and telephone number of organization receiving sample

2. Name, address, and telephone number of organization receiving sample

3. Name, address, and telephone number of organization receiving sample

CHAIN OF POSSESSION

R. B. Gray Production Specialist 3-30-84
Signature Title Inclusive Dates

Randall Gray Engineer 3-30-84
Signature Title Inclusive Dates

Michael Williams Shipper Monsanto 4-2-84
Signature Title Inclusive Dates

Signature Title Inclusive Dates

R. B. Hugo 4-11-84

MONS 023026

CHAIN OF CUSTODY

Date of Collection: 3-20-84

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>A</u>	<u>1500</u>				

Location of Sampling: SSA-1 Producer NTA Hauler _____ Disposal Site _____
Other (Explain) _____

Address of Sampling: Monsanto Chocolate Bayou

Type of process producing sampled material: Chemical Process

FIELD INFORMATION

SP. INFO

Monsanto Company Telephone: 713
P. O. Box 7000 711 393-4621
Jensen City, Texas 77500
4101 215 Contact: R. B. Gray

COLLECTOR

Collector's Name: S. H. Price Telephone: () 3934631
Collector's Affiliation: Monsanto
Address: PO Box 711 Abilene Tex. 77511
Company Contact: Randall Gray Extension: 4571

SAMPLE ALLOCATION

- Name, address, and telephone number of organization receiving sample
- Name, address, and telephone number of organization receiving sample
- Name, address, and telephone number of organization receiving sample

CHAIN OF POSSESSION

<u>S. H. Price</u>	<u>Production Specialist</u>	<u>3-20-84</u>
Signature	Title	Inclusive Dates
<u>Randall Gray</u>	<u>Engineer</u>	<u>3-20-84</u>
Signature	Title	Inclusive Dates
<u>Monte McRae</u>	<u>Shipper Monsanto CB</u>	<u>4-2-84</u>
Signature	Title	Inclusive Dates
Signature	Title	Inclusive Dates

Pat Hogg 4-11-84

MONS 023027

CHAIN OF CUSTODY

Date of Collection: 3-27-84

Collector's Sample No.	Time	Collector's Sample No.	Time	Collector's Sample No.	Time
<u>01</u>	<u>18:30</u>				

Location of Sampling: 326 712-2 Producer Monsanto Hauler _____ Disposal Site _____
Other (Explain) _____

Address of Sampling: MONSANTO, CINCINNATI, OHIO

Type of process producing sampled material: ORGANIC CHEMICAL PLANT

FIELD
INFORMATION

SHIPPER

Monsanto Company
P. O. Box 711
ALVIN Texas 77511

Telephone: ⁷¹³ (400) 581-2161
Contact: PANDOLL GRAY

COLLECTOR

Collector's Name: DAVID SALDANA Telephone: (713) 581-2161
Collector's Affiliation: MONSANTO
Address: P.O. BOX 711, ALVIN TX 77511
Company Contact: PANDOLL GRAY Extension: 4571

SAMPLE
ALLOCATION

- Name, address, and telephone number of organization receiving sample
- Name, address, and telephone number of organization receiving sample
- Name, address, and telephone number of organization receiving sample

QUALITY OF POSSESSION

<u>David Saldana</u>	<u>Processor</u>	<u>3-27-84</u>
Signature	Title	Inclusive Dates
<u>Robert P. ...</u>	<u>EA+V</u>	<u>4-3-84</u>
Signature	Title	Inclusive Dates
<u>Robert P. ...</u>	<u>Shipper Monsanto CB</u>	<u>4-4-84</u>
Signature	Title	Inclusive Dates
<u>Robert P. ...</u>	<u>4-11-84</u>	
Signature	Title	Inclusive Dates

MONS 023028