

worn during all procedures starting with the removal of wheels and including reassembly.

- (3) When removing worn friction materials, remove the accumulated dust in the assemblies with an industrial vacuum cleaner equipped with a high efficiency filter system. If such equipment is not available, dust can be removed with a damp cloth. Do not use compressed air or dry brushing for cleaning unless the assembly is enclosed and properly exhausted.
- (4) Whenever possible, purchase friction materials preground and ready for installation. If matching is necessary, the precautions which must be taken are of extreme importance. This is the operation in brake service when exposure to asbestos dust may be at its highest. This increases the difficulty in complying with the OSHA standards. In addition to the approved respirator, there must be local exhaust ventilation such that worker exposures are maintained below the OSHA asbestos standards. If there is any question as to the efficiency of asbestos dust removal by the machine, the manufacturer should be contacted.
- (5) Industrial vacuum cleaner bags containing asbestos dust and cloths used for wiping brake assemblies should be sealed in plastic bags and labeled with the following warning label printed in letters of sufficient size and contrast to be readily visible and legible.

Caution
Contains Asbestos Fibers
Avoid Creating Dust
Breathing Asbestos Dust May Cause Serious
Bodily Harm

All asbestos waste should be disposed of in accordance with OSHA and EPA asbestos regulations. During removal of vacuum bags, an approved respirator, as described in (2) above should be worn.

- (6) Good housekeeping is essential in a workplace where asbestos containing materials are handled. Industrial vacuum cleaners equipped with multiple stage high efficiency filters should be used for removing accumulations of asbestos dust and waste. Never use compressed air or dry sweeping for cleaning. Water or other dust suppressants should be applied if brooms are used.