

cient to warm the air needed to meet the ventilating requirements, a corresponding reduction may be made in the amount of direct radiation installed. The greater the amount of excess capacity of the unit, the more efficient will be the temperature regulation of the room. The split system permits the heating of the room during failure of electric current, since the direct radiators will furnish heat, but it permits a careless operator to avoid operating the ventilating equipment.

The *combined* system employs a unit ventilator with sufficient capacity for both ventilation and the normal heat transfer losses. In such a case no direct radiation is required. The necessary operation of the fan when the room is being heated also gives assurance that some ventilation is being provided, especially if automatic dampers are used in the air intake and in the recirculating intake. These dampers are arranged to provide a certain quantity of outside air, depending upon the weather conditions. The cost of installation of a combined system is usually less than that of a split system and there is less danger of overheating, but if the electric energy fails there will be available only the heating effect of the units acting as convectors.




FIG. 10. TYPICAL WINDOW VENTILATOR

Location of Unit Ventilator

The location of the unit ventilator in a room is important. Wherever possible it should be placed against an outside wall and on the center line of the room. It is difficult to obtain proper air distribution if the unit is installed either on an inside wall or in a corner of the room. Standard units discharge the air stream upward, but for special cases units may be installed to discharge air horizontally. Units may be set away from the wall or partially recessed into the wall to save space without materially affecting the results. The air inlet may enter the cabinet at the back at any point from top to bottom.

Air Exhaust Vents and Flues

The size and location of the air exhaust vent* outlet is important. In many cases the sizes for public buildings are regulated by law.

In cases where no codes govern, the location and size of vents are left to the discretion of the engineer.

Best results have been obtained with a velocity through the vent openings nearly equal to that at which the air is introduced into the room, thus maintaining a slight pressure in the room. Calculated velocities at the

vent openings of from 600 to 800 fpm produce the best diffusion results from this system. Many states, however, have regulations that will not permit velocities as high as 800 fpm. If a vent opening at or near the floor is near a desk or place where a person is seated, a velocity of 800 fpm in the vent opening will produce an objectionable draft. In such a case the velocity in the vent opening should not exceed 400 to 450 fpm, although duct velocities are maintained at 600 to 800 fpm if codes permit.

In school buildings provided with wardrobes or cloakrooms the vents may be so located that the air shall pass through these spaces, ventilating them with air which otherwise would be passed to the outside without being used to the best advantage. Many state codes for ventilation of public buildings make this arrangement mandatory.

WINDOW VENTILATORS

A window ventilator illustrated in Fig. 10 consists of filter and switch controlled motor driven fans enclosed in a cabinet to be mounted on the window sill. Such units accomplish ventilation, air cleaning, and air cir-




FIG. 11. TYPICAL UNIT HUMIDIFIER OF THE SPRAY TYPE WITH STEAM COIL TO PREHEAT THE AIR FOR RESIDENCES

ulation, but have no means of heating the air. The direction of air discharge is manually adjustable for seasonal operation.

UNIT HUMIDIFIERS

Unit humidifiers fall into four general classifications, depending on the method of causing evaporation. These are as follows: (1) *Nozzle Type*, (2) *Rotary Type*, (3) *Cascade Type*, and (4) *Heater Type*.

In the *nozzle type* of humidifier water is sprayed into the air and evaporation is effected by adiabatic exchange of energy. Units of this type in simplest form spray a fine mist of water directly into the air in a space. They are used to a great extent in the textile industry.

To the simple type of nozzle unit may be added the following accessories: a water heater whose function is to increase the vapor pressure, an air heater to heat the air either before or after humidification takes place, a screen or air filter over which the water is sprayed and through which the air is drawn for intimate contact with the water, a fan to create an air stream and to deliver air to the space to be humidified, and a housing to enclose all the elements. This type of unit has been made in practically all of the variations mentioned. It has the disadvantage of clogging the nozzles and must be serviced continually.

Fig. 11 illustrates a nozzle unit having a humidifying capacity sufficient for a residence or small building. These units usually include air filters and in some cases provide ventilation air by means of an outside air duct