

Table 4 of Chapter 8 indicates air changes commonly used but should be taken only as a guide. For further discussion of the method see section on Air Change Method in Chapter 8.

Crack Length to be Used for Computations

For designers who prefer to use the crack method the basis of calculation is as follows: The amount of crack used for computing the infiltration heat loss should not be less than half of the total crack in the outside walls of the room. For a building having no partitions, whatever wind enters through the cracks on the windward side must leave through the cracks on the leeward side. Therefore, take one-half the total crack for computing each side and end of the building. In a room with one exposed wall, take all the crack; with two exposed walls, take the wall having the most crack; and with three or four exposed walls, take the wall having the most crack; but in no case take less than half the total crack.

The total infiltration loss of a building having partitions will not be equal to the sum of the infiltration losses of the various rooms, since at any given time infiltration will take place only on the windward side or sides and not on the leeward side. Therefore, if a building has more than one room which is divided by interior walls or partitions, it is sufficiently accurate to use half of the total infiltration losses for determining the total heat requirements.

Latent Heat Loss

When it is intended to add moisture to air leaking into a room for the maintenance of proper winter comfort conditions, it is necessary to determine the heat equivalent to evaporate the required amount of water vapor, which may be calculated by the equation:

$$H_1 = Qd \left(\frac{m_i - m_o}{7000} \right) h_{fg} \quad (5)$$

where

H_1 = heat required to increase moisture content of air leaking into building from m_o to m_i , Btu per hour.

Q = volume of outside air entering building, cubic feet per hour.

d = density of air at temperature t_i , pounds per cubic foot.

m_i = vapor density of inside air, grains per pound of dry air.

m_o = vapor density of outside air, grains per pound of dry air.

h_{fg} = latent heat of vapor at m_i , Btu per pound.

If the latent heat of vapor (h_{fg}) is assumed to be 1060 Btu per pound, Equation 5 reduces to

$$H_1 = 0.0114 Q (m_i - m_o) \quad (5a)$$

Equations 4a, 4b and 5a may also be used for determining the sensible and latent heat gains due to infiltration in cooling load computations.

SELECTION OF WIND VELOCITIES

The effect of wind on the heating requirements of any building should be given consideration under two heads:

1. Wind movement increases the heat transmission of walls, glass, and roof, affecting poor walls to a much greater extent than good walls.

Heating Load

2. Wind movement materially increases the infiltration of cold air through the cracks around doors and windows, and even through the building materials themselves.

Theoretically as a basis for design, the most unfavorable combination of temperature and wind velocity should be chosen. It is entirely possible that a building might require more heat on a windy day with a moderately low outside temperature than on a quiet day with a much lower outside temperature. However, the combination of wind and temperature which is the worst would differ with different buildings, because wind velocity has a greater effect on buildings which have relatively high infiltration losses. It would be possible to compute the heating load for a building for several different combinations of temperature and wind velocity which records show to have occurred and to select the worst combination; but designers generally do not feel that such a degree of refinement is justified.

Therefore, since Table 1 lists the average velocity of winds occurring at temperatures equalled or exceeded 97½ per cent of the winter period for each locality, this value should be the basis for estimating infiltration losses. When using the air change method it will not be necessary to consider the wind velocities. Designers employing the crack method generally use values corresponding to a 15-mile wind. Due to the small effect of the wind velocity on the transmission coefficient, the values in Chapter 6, based on a 15-mile wind may be used at all times.

Exposure Factors

Many designers use empirical exposure factors to increase the calculated heat loss of rooms or spaces on the side or sides of the building exposed to the prevailing winds. However, according to a survey made in 1943, many GUIDE users have found that the use of exposure factors is not necessary as the GUIDE method of calculating heat losses provides an ample heat loss allowance. Therefore exposure factors may be regarded as *factors of safety* for the rooms or spaces exposed to the prevailing winds, to allow for additional capacity for these rooms or spaces, or to *balance the radiation*, particularly in the case of multi-story buildings. Although the exposure allowance is frequently assumed to be 15 per cent, the actual allowance to be made, if any, must to a large extent be a matter of experience and judgment of the designer, since there are at present no authentic test data available from which rules could be developed for the many conditions encountered in practice.

As stated previously, the value of U in the tables of Chapter 6 is based on a wind velocity of 15 mph and the surface resistance for this wind velocity (0.17) is sufficiently low so that higher wind velocities will decrease the surface resistance to a negligible degree and therefore have only a slight effect on the average over-all coefficient. On the other hand, infiltration losses vary almost directly as the wind velocity, as will be apparent from the factors in Table 2 of Chapter 8. The more exact method therefore would be to differentiate among the various exposures more accurately by calculating the infiltration and transmission losses separately for the different sides of the building, using different assumed wind velocities for the infiltration losses on the various sides.

AUXILIARY HEAT SOURCES

The heat supplied by persons, lights, motors and machinery should always be ascertained in the case of theaters, assembly halls, and industrial plants, but allowances for such heat sources must be made only